wolezek BL-B20B

Wolezek BL-B20B Grow Lights for Indoor Plants Instruction Manual

Model: BL-B20B
Brand: Wolezek

Introduction

Thank you for choosing Wolezek Grow Lights for your indoor plants. This manual provides essential information for the safe and effective use of your new grow light. Please read these instructions carefully before installation and operation, and retain them for future reference.

Product Features

- **Full Spectrum 80 LEDs:** Provides a powerful and efficient light source for healthy plant growth and higher yields.
- **3 Color Modes & 5 Brightness Levels:** Offers three color temperature options (6500K Natural White, 3000K Warm White & Red, 5000K All Light On) and five dimmable brightness levels to meet specific plant requirements at different growth stages.
- **Adjustable Gooseneck:** The 360° flexible gooseneck allows for easy adjustment of light angle and direction, ensuring optimal light distribution to all parts of your plants.
- **6/12/16-Hour Timer:** Equipped with an automatic timer to set consistent lighting durations, supporting optimal growth cycles.
- **Height Adjustable:** The design allows for height adjustment from 10 inches to 65 inches, accommodating plants of various sizes.

Setup Instructions

Follow these steps to set up your Wolezek Grow Light:

1. **Assemble the Gooseneck:** Insert the gooseneck into the lamp pole. Ensure it is securely connected.

2. **Insert into Pot:** Gently insert the assembled pole into the soil of your plant pot. Ensure stability.
3. **Adjust Height and Angle:** Adjust the height of the lamp pole and bend the gooseneck to position the light directly over your plant, ensuring even coverage.
4. **Connect Power:** Plug the power adapter into a standard electrical outlet.




Figure 1: Step-by-step guide for assembling and positioning the grow light.

Operating Instructions

The Wolezek Grow Light features an inline controller for easy operation:

- **Power On/Off:** Press the power button (**U**) to turn the light on or off.
- **Brightness Adjustment:** Use the brightness buttons (**+/-**) to cycle through 5 dimmable brightness levels (20%, 40%, 60%, 80%, 100%).
- **Color Mode Selection:** Press the color mode button (**C**) to switch between 3 light spectrums: 6500K Natural White, 3000K Warm White & Red, and 5000K All Light On.
- **Timer Setting:** Press the timer button (**T**) to set the automatic shut-off timer for 6, 12, or 16 hours. The light will automatically turn on at the same time the next day.



Figure 2: Inline controller for managing light settings.



Figure 3: Visual representation of the three available color modes.



Figure 4: Illustration of the five dimmable brightness levels.

Maintenance

To ensure the longevity and optimal performance of your Wolezek Grow Light, follow these maintenance guidelines:

- **Cleaning:** Periodically wipe the LED light panel and gooseneck with a soft, dry cloth to remove dust and debris. Do not use abrasive cleaners or immerse the unit in water.
- **Inspection:** Regularly check the power cord and connections for any signs of damage. If any damage is found, discontinue use and contact customer support.
- **Placement:** Ensure the light is positioned to avoid direct water contact during plant watering.

Troubleshooting

If you encounter any issues with your grow light, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	Power cord not properly connected; power outlet malfunction.	Check power connections; try a different outlet.
Light flickers or is dim.	Low brightness setting; power supply issue.	Increase brightness using the controller; ensure stable power supply.
Timer function not working.	Timer not set correctly.	Re-set the timer according to operating instructions.

Specifications

Feature	Detail
Model Number	BL-B20B
Light Source Type	LED
Number of Light Sources	80
Color Modes	3 (6500K, 3000K, 5000K)
Brightness Levels	5
Timer Settings	6H, 12H, 16H
Height Adjustment	10 inches - 65 inches
Gooseneck	360° Adjustable
Power Source	Corded Electric
Material Type	Aluminum
Indoor/Outdoor Usage	Indoor

Warranty and Support

Wolezek provides a comprehensive 12-month manufacturer's warranty for this product. Additionally, lifetime customer support is available for any assistance you may require. For warranty claims or technical support, please refer to the contact information provided with your purchase or visit the official Wolezek website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question