

[Manuals.plus](#) /

› [KKENZA](#) /

› KKENZA XIWBSY Android 4K Projector User Manual

KKENZA XIWBSY T07

KKENZA XIWBSY Android 4K Projector User Manual

Model: XIWBSY T07

INTRODUCTION

Welcome to the user manual for your KKENZA XIWBSY Android 4K Projector. This guide provides essential information for setting up, operating, and maintaining your projector to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of electric shock, fire, or damage to the device, please follow these safety guidelines:

- Ensure proper ventilation around the projector. Do not block any ventilation openings.
- Use only the power adapter supplied with the projector.
- Do not expose the projector to rain, moisture, or extreme temperatures.
- Avoid looking directly into the projector lens when the lamp is on.
- Keep the projector away from children and pets.
- Unplug the projector during lightning storms or when unused for long periods.

PACKAGE CONTENTS

Your KKENZA XIWBSY Projector package should contain the following items:

- KKENZA XIWBSY Projector

- Remote Control
- Power Cable
- User Manual



Image: KKENZA XIWBSY Projector with its main features highlighted, including Android TV, 25000 Lumens, 8K Support, and 6G WiFi.

PRODUCT OVERVIEW

The KKENZA XIWBSY Projector is designed to deliver a high-quality home cinema experience with advanced features:

- **WiFi-6 and Bluetooth 5.1 Connectivity:** Stay connected with ultra-fast WiFi-6 and Bluetooth 5.1 for seamless streaming and audio synchronization.
- **Automatic Focus and Keystone Correction:** Enjoy easy setup with automatic focus and keystone correction for a perfectly square image, anywhere in the room.
- **4K/8K Compatibility with 1920x1080P Native Resolution:** Experience future-ready visuals with 4K/8K support and a sharp 1920x1080P native resolution for stunning detail.
- **25000 Lumens Brightness (800 ANSI Lumens):** Illuminate your home theater with 25000 lumens, ensuring vivid images even in daylight conditions with 800 ANSI lumens.

- **Integrated Android 9.0 System with Google Play Store:** Stream seamlessly with Android 9.0 and access thousands of applications through the integrated Google Play Store.



Image: The projector in use, displaying a clear film outdoors during the day, highlighting its brightness.



Image: The projector displaying the Android TV interface, showing integrated apps like Netflix, Prime Video, YouTube, and Disney+.

Autofocus

Focus more easily and precisely



Image: A visual representation of the projector's autofocus feature, showing how it precisely adjusts the image clarity.

Keystone Correction And 50% Zoom

Get a Rectangle of a suitable size




Image: The projector demonstrating keystone correction (auto-vertical, 4P) and 50% zoom, allowing for a perfectly rectangular image of suitable size.

SETUP

Placement

Position the projector on a stable, flat surface or mount it using a compatible stand. Ensure adequate ventilation around the device to prevent overheating. The projector features an adjustable screw on the bottom to fine-tune the tilt angle.

Your browser does not support the video tag.

Video: This video demonstrates how to adjust the tilt of the projector using the adjustable screw on the bottom, allowing you to raise the front part for a better projection angle.

Power Connection

Connect the power cable to the projector's power input port, then plug the other end into a standard electrical outlet.

First Power On & Automatic Adjustments

Press the power button on the projector or remote control to turn on the device. The projector will automatically perform focus and keystone correction to ensure a clear and rectangular image on your screen or wall.

Network Connection

Navigate to the projector's settings menu to connect to your Wi-Fi network. This is essential for accessing online streaming services and using screen mirroring features.

OPERATING INSTRUCTIONS

Android 9.0 Interface

The projector runs on the Android 9.0 operating system, providing a user-friendly interface. You can navigate through apps, settings, and content using the provided remote control. Access the Google Play Store to download and install your favorite streaming applications like Netflix, YouTube, Disney+, and more.

Screen Mirroring

To mirror content from your smartphone or tablet (iOS or Android) to the projector, ensure both devices are connected to the same Wi-Fi network. Select the 'ScreenShare' or 'Screencast' option from the projector's main menu and follow the on-screen instructions to connect your device.

Bluetooth Speaker Mode

The projector can be used as a standalone Bluetooth speaker. Activate 'Bluetooth Speaker Mode' in the projector's settings. Then, enable Bluetooth on your mobile device, search for 'Bedroom TV/G1' (or similar name displayed on the projector), and pair to connect. You can then play music from your phone through the projector's speakers.

Your browser does not support the video tag.

Video: This video demonstrates how to connect your mobile device via Bluetooth to use the projector as an external speaker, allowing you to play music directly from your phone.

Adjusting Image Settings

Access the projector's settings menu to fine-tune image parameters such as brightness, contrast, and color temperature. These adjustments can optimize the viewing experience based on ambient light conditions and personal preferences.

MAINTENANCE

Cleaning the Dust Filter

Regularly clean the projector's dust filter to maintain optimal performance and prevent overheating. The filter is located on the bottom of the projector, under a removable label. Carefully remove the label, open the dust cover, and clean the internal screen with a dry cotton swab or one moistened with an alcohol solution until all dust is removed. Close the dust cover and reapply the label.

Your browser does not support the video tag.

Video: This video demonstrates the process of cleaning the projector's internal screen by removing the bottom label, opening the dust cover, and using a cotton swab.

General Cleaning

Use a soft, dry cloth to clean the exterior of the projector. For the lens, use a specialized lens cleaning cloth

and solution. Avoid abrasive cleaners, solvents, or excessive moisture, as these can damage the device.

TROUBLESHOOTING

- **No Image:** Check all power connections and ensure the correct input source (HDMI, USB, etc.) is selected.
- **Blurry Image:** Use the automatic focus feature or manually adjust the focus via the settings menu until the image is clear.
- **Distorted Image (Trapezoid Shape):** Apply automatic keystone correction or manually adjust it in the settings to achieve a perfectly rectangular image.
- **No Sound:** Verify the volume levels on both the projector and the source device. Check the audio output settings and ensure any external speakers are properly connected and functioning.
- **Connectivity Issues (Wi-Fi/Bluetooth):** Ensure both the projector and your connected device are on the same Wi-Fi network for screen mirroring. For Bluetooth, confirm that Bluetooth is enabled on both devices and they are correctly paired.

SPECIFICATIONS

Feature	Specification
Brand	KKENZA
Model	XIWBSY T07
Brightness	25000 Lumens (800 ANSI Lumens)
Native Resolution	1920 x 1080P
Maximum Resolution	3840 x 2160 (4K Compatible)
Contrast Ratio	20000:1
Connectivity	WiFi-6, Bluetooth 5.1, HDMI, USB
Operating System	Android 9.0
Special Features	Auto Focus, Keystone Correction, Integrated Google Play Store
Dimensions	1 x 1 x 1 cm (Note: These dimensions appear unusually small for a projector and may be placeholder data.)
Weight	50 g (Note: This weight appears unusually low for a projector and may be placeholder data.)

WARRANTY AND SUPPORT

Your KKENZA XIWBSY T07 Projector comes with a 1-year warranty covering replacement and free maintenance. If you encounter any issues or have questions about your projector, please refer to the contact

information provided in your product packaging or user manual to reach customer service.