

[Manuals.plus](#) /

> [GRACEALL](#) /

> GRACEALL Electric Ceramic Hob 4 Burners 60cm, Built-in 6700W, Model EU46T1-1R User Manual

## GRACEALL EU46T1-1R

# GRACEALL Electric Ceramic Hob 4 Burners 60cm, Model EU46T1-1R User Manual

Comprehensive guide for installation, operation, and maintenance

## 1. INTRODUCTION

Thank you for choosing the GRACEALL Electric Ceramic Hob. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new appliance. Please read these instructions carefully before use and retain them for future reference.



*Image: The GRACEALL electric ceramic hob in use, highlighting its integrated design and ease of use.*

## 2. SAFETY INFORMATION

Your safety and the safety of others are paramount. Please observe all safety warnings and precautions outlined in this manual.

## General Safety Precautions:

- Ensure the appliance is installed by a qualified technician in accordance with local regulations.
- Do not operate the hob if the ceramic glass surface is cracked or broken. Disconnect from power immediately.
- Avoid placing metallic objects such as knives, forks, spoons, and lids on the hob surface as they can become hot.
- Do not use abrasive cleaners or sharp metal scrapers to clean the hob, as they can scratch the surface.
- Always supervise cooking, especially when using high heat settings or cooking with oil/fat.
- Keep children away from the appliance during operation and while it is cooling down.

## Integrated Safety Features:

- **Child Lock:** Prevents accidental operation by children.
- **Residual Heat Indicator:** 'H' will appear on the display to warn that the cooking zone is still hot after use.
- **Overheating Protection:** The hob will automatically shut down if a cooking zone becomes excessively hot.
- **Automatic Safety Shut-off:** If a cooking zone is left on for an extended period without adjustment, it will automatically turn off. The duration depends on the power level (see Specifications section).
- **Cooling Fan:** An integrated cooling fan helps maintain optimal operating temperatures and enhances safety.



Image: Overview of key features and safety functions.

## 3. PRODUCT OVERVIEW

The GRACEALL Electric Ceramic Hob features a sleek, built-in design with four high-efficiency heating zones, offering a total power output of 6700W. Its smooth ceramic glass surface is both durable and easy to clean.

### Key Features:

- **4 High-Efficiency Heating Zones:** Provides uniform heat distribution for various cooking needs.
- **9 Power Levels:** Offers precise temperature control from gentle simmering to rapid boiling.
- **Programmable Timer:** Set cooking times from 1 to 99 minutes for each zone.
- **Pause Function:** Temporarily stops cooking and resumes with the same settings.
- **Keep Warm Function:** Maintains food at an ideal serving temperature.

- **Expandable Double Ring Zone:** One zone can be expanded to accommodate larger cookware.
- **Universal Cookware Compatibility:** Works with all flat-bottomed pots and pans made of stainless steel, ceramic, aluminum, glass, or enamel.

## Pannello di controllo tattile più intelligente



*Image: Detailed view of the smart touch control panel.*

## Compatibile con tutte le pentole a fondo piatto (10-25 cm)



Image: Power distribution across the four cooking zones and cookware compatibility.

### 4. SETUP & INSTALLATION

Installation must be performed by a qualified electrician or technician. Ensure the power supply is disconnected before beginning installation.

#### Unpacking:

Carefully remove the hob from its packaging. Check for any damage. Retain packaging for transport if needed.

#### Required Cutout Dimensions:

The hob is designed for built-in installation. Ensure your countertop has a cutout of 56 cm x 49 cm (Width x Depth).

#### Electrical Connection:

- The appliance requires a fixed electrical connection to a 230V power supply.

- The total power consumption is 6700W.
- Refer to the wiring diagram provided with the product and on the appliance itself.
- Connect the N (Blue/Grey), L (Brown/Black), and Green/Yellow (Ground) wires correctly.

### Mounting:

- Apply the foam sealing strip around the edge of the hob to prevent liquid ingress.
- Place the hob into the countertop cutout.
- Secure the hob from underneath using the provided mounting clips and plastic feet.

## Design integrato - Senza presa

### 6700W/220-240V



Image: Installation dimensions and electrical wiring diagram.

## 5. OPERATING INSTRUCTIONS

Familiarize yourself with the control panel before operating the hob.

## Power On/Off:

Press and hold the On/Off button to turn the hob on or off.

## Selecting a Cooking Zone:

After powering on, select the desired cooking zone by touching its corresponding zone selection control.

## Adjusting Power Levels:

Once a zone is selected, use the '+' and '-' touch controls to adjust the power level from 1 (lowest) to 9 (highest).

**Superficie In Microcristallo  
Resistente - Progettata Per Durare  
Resistente Ai Graffi Per L'Uso Quotidiano**



*Image: Illustrating the 9 power levels and compatible cookware.*

## Using the Timer:

- Select a cooking zone.
- Press the Timer control.

- Use '+' and '-' to set the desired cooking time (1-99 minutes). The zone will automatically turn off when the timer expires.

### Pause Function:

Press the Pause button to temporarily stop all active cooking zones. Press it again to resume cooking with the previous settings.

### Keep Warm Function:

Select a cooking zone and activate the Keep Warm function to maintain food at a low, serving temperature.

## 9 livelli di temperatura - da bollire a sigillare



*Image: The Keep Warm function in use.*

### Expandable Double Ring Zone:

One of the cooking zones features an expandable double ring. To activate the larger ring, select the zone and press the double zone control button. This allows for more efficient heating of larger pots and pans.

# Design anello doppio espandibile

Zone di riscaldamento flessibili per una cottura più efficiente

Anello doppio  
(1100-2300W)



Espansione  
(1100W-2000W)



*Image: Operation of the expandable double ring zone.*

## Child Lock:

To activate the child lock, press and hold the lock button. The controls will be disabled. To deactivate, press and hold the lock button again.

## 6. MAINTENANCE & CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your ceramic hob.

### Cleaning the Ceramic Glass Surface:

- Allow the hob to cool completely before cleaning.
- Wipe the surface with a damp cloth and a small amount of mild dish soap.
- For stubborn stains, use a specialized ceramic hob cleaner.
- Rinse with a clean, damp cloth and dry thoroughly with a soft cloth to prevent streaks.

- Do not use abrasive sponges, scouring pads, or harsh chemical cleaners, as these can damage the surface.

**Superficie In Microcristallo  
Resistente - Progettata Per Durare**  
Resistente Ai Graffi Per L'Uso Quotidiano



**Ventola Di Raffreddamento  
Integrata Per Un Uso Più Sicuro**

**Pulizia Semplice Con  
Una Sola Passata**

*Image: Cleaning the ceramic glass surface.*

## 7. TROUBLESHOOTING

If you encounter issues with your hob, please refer to the following common troubleshooting steps. For problems not listed here, contact a qualified service technician.

### Common Issues:

- **Hob not turning on:** Check if the appliance is properly connected to the power supply. Ensure the child lock is not activated.
- **Cooking zone not heating:** Verify that the correct zone is selected and the power level is set above '0'. Check for any error codes on the display.
- **'H' displayed after use:** This indicates residual heat. The zone is still hot. This is a normal safety feature.
- **Hob automatically shuts off:** This may be due to the overheating protection or the automatic safety shut-off

feature if a zone was left on for too long without adjustment. Allow the hob to cool down before attempting to use it again.

- **Unusual noises:** A faint humming sound during operation is normal, especially when using higher power settings. The cooling fan may also produce a gentle whirring sound.

## 8. SPECIFICATIONS

Feature	Specification
Model Number	EU46T1-1R
Brand	GRACEALL
Product Dimensions (L x W x H)	52.7 cm x 58.7 cm x 5.8 cm
Weight	8.4 kg
Total Power Output	6700W
Voltage	230V
Number of Heating Zones	4
Power Levels	9
Surface Material	Ceramic Glass
Frame Material	Stainless Steel
Special Features	Child Lock, Keep Warm Function, Pause Function, Timer, Overheating Protection, Automatic Shut-off
Cutout Dimensions (W x D)	56 cm x 49 cm

### Automatic Safety Shut-off Times:

Power Level	Default Operating Timer (Hours)
1	6
2	6
3	6
4	3
5	3
6	3
7	2
8	2
9	1.5

# Funzione mantenere caldo (24 pollici)

Ideale per riunioni e celebrazioni



*Image: Automatic shut-off protection table.*

## 9. WARRANTY & SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or contact the retailer/manufacturer directly. Keep your proof of purchase for any warranty claims.