

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Eseesmart](#) /

› [Eseesmart Smart Key Lock Box YL-B5BF User Manual](#)

Eseesmart YL-B5BF

Eseesmart Smart Key Lock Box YL-B5BF User Manual

Model: YL-B5BF

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Eseesmart Smart Key Lock Box (Model YL-B5BF). This device offers multiple secure access methods, including fingerprint recognition, custom passcodes, and smartphone app control, making it suitable for various applications such as home use, short-term rentals, and commercial properties.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 x Eseesmart Smart Key Lock Box
- 1 x Adjustable Shackle
- 1 x User Manual
- 1 x Screwdriver
- 1 x Type-C Cable (for emergency power)
- 4 x Wall Mounted Screws
- 4 x Screw Anchors
- 2 x Silicone Plugs



Figure 2.1: Package Contents

3. PRODUCT FEATURES

The EseeSmart Smart Key Lock Box is designed with advanced features for security and convenience:

- **Multi-Way Unlocking:** Access via the eSmartLock app, 0.2-second fingerprint recognition, customizable passcodes (permanent, user-defined, or one-time), or Apple Watch integration. Supports up to 100 fingerprints.
- **Durable Construction:** Made from premium zinc alloy with an IP65 waterproof rating, capable of operating in temperatures from -13°F to 149°F.
- **Flexible Installation:** Features a detachable and adjustable stainless steel shackle (1.6"–2.0") with a scratch-proof rubber sleeve for mounting on walls, door handles, or fixtures.
- **Spacious Interior:** Designed to securely hold keys, wallets, passports, jewelry, and other small valuables.
- **Reliable Power:** Operates on 3x AAA batteries (not included) with app and indicator battery alerts. Includes a USB-C port for emergency charging.

4 Ways to Unlock



Figure 3.1: Four Unlocking Methods

Larger Capacity



Figure 3.2: Large Storage Capacity

4. SETUP

4.1 Battery Installation

1. Unscrew the two screws on the back panel of the lock box to open the battery compartment.
2. Insert 3x AAA batteries (not included), ensuring correct polarity. Rechargeable batteries are recommended.
3. Close the battery compartment and secure it with the screws.

4.2 App Download and Pairing

1. Download the "eSmartLock" app from your device's app store (available for Android and iOS).
2. Enable Bluetooth on your smartphone.
3. Open the eSmartLock app and follow the on-screen instructions to add your Smart Key Lock Box. The lock box will typically blink blue when ready for pairing.
4. Allow location permissions if prompted by the app.

4.3 Setting Unlock Methods

Once paired with the app, you can configure various unlock methods:

- **Fingerprint:** In the app, navigate to Fingerprint Management to add and register up to 100 unique fingerprints.
- **Passcode:** Set permanent, time-limited guest, or one-time passcodes through the app's Passcode Management section.
- **Apple Watch:** Integrate with your Apple Watch for convenient unlocking.

The advertisement features a black eSmartLock device with a numeric keypad and a fingerprint sensor. A hand is shown touching the sensor, with a series of blue fingerprint icons illustrating the scanning process. The text highlights the device's capabilities: 'Latest Update of AI Fingerprint Sensor', '100 Fingerprints', 'Faster 0.2s Unlock', 'Smarter Self-learning AI', and 'More Secure AES - 256 Encrypted Chip'. A small fingerprint icon is also visible in the top right corner.

Latest Update of AI Fingerprint Sensor

100 Fingerprints

Faster
0.2s Unlock

Smarter
Self-learning AI

More Secure
AES - 256 Encrypted Chip

Figure 4.1: Fingerprint Sensor Technology

Multi-function Password



- Permanent (20 passwords)
- Guest Password (Scheduled entry time)
- One-time Password (Unlimited times)




Figure 4.2: Multi-function Passcode Setup

5. OPERATING INSTRUCTIONS

5.1 Unlocking the Device

- **Fingerprint:** Place your registered finger on the fingerprint sensor. The lock will unlock if the fingerprint is recognized.
- **Passcode:** Enter your programmed passcode on the touchscreen keypad.
- **App Control:** Open the eSmartLock app on your smartphone, ensure Bluetooth is connected, and tap the unlock icon.

5.2 Access Management via App

The eSmartLock app allows for comprehensive access management:

- **User Management:** Add or remove authorized users who can access the lock box.
- **Temporary Passwords:** Generate and share temporary or one-time passcodes for guests or service providers.
- **Unlock Records:** View a history of all unlock events, including method and time.



Figure 5.1: App Interface for User and Temporary Password Management



Figure 5.2: App Interface for Sharing Permissions and Viewing Records

5.3 Mounting Options

The lock box offers two primary mounting methods:

- **Door Hanging:** Use the adjustable shackle to hang the lock box on a door handle or similar fixture.
- **Wall Mount:** Utilize the provided screws and anchors to securely mount the lock box to a wall.

2 Mounting types



suitable for all scenarios.



Figure 5.3: Versatile Mounting Options

6. MAINTENANCE

6.1 Battery Management

The lock box is powered by 3x AAA batteries. To ensure continuous operation:

- Monitor battery levels via the eSmartLock app or the indicator lights on the device.
- When batteries are low, use the provided USB-C cable for emergency charging to avoid lockouts.
- Replace batteries promptly when alerts indicate low power.

365 Day Longer Standby

Low Power Consumption




3 AAA - batteries (not included)

No Battery Anxiety



AAA
AAA
AAA



Unlock

the smart lock is low, please replace the battery



Low Battery Alarm Type-C Emergency Charging Battery Level Check on APP

Figure 6.1: Battery Features and Management

6.2 General Care

To maintain the longevity and functionality of your lock box:

- Regularly clean the touchscreen keypad and fingerprint sensor with a soft, dry cloth.
- Avoid exposing the device to extreme physical impact or corrosive substances.
- Ensure the waterproof rubber plug for the USB-C port is properly sealed when not in use.

7. TROUBLESHOOTING

Issue	Possible Cause	Solution
Cannot unlock with fingerprint.	Fingerprint not registered or sensor is dirty.	Ensure your fingerprint is properly registered in the app. Clean the fingerprint sensor. Try re-registering your fingerprint.

Issue	Possible Cause	Solution
Cannot unlock with passcode.	Incorrect passcode entered or keypad unresponsive.	Verify the passcode in the app. Ensure the keypad is active (touch to wake). Check battery level.
App cannot connect to the lock box.	Bluetooth is off, lock box is out of range, or low battery.	Ensure Bluetooth is enabled on your phone. Move closer to the lock box. Check battery level and charge if necessary. Restart the app.
Remote code change not working.	The device uses Bluetooth, not Wi-Fi, for app control.	Remote code changes require your phone to be within Bluetooth range of the lock box. You must be physically near the unit to update codes via the app.
Lock box is unresponsive.	Dead batteries.	Use the USB-C cable for emergency power to temporarily activate the lock and replace the batteries.

8. SPECIFICATIONS

Feature	Detail
Model Name	YL-B5BF
Brand	Eseesmart
Lock Type	Biometric, Digital keypad, Smart lock box
Unlocking Methods	Fingerprint, Passcode, App, Apple Watch
Fingerprint Capacity	Up to 100 fingerprints
Connectivity	Bluetooth
Controller Type	Android, iOS
Material	Premium Zinc Alloy Body, Stainless Steel Shackle with Rubber Protection
Dimensions (L x W x H)	3 x 2 x 5.5 inches
Item Weight	1.7 Pounds
Waterproof Rating	IP65
Operating Temperature	-13°F to 149°F (-25°C to 65°C)
Power Source	3x AAA batteries (not included)
Emergency Power	USB-C Port

9. WARRANTY AND SUPPORT

Eseesmart is committed to providing quality products and customer satisfaction. Your Smart Key Lock Box comes with the following:

- **12-Month Free Replacement:** For any manufacturing defects or malfunctions within 12 months of purchase.
- **Lifetime Service:** Ongoing support for the lifespan of your product.
- **24-Hour Response Guarantee:** Our customer support team is available to assist you promptly with any inquiries or issues.



Worried About Durability?

EseeSmart Provide:

- 12 Month Free Replacement
- Full Reimbursement within 6 Months
- Lifelong Support, Available 24/7!

Figure 9.1: Customer Support Information

10. PRODUCT OVERVIEW VIDEO

Video 10.1: EseeSmart Newly Upgraded Smart Key Lock Box. This video provides a brief overview of the key features and functionality of the EseeSmart Smart Key Lock Box.