Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Alupssuc AL-6.5ft Half Multi Prelit Tree

Alupssuc 6.5ft Half Prelit Artificial Hinged Christmas Tree

Model: AL-6.5ft Half Multi Prelit Tree

Brand: Alupssuc

Introduction

This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your Alupssuc 6.5ft Half Prelit Artificial Hinged Christmas Tree. Please read these instructions thoroughly before setup and retain them for future reference.



Image: The Alupssuc 6.5ft Half Prelit Artificial Hinged Christmas Tree, displayed in both its full and space-saving half configurations, accompanied by its remote control.

Package Contents

Verify that all components are present before beginning assembly:

- Christmas Tree (3 hinged sections: A, B, C)
- Foldable Metal Base
- Remote Control (requires 2 AAA batteries, not included)
- User's Manual (this document)

Setup Instructions

1. **Assemble the Tree Stand:** Unfold the metal base and insert the provided screw to secure it. Ensure the stand is

stable on a flat, level surface.

2. **Insert the Bottom Section (A):** Carefully insert the bottom section of the tree (marked 'A') into the assembled metal stand.
3. **Insert Middle Section (B):** Place the middle section (marked 'B') onto section 'A'. The hinged branches will fall into place.
4. **Insert Top Section (C):** Place the top section (marked 'C') onto section 'B'.
5. **Connect the Lights:** Locate the light connectors between each section and securely connect them. Ensure all connections are tight to prevent light outages.
6. **Connect to Power:** Plug the tree's power cord into a standard electrical outlet.
7. **Shape the Branches:** Gently spread out the hinged branches, working from the bottom to the top, to achieve a full and natural appearance. Adjust individual branch tips to fill any gaps.



Image: A close-up view of the convenient hinged branch structure, illustrating how branches effortlessly fall into place during assembly.



Image: A sturdy metal tree stand providing stable support for the Christmas tree on a wooden floor.

Operating Instructions

Your Alupssuc Christmas tree features pre-installed LED lights with multiple settings controlled by the included remote.

Remote Control Functions:

Remote control Instructions




Image: A detailed diagram of the remote control, highlighting buttons for light brightness, mode selection, timing functions, and power.

- **ON/OFF:** Press to turn the lights on or off.
- **MODE:** Cycle through 12 different lighting modes.
- **BRIGHTNESS (+/-):** Adjust the light brightness (5 levels).
- **SPEED (+/-):** Adjust the speed of dynamic light modes (5 levels).
- **TIMER:** Select from 23 timer choices for automatic operation.

Lighting Modes:

The tree offers 12 distinct lighting modes, including:

- Automatic
- Warm White Steady-on
- Multi-color Steady-on
- Warm White Twinkle/Flash
- Multi-color Twinkle/Flash
- Warm White/Multi-color Switching

- Warm White Breathing
- Multi-color Breathing
- Warm White/Multi-color Flash Switching
- All Colors Breathing/Flash Switching
- All Colors Slow Fade



Image: A visual comparison of the tree's lighting options, showing lights off, warm white illumination, and vibrant multi-color lights.

Maintenance

Cleaning:

To clean the tree, gently wipe the branches and lights with a soft, dry cloth. Do not use liquid cleaners or immerse any part of the tree in water.

Storage:

When storing, ensure the tree is completely dry. Disassemble the tree by reversing the setup steps. Store the sections

and stand in their original packaging or a suitable storage container in a cool, dry place away from direct sunlight and extreme temperatures. This will help maintain the quality of the PVC material and pre-lit lights.



Image: A close-up of the tree's branches, emphasizing the premium, flame-retardant, and smell-free PVC material.

Troubleshooting

- **Lights Not Working:**
  - Ensure all sections are correctly connected and the power cord is securely plugged into a working outlet.
  - Check the remote control batteries (2 AAA, not included) and replace if necessary.
  - Verify that the light connectors between tree sections are fully engaged.
- **Tree Appears Sparse:**
  - After assembly, it is crucial to properly "fluff" the branches. Gently spread out each individual branch and tip, working from the inside out and bottom to top, to achieve a full and lush appearance.
- **Remote Control Not Responding:**
  - Ensure the remote has fresh batteries and is pointed directly at the tree's receiver.
  - Remove any obstructions between the remote and the tree.

Specifications

Feature	Detail
Brand	Alupssuc
Model Number	AL-6.5ft Half Multi Prelit Tree
Product Dimensions	37.4"D x 7.9"W x 78"H
Color	Green
Material	Polyvinyl Chloride (PVC)
Item Weight	13.64 pounds
Tree Type	Fir

Base Type	Stand
Built-in Light	Yes
Light Color	Warm White & Multi-Color
Tip Count	453
Included Components	Pre-lit Design, Remote Control, Foldable Metal Base



Image: A comparative table outlining specifications for various tree sizes, detailing material, number of branch tips, LED lights, and included package items.

Warranty and Support

Warranty information for this product is not provided in the current documentation. For any support inquiries, please refer to the retailer or manufacturer's customer service contact information available at the point of purchase.

© 2025 Alupssuc. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F4X43HV1

More documents and user manuals: **https://manuals.plus/**