

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ULANZI](#) /

› [ULANZI PK-11 Charging Adapter Base for DJI Osmo Pocket 3 Instruction Manual](#)

## ULANZI PK-11

# ULANZI PK-11 Charging Adapter Base for DJI Osmo Pocket 3 Instruction Manual

Model: PK-11

[Instructions](#) [Overview](#) [Setup](#) [Operating](#)  
[Maintenance](#) [Troubleshooting](#) [Specifications](#) [Product Videos](#) [Warranty & Support](#)

## PRODUCT OVERVIEW

The Ulanzi PK-11 Charging Adapter Base is designed for the DJI Osmo Pocket 3, providing enhanced functionality and stability. This compact accessory features a full-function Type-C data port, allowing for simultaneous charging, data transfer, and webcam use. It also includes a 1/4" screw thread and an Arri locating hole for broad compatibility with various camera accessories.



Image: Ulanzi PK-11 Charging Adapter Base attached to DJI Osmo Pocket 3, showcasing its compact design and integration.

## Key Features:

- Full-Function Type-C Port:** Supports charging during use, data transfer, and webcam functionality.
- Versatile Mounting Options:** Equipped with a 1/4" thread and Arri locating hole for compatibility with tripods, magic arms, gimbals, ball heads, super clamps, and selfie sticks.
- Compact and Portable:** Lightweight aluminum alloy construction for easy transport.
- Durable Design:** Made of sturdy aluminum alloy with a silicone pad for anti-rub and anti-scratch protection.

## SETUP GUIDE

### What's in the Box:

- ULANZI PK-11 Pocket 3 Base x 1
- Packaging Box x 1

## Attaching the PK-11 Base to DJI Osmo Pocket 3:

1. Ensure your DJI Osmo Pocket 3 is powered off.
2. Align the Type-C connector of the PK-11 base with the charging port at the bottom of the Osmo Pocket 3.
3. Gently push the PK-11 base onto the Osmo Pocket 3 until it clicks securely into place. The side clips should engage firmly.
4. Verify that the base is securely attached and does not wobble.



**\*Ulanzi PK-08 is sold separately.**

Image: The ULANZI PK-11 base securely attached to the DJI Osmo Pocket 3, ready for use.

## Using with External Accessories:

The PK-11 base features a 1/4" screw thread and an Arri locating hole on its underside for attaching to various camera accessories.

1. For accessories with a 1/4" screw, simply screw the accessory into the thread on the PK-11 base.
2. For accessories compatible with an Arri locating pin, align the pin with the Arri locating hole on the base and secure the accessory.

Ulanzi PK-11

## Pocket 3 Arri Locating Base



Compatible with magic arm, gimbal,etc



Image: Close-up of the Ulanzi PK-11 base, highlighting the 1/4" thread and Arri locating hole for accessory attachment.

### OPERATING INSTRUCTIONS

#### Charging the Osmo Pocket 3:

With the PK-11 base attached, you can charge your DJI Osmo Pocket 3 directly through the Type-C port on the base.

1. Connect a Type-C charging cable to the port on the PK-11 base.
2. Connect the other end of the charging cable to a power source.
3. The Osmo Pocket 3 will begin charging. The indicator light on the Osmo Pocket 3 will show charging status.

# Full-Function Interface

Experience ultimate performance and seamless transmission with the full-function data port, supporting charging while in use.



Image: DJI Osmo Pocket 3 connected to a charging cable via the ULANZI PK-11 base, illustrating the charging function.

## Data Transfer and Webcam Functionality:

The full-function Type-C port on the PK-11 base also supports data transfer and webcam mode when connected to a computer.

1. Connect the PK-11 base to your computer using a compatible Type-C data cable.
2. Your Osmo Pocket 3 should be recognized by your computer for data transfer or as a webcam, depending on the mode selected on the device.

## Full-Function Interface

Experience ultimate performance and seamless transmission with the full-function data port, supporting charging while in use.



### Type-C Full-function Data Port

- Data Transfer
- Webcam
- Fast Charging




Image: The ULANZI PK-11 base connected to a laptop, demonstrating its data transfer and webcam capabilities for the DJI Osmo Pocket 3.

## Enhanced Stability:

The design of the PK-11 base provides a stable platform for your Osmo Pocket 3, whether used standalone or with a mini tripod (like the ULANZI PK-08, sold separately).

## Quick Switch between Tripod & Grip Mode

Unfolded as a tripod and fold back as a hand grip, effortlessly switch modes for every shot.



Image: The DJI Osmo Pocket 3 with the ULANZI PK-11 base, illustrating its use in both tripod and handheld grip modes for stable shooting.

## MAINTENANCE

- Cleaning:** Use a soft, dry cloth to wipe the surface of the PK-11 base. Avoid using harsh chemicals or abrasive materials.
- Storage:** Store the PK-11 base in a cool, dry place away from direct sunlight and extreme temperatures.
- Handling:** While durable, avoid dropping the base or subjecting it to strong impacts to prevent damage to the aluminum alloy and internal components.
- Silicone Pad:** The silicone pad provides anti-rub and anti-scratch protection. Ensure it remains clean and free of debris for optimal performance.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
PK-11 base does not attach securely.	Incorrect alignment or obstruction.	Ensure the Type-C connector is correctly aligned and there is no debris in the port or on the base. Apply gentle, even pressure until it clicks.
Osmo Pocket 3 not charging via PK-11.	Faulty cable, power source, or improper connection.	Try a different Type-C cable and power adapter. Ensure the cable is fully inserted into the PK-11 port. Verify the power source is active.
Data transfer or webcam mode not working.	Incorrect cable, driver issue, or Osmo Pocket 3 settings.	Use a data-capable Type-C cable. Check your computer's device manager for driver issues. Ensure the correct mode is selected on your Osmo Pocket 3.
Accessory (e.g., tripod) not stable on PK-11.	Loose connection or incompatible accessory.	Ensure the accessory is tightly screwed into the 1/4" thread or securely attached via the Arri locating hole. Check compatibility of the accessory.

## SPECIFICATIONS

Feature	Detail
Brand	ULANZI
Model Number	PK-11
Product Dimensions	1.11"D x 1.38"W x 0.73"H (28.2mm x 35.2mm x 18.5mm)
Item Weight	0.988 ounces (28 Grams)
Material	Aluminum Alloy + Iron + PCB + Silicone
Compatible Devices	DJI Osmo Pocket 3
Interface	Type-C Full-Function Data Port (Charging, Data Transfer, Webcam)
Mounting Points	1/4" Thread, Arri Locating Hole

\*Manually measured weight and size may not be accurate.

## PRODUCT VIDEOS

---

### ULANZI Pocket 3 Accessories Overview

Your browser does not support the video tag.

Video: This video from ULANZI Official US Store provides an overview of various accessories for the DJI Osmo Pocket 3, including the PK-11 base, demonstrating their features and compatibility.

## WARRANTY & SUPPORT

---

ULANZI products are designed for durability and performance. For specific warranty information, please refer to the warranty card included in your product packaging or visit the official ULANZI website.

### Customer Support:

If you encounter any issues or have questions regarding your ULANZI PK-11 Charging Adapter Base, please contact ULANZI customer support through their official channels. You can typically find contact information on the product packaging or the ULANZI brand store on Amazon.

- **Online Support:** Visit the [ULANZI Store on Amazon](#) for FAQs and support resources.
- **Email/Phone:** Refer to your product documentation for direct contact methods.

Please have your product model number (PK-11) and purchase details ready when contacting support.