

[manuals.plus](#) /› [Dexnor](#) /› [Dexnor Magnetic Floating Slim Case for iPad Pro 13 Inch M4 \(2024\) - User Manual](#)

Dexnor iPad Pro 13 Inch M4 (2024) Case

Dexnor Magnetic Floating Slim Case for iPad Pro 13 Inch M4 (2024) - User Manual

This manual provides detailed instructions for the setup, operation, and maintenance of your Dexnor Magnetic Floating Slim Case, designed specifically for the iPad Pro 13 Inch M4 (2024) (Model Number: A2925/A2926).

Brand: Dexnor | **Model:** iPad Pro 13 Inch M4 (2024) Case

1. PRODUCT OVERVIEW

The Dexnor Magnetic Floating Slim Case offers versatile functionality and robust protection for your iPad Pro 13 Inch M4 (2024). It features a detachable design, adjustable viewing angles, and strong magnetic attachment for enhanced usability and stability. The case is constructed from shockproof TPU and PC hybrid materials, providing full-body coverage against drops, bumps, and scratches.



Figure 1.1: Dexnor Magnetic Floating Slim Case showcasing its versatile design and multiple viewing positions.


Compatibility

This case is specifically designed for the **iPad Pro 13 Inch M4 (2024)** (Model Number: A2925/A2926). It is not compatible with other iPad models, including the 12.9-inch iPad Pro (6th/5th/4th/3rd Gen) or the 13-inch iPad Air (M2, 2024/M3, 2025).

ONLY COMPATIBLE WITH 13-inch iPad Pro M4 (2024)



13" iPad
Pro (M4)



12.9" iPad
Pro (6th/5th/
4th/3rd Gen)



13" iPad
Air (M2,2024/
M3,2025)



Model Number
A2925/A2926

Figure 1.2: Compatibility details for the Dexnor case, highlighting specific iPad Pro M4 models.

2. SETUP AND INSTALLATION

Follow these steps to properly install your iPad Pro into the Dexnor Magnetic Floating Slim Case.

- Attaching the Inner Case:** Gently align your iPad Pro 13 Inch M4 with the protective inner case. Ensure all ports, buttons, and camera cutouts are correctly aligned. Press firmly around the edges until the iPad is securely seated within the inner case.
- Attaching the Magnetic Cover:** The inner case features strong built-in magnets. Align the inner case (with your iPad installed) with the magnetic cover. The magnets will automatically snap the iPad into place, ensuring a secure attachment.
- Detaching the Magnetic Cover:** To detach the iPad from the magnetic cover, simply pull the inner case away from

the cover. The strong magnets allow for easy removal when you wish to use the iPad without the full cover, or for fridge mounting.



Figure 2.1: Demonstration of the detachable magnetic cover and its secure fridge mounting capability.

3. OPERATING INSTRUCTIONS

The Dexnor case offers multiple modes and features to enhance your iPad experience.

Multiple Viewing Angles

The case provides flexible folding modes and adjustable angles from 105° to 160°, allowing you to position your iPad Pro at the optimal angle for various activities. The sturdy stainless steel hinge ensures quick and easy angle adjustments.

- **Typing Mode:** A lower angle ideal for comfortable typing on the on-screen keyboard.

- **Viewing Mode:** A more upright angle perfect for watching videos or presentations.
- **Drawing Mode:** A shallow, comfortable angle for sketching or writing with a stylus.
- **Video Calling Mode:** An elevated angle for clear video calls.
- **Gaming Mode:** A flat or slightly angled position for immersive gaming.
- **Browsing Mode:** A versatile angle suitable for general web browsing and reading.

ANY MODE YOU WANT



Figure 3.1: Different usage modes supported by the Dexnor case.

DURABLE AND ADJUSTABLE

Stainless steel hinge makes angle adjustments quick and easy.

10000 Folds



Figure 3.2: The durable stainless steel hinge allows for precise angle adjustments.

Ergonomic Floating Design

The Magic-style floating design lifts your iPad Pro M4 to an ergonomic viewing height, which helps reduce neck strain during extended use, especially when watching videos or engaging in video calls.

ERGONOMIC FLOATING DESIGN

Raises your iPad to a more comfortable viewing height.



Figure 3.3: The ergonomic floating design provides a raised viewing height.

Secure Magnetic Clasp and Stylus Holder

The case features a magnetic clasp that secures your iPad and Apple Pencil (not included) in place, preventing accidental drops and ensuring your stylus is always charged and ready. The dedicated stylus holder keeps your Apple Pencil securely stored and easily accessible.

SECURE MAGNETIC CLASP

Keeps your Apple Pencil securely stored and charged.



Figure 3.4: The magnetic clasp secures the Apple Pencil.

Auto Sleep and Wake Functionality

The premium PU leather front flap automatically wakes up your iPad Pro when opened and puts it to sleep when closed, conserving battery life and providing convenience.

Product Demonstration Video

Watch this official product video for a visual guide on the features and functionality of the Dexnor Magnetic Floating Slim Case.

Your browser does not support the video tag.

Video 3.1: Official demonstration of the Dexnor for iPad Pro 13 Inch Case M4 (2024), highlighting its features and usage.

4. MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your Dexnor case, follow these maintenance guidelines:

- **Cleaning:** Wipe the exterior of the case with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the PU leather and hybrid materials.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** While the case offers robust protection, avoid intentionally dropping or subjecting it to excessive force.
- **Magnetic Components:** Keep magnetic components clean and free of debris to ensure strong and reliable attachment.

5. TROUBLESHOOTING

If you encounter any issues with your Dexnor case, refer to the following common troubleshooting tips:

- **Issue:** The iPad does not securely attach to the magnetic cover or stand.
Solution: Ensure both the inner case and the magnetic cover are clean and free of any obstructions or debris. Verify that the iPad is correctly seated within the inner case. The magnets are strong, but proper alignment is key.
- **Issue:** The stand collapses or does not hold the desired viewing angle.
Solution: Ensure the case is folded correctly into the desired stand configuration. The triangular base should be stable. If the issue persists, check for any damage to the stainless steel hinge.
- **Issue:** Auto sleep/wake function is not working.
Solution: Ensure the front flap is fully closed and making proper contact with the iPad screen. Check your iPad settings to ensure the "Lock/Unlock" feature (or similar, depending on iPadOS version) is enabled.
- **Issue:** Apple Pencil does not charge or stay attached.
Solution: Ensure the Apple Pencil is correctly positioned on the magnetic charging strip of the iPad. The case's magnetic clasp is designed to secure it, but the Pencil itself needs to be correctly aligned for charging.

If these steps do not resolve your issue, please contact Dexnor customer support for further assistance.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions	0.71 x 9.17 x 11.34 inches
Item Weight	1.38 pounds
Compatible Devices	iPad Pro 13 inch M4 2024 (Model Number: A2925/A2926)
Color	Blue (for this specific model)
Form Factor	Case
Shell Type	Hybrid (TPU and PC)
Special Features	Magnetic Attachment, Multiple Viewing Angles (105°-160°), Auto Sleep/Wake, Foldable, Ergonomic Floating Design, Secure Magnetic Clasp for Apple Pencil
Manufacturer	Dexnor

7. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Dexnor website or contact their customer service directly. Details regarding specific warranty periods and claims procedures are typically provided with your purchase or on the manufacturer's official channels.

Online Support: Visit the [Dexnor Store on Amazon](#) for product information and support resources.

© 2024 Dexnor. All rights reserved. iPad and Apple Pencil are trademarks of Apple Inc., registered in the U.S. and other countries.