Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ehozirta B0F4XHWCB4

ehozirta 60-inch Kids Trampoline Instruction Manual

Model: B0F4XHWCB4

1. Introduction

This manual provides essential information for the safe assembly, operation, and maintenance of your ehozirta 60-inch Kids Trampoline. This multi-functional play equipment includes a safety enclosure, an adjustable gymnastics bar, a basketball hoop, and a swing, designed for children aged 3 to 8 years. Please read all instructions carefully before assembly and use to ensure the safety of all users.



Image 1.1: The ehozirta 60-inch Kids Trampoline with its various accessories.

2. Safety Information

Your safety and the safety of others are paramount. Adhere to the following guidelines:

- **Adult Supervision:** Always ensure children are supervised by an adult while using the trampoline.
- **Age and Weight Limits:** This trampoline is designed for children aged 3-8 years. The maximum weight capacity is 440 pounds (approximately 200 kg). Do not exceed this limit.
- **One User at a Time:** To prevent collisions and injuries, only one child should use the trampoline at any given time.

- **Clear Surroundings:** Ensure the area around the trampoline is clear of obstacles, furniture, or other hazards. Maintain a safe distance from walls and other structures.
- **Safety Enclosure:** The trampoline features a 360-degree surround eco-friendly three-layer thickened safety pad and a thickened, encrypted safety net. Always ensure the safety net is properly secured before use.
- **Stable Structure:** The galvanized steel frame and widened U-shaped bases with enhanced static suction cups are designed for stability. Regularly check all connections to ensure they are tight and secure.
- **No Flips or Stunts:** Avoid performing somersaults or other dangerous stunts that could lead to serious injury.
- **Proper Attire:** Users should wear appropriate clothing, free of loose items that could get caught. Remove shoes before jumping.



Image 2.1: The trampoline in an outdoor setting, demonstrating its stable design and safety enclosure.

3. Package Contents

Verify that all components are present before beginning assembly:

- 1 x Kids Trampoline (Frame, Jumping Mat, Safety Pads, Enclosure Net)
- 1 x Sandbag
- 1 x Swing
- 1 x Basketball Hoop
- 1 Set of Ocean Balls
- 1 x Small Basketball
- 2 x Pull Rings
- Assembly Hardware (bolts, nuts, tools if included)



Image 3.1: A visual representation of the various accessories included with the trampoline.

4. Setup Instructions

Assembly is designed to be straightforward. Follow these steps carefully:

1. **Unpack Components:** Lay out all parts and verify against the package contents list.

2. **Assemble the Base Frame:** Connect the U-shaped base legs to the main trampoline frame using the provided hardware. Ensure all connections are secure.
3. **Attach Jumping Mat:** Carefully attach the jumping mat to the frame using the tension ropes or springs. Ensure even tension around the entire mat.
4. **Install Safety Pads:** Place the thickened safety pads over the frame and tension ropes/springs to cover all hard surfaces. Secure them in place.
5. **Erect Enclosure Poles:** Attach the vertical poles for the safety enclosure to the trampoline frame.
6. **Install Safety Net:** Drape the safety net over the enclosure poles and secure it to the jumping mat and frame as per the specific design. Ensure the entrance zipper or closure is functional.
7. **Attach Gymnastics Bar:** Mount the adjustable gymnastics rod to the top of the enclosure poles. Adjust its height between 59 and 62 inches to suit the child's height.
8. **Install Accessories:** Attach the basketball hoop, swing, and pull rings to the designated points on the frame or gymnastics bar.
9. **Final Check:** Before first use, thoroughly inspect all connections, safety pads, and the net to ensure everything is correctly assembled and secure.



Image 4.1: An overhead view illustrating the assembly of the trampoline's jumping mat and frame.

5. Operating Instructions

Once assembled, the trampoline offers multiple play options:

- **Trampoline Jumping:** Children can safely jump on the mat within the enclosure. Encourage controlled bouncing and discourage rough play.
- **Basketball Hoop:** Use the included small basketball with the hoop for shooting practice.
- **Swing:** The attached swing provides an additional activity. Ensure the child is seated properly and swings gently.
- **Gymnastics Bar & Pull Rings:** The adjustable gymnastics bar can be used with the pull rings for hanging and simple gymnastic exercises, promoting physical fitness and balance.
- **Ocean Balls:** The set of ocean balls can be used for play inside the trampoline enclosure, adding another element of fun.



Image 5.1: A child enjoying the trampoline, demonstrating safe use within the enclosure.

6. Maintenance

Regular maintenance ensures the longevity and safety of your trampoline:

- **Routine Inspection:** Before each use, inspect the trampoline for any signs of wear, damage, or loose parts. Check the jumping mat, safety net, pads, frame, and all accessories.
- **Cleanliness:** Clean the jumping mat and frame regularly with a damp cloth and mild soap. Avoid harsh chemicals.
- **Hardware Check:** Periodically check and tighten all bolts and nuts to ensure structural integrity.
- **Pad and Net Integrity:** Ensure the safety pads are securely in place and free from tears. Check the safety net for holes or damage. Replace any compromised parts immediately.
- **Storage:** While designed for indoor/outdoor use, prolonged exposure to extreme weather conditions can reduce its lifespan. Consider covering or storing indoors during harsh weather.



Image 6.1: Detail of the protective cover and padding, essential for user safety and product longevity.

7. Troubleshooting

Address common issues with the following steps:

- **Trampoline Instability:** If the trampoline feels wobbly, check that all frame connections are securely tightened and that the U-shaped bases are flat on the ground. Ensure suction cups are engaged if applicable.
- **Reduced Bounce:** Inspect the tension ropes or springs for damage or stretching. Ensure the jumping mat is correctly installed and taut.
- **Damaged Safety Net/Pads:** If the safety net or pads are torn or significantly worn, they must be replaced immediately to maintain safety. Do not use the trampoline with damaged safety components.
- **Missing Parts:** If any parts are missing during assembly, refer to the package contents list and contact customer support for assistance.

8. Specifications

Feature	Detail
Brand	ehozirta
Model Name	Kids Trampoline
ASIN	B0F4XHWCB4
Material	Polypropylene (PP)
Frame Material	PP (Galvanized Steel internal structure)
Frame Size	59.1 Inches (Diameter)
Shape	Round
Product Dimensions (L x W x H)	62.9" x 59.1" x 62.9" (160cm x 150cm x 160cm)
Maximum Bearing Capacity	440 lbs (200 kg)
Recommended Age	3-8 Years
Adjustable Gymnastics Bar Height	59 - 62 inches
Color	RED



Image 8.1: A diagram illustrating the key dimensions of the trampoline.

9. Warranty and Support

The product specifications indicate that there is no explicit warranty provided for this item. For any product inquiries, missing parts, or technical assistance, please refer to your purchase documentation or contact the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F4XHWCB4

More documents and user manuals: **https://manuals.plus/**