



[Manuals.plus](#) /

> [Outsunny](#) /

> Outsunny 10' x 13' Patio Gazebo User Manual

Outsunny 84C-580V00DB

Outsunny 10' x 13' Patio Gazebo User Manual

Model: 84C-580V00DB

INTRODUCTION

Thank you for choosing the Outsunny 10' x 13' Patio Gazebo. This manual provides essential information for the safe assembly, operation, and maintenance of your new outdoor structure. Please read these instructions thoroughly before beginning assembly and retain them for future reference.

This gazebo is designed to provide a comfortable and shaded outdoor space, featuring a double-tier roof for ventilation and removable curtains for sun protection and privacy. Its robust metal frame ensures stability for various outdoor settings.

SAFETY INFORMATION

WARNING: Failure to follow these safety instructions could result in serious injury or property damage.

- **Assembly Safety:** Assembly requires a minimum of three people. Do not attempt to assemble alone. Ensure all parts are present and undamaged before starting.
- **Secure Installation:** Always secure the gazebo to the ground using the provided ground stakes for soft surfaces or expansion screws for hard surfaces. Failure to do so may result in the gazebo blowing away in strong winds.
- **Weather Conditions:** This gazebo is designed for fair weather conditions. In case of strong winds, heavy rain, snow, or other severe weather, remove the canopy and curtains to prevent damage to the structure and potential injury. Do not use in extreme weather.
- **Fire Safety:** Keep all flame and heat sources away from the gazebo fabric. The fabric is not fireproof.
- **Structural Integrity:** Do not hang heavy objects from the frame. Do not climb on the gazebo structure.
- **Children and Pets:** Keep children and pets away from the assembly area. Supervise children when they are near or inside the gazebo.
- **Site Selection:** Choose a level surface for assembly and installation. Ensure there are no overhead obstructions like power lines or tree branches.

PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or

damaged, please contact customer support.

- Main Metal Frame Components (Columns, Beams, Roof Supports)
- Double-Tier Canopy Fabric
- Six Removable Curtains
- Ground Stakes
- Expansion Screws (for hard surfaces)
- Assembly Hardware (Bolts, Nuts, Washers, Wrenches)



Figure 1: The Outsunny 10' x 13' Patio Gazebo in Dark Blue, showcasing its double-tier roof and six removable curtains. This image provides an overview of the complete product.



Figure 2: Example of a metal frame component, illustrating the robust construction of the gazebo's support structure.

SETUP (ASSEMBLY)

Follow these steps carefully for proper assembly. It is highly recommended to have at least three people for this process.

1. **Unpack and Identify Parts:** Lay out all components on a clean, flat surface. Refer to the parts list (not provided in detail here, refer to your product's specific assembly diagram) to identify each piece.
2. **Assemble Base Frame:** Connect the horizontal beams to the vertical columns to form the base structure. Ensure all connections are secure but do not fully tighten bolts until the entire frame is assembled.

3. **Install Roof Supports:** Attach the roof support beams to the top of the columns, creating the framework for the canopy.
4. **Attach Canopy:** Carefully drape the main canopy fabric over the roof frame. Secure it according to the attachment points (e.g., ties, velcro, rings). Ensure the double-tier roof is correctly aligned for ventilation.
5. **Install Curtains:** Hang the six removable curtains onto the designated tracks or rings around the perimeter of the gazebo.
6. **Final Tightening:** Once the entire structure is upright and all components are in place, systematically tighten all bolts and connections.
7. **Secure to Ground:** Use the provided ground stakes to anchor the gazebo firmly into soft ground (lawn, soil). For hard surfaces like concrete or decking, use expansion screws (not included, but foot holes are provided for securing). This step is crucial for stability.



Figure 3: The gazebo fully assembled and secured on a patio, demonstrating its integration into an outdoor living space. Note the stable positioning on a level surface.

STABLE STANDING



Ground Stakes:
to secure on soft surfaces



Expansion Screws:
to secure on hard surfaces

Figure 4: Detail showing the base of a gazebo column with options for securing: ground stakes for soft surfaces and expansion screws for hard surfaces. Proper anchoring is essential for stability.

OPERATING THE GAZEBO

Your Outsunny gazebo is designed for versatile use and comfort.

- **Two-Tier Roof:** The double-tier roof design enhances air circulation, reducing heat buildup and wind stress within the gazebo. This feature helps maintain a comfortable temperature.
- **Drainage Holes:** The canopy is equipped with eight drainage holes to prevent water accumulation during light rain, ensuring water runs off efficiently.
- **Removable Curtains:** The six curtains can be easily opened, closed, or removed to adjust for sun exposure, privacy, or airflow. They provide shade from the sun and protection from glare from various angles.

6 REMOVABLE CURTAINS

Shield you from sun and glare from every angle



Figure 5: The gazebo with its curtains partially drawn, illustrating how they can be used to shield from sun and provide privacy. The curtains are easily adjustable.



Figure 6: Illustration of the gazebo in a fully open configuration, allowing for maximum airflow and an unobstructed view of the surroundings.



Figure 7: Illustration of the gazebo in a fully closed configuration, providing complete privacy and enhanced protection from sun glare.

MAINTENANCE

Regular maintenance will extend the life of your gazebo.

- **Cleaning Canopy and Curtains:** The canopy and curtains are easily removable for cleaning. Use a mild soap and water solution. Do not use harsh chemicals or abrasive cleaners. Allow fabric to air dry completely before reattaching or storing.
- **Frame Cleaning:** Wipe down the metal frame with a damp cloth and mild detergent as needed. Dry thoroughly to prevent rust.
- **Seasonal Storage:** For protection against harsh weather conditions (e.g., heavy snow, strong winds, prolonged rain), it is recommended to remove the canopy and curtains and store them in a dry, protected area. This will prevent damage and prolong their lifespan.
- **Hardware Check:** Periodically check all bolts and connections to ensure they remain tight and secure. Tighten as necessary.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Gazebo unstable or swaying in wind.	Not properly anchored; loose connections.	Ensure gazebo is secured with ground stakes or expansion screws. Check and tighten all frame connections. Remove canopy and curtains in strong winds.
Water pooling on canopy.	Excessive rain; drainage holes blocked.	Ensure drainage holes are clear of debris. In heavy rain, it is advisable to remove the canopy.
Curtains not sliding smoothly.	Debris in tracks; damaged rings.	Clean tracks of any dirt or debris. Inspect curtain rings for damage and replace if necessary.

SPECIFICATIONS

Feature	Detail
Brand	Outsunny
Model Number	84C-580V00DB
Material	Polyester, Metal
Frame Material	Iron
Product Dimensions	156.3" L x 116.9" W x 104.3" H (10' x 13')
Item Weight	52 Pounds
Water Resistance Level	Water Resistant
UV Protection	Yes
Occupancy	Up to 12 Person
Color	Blue
Assembly Required	Yes



Figure 8: Detailed dimensions of the gazebo, including length, width, and height, to assist with planning and placement.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact Outsunny directly. This product typically includes a 30-day return policy from the point of purchase.

For assistance with assembly, missing parts, or any product-related inquiries, please visit the official Outsunny website or contact their customer service department. You can often find contact information on the product packaging or through the retailer where you purchased the gazebo.

Online Support: [Visit the Outsunny Store on Amazon](#)

