

WLIVE ASNG135WH

WLIVE White LED Dresser User Manual

MODEL: ASNG135WH

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your WLIVE White LED Dresser. Please read this manual thoroughly before assembly and use to ensure safe and correct operation. Keep this manual for future reference.

The WLIVE White LED Dresser (Model ASNG135WH) is a versatile storage unit designed for various rooms, featuring four spacious drawers, an open display shelf, integrated LED lighting, and a convenient charging station.

2. Safety Information

- **Anti-Tip Device:** Always install the included anti-tip device to secure the dresser to the wall. This prevents accidental tipping, which can cause serious injury, especially to children and pets. Refer to the assembly instructions for proper installation.
- **Weight Limits:** Do not exceed the maximum weight capacity for the countertop (66 lbs) and individual drawers (22 lbs). Overloading can compromise stability and structural integrity.
- **Electrical Safety:** The integrated charging station has passed UL/ETL certification. Ensure the power cord is not pinched or damaged during assembly or use. Do not expose the charging station to moisture.
- **Assembly:** Assemble the dresser on a soft, clean surface to prevent scratches. Ensure all screws and fasteners are tightened securely before use. Periodically check and re-tighten fasteners as needed.
- **Placement:** Place the dresser on a level surface to ensure stability. Avoid placing it in areas with high humidity or direct sunlight, which can affect the wood material.

3. Package Contents

Before beginning assembly, verify that all parts and hardware are present. If any items are missing or damaged, please contact customer support.

- Dresser Panels (Top, Bottom, Sides, Back)
- Drawer Panels (Front, Back, Sides, Bottom)

- Drawer Slides
- Drawer Handles
- LED Light Strip and Controller
- Charging Station Unit (2 AC outlets, 2 USB ports)
- Anti-Tip Device
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Assembly Tools (screwdriver, hex key)
- Instruction Manual

4. Setup and Assembly

Assembly is required for this product. A detailed assembly guide with clearly marked screw positions and reserved installation holes is included. No professional skills are required, and one person can complete the assembly.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a soft, clean surface. Compare them with the parts list in the included assembly guide.
2. **Assemble the Main Frame:** Follow the step-by-step instructions in the assembly guide to construct the dresser frame. Ensure all connections are secure.
3. **Install Drawer Slides:** Attach the drawer slides to the dresser frame and drawer sides as indicated in the instructions. Ensure they are aligned correctly for smooth operation.
4. **Assemble Drawers:** Construct each of the four drawers according to the guide. Install the metal handles securely.
5. **Install LED Lights:** The LED light strips can be freely pasted into the designated area of the open shelf. Connect them to the controller.
6. **Install Charging Station:** Integrate the charging station into the designated area. Route the 1.5m power cable safely.
7. **Attach Anti-Tip Device:** This is a critical safety step. Securely attach the anti-tip device to the back of the dresser and to a wall stud using the provided hardware.

PRODUCT SIZE



Figure 1: Product Dimensions. The dresser measures 15.75 inches deep, 27.56 inches wide, and 38.07 inches high. Each drawer can hold up to 22 lbs, the open shelf 33 lbs, and the top surface 66 lbs.

ANTI-TIP LOCK DETAILS





Figure 2: Anti-Tip Lock Details. This diagram illustrates the correct method for securing the dresser to the wall using the anti-tip device to prevent accidental tipping.

5. Operating Instructions

5.1. LED Lights Operation

The integrated LED lights offer customizable ambiance for your space.

- **Control Methods:** The LED lights can be controlled via a remote control or a dedicated mobile application.
- **Color and Mode Selection:** Choose from 12 scene modes and over 6000 colors to match your preference.
- **Adjustments:** Adjust the speed and brightness of the lights as desired.
- **Music Synchronization:** The lights can synchronize with music, providing a dynamic lighting experience for entertainment.

DRESSER WITH COLORFUL LED LIGHTS

Provide a personalized atmosphere for your family gatherings



6000+ Color Levels



Music Sync



Built-in Mic



Timming Function



Figure 3: LED Light Control. The image shows the LED lights illuminating the open shelf and a smartphone interface for controlling the light settings, including color and mode selection.

5.2. Charging Station Usage

The built-in charging station provides convenient power access for your electronic devices.

- **AC Outlets:** Features 2 standard AC outlets (125V/12A) for powering larger devices.
- **USB Ports:** Includes 2 USB ports (5V/2A) for charging smartphones, tablets, and other USB-powered devices.
- **Power Cable:** The charging station is equipped with a 1.5-meter (approximately 4.9-foot) flexible power cable. Ensure it is plugged into a grounded wall outlet.

LED DRESSER WITH CHARGING STATION

Provide a personalized atmosphere for your family gatherings



2 AC Outlets
125V/12A



2 USB Ports
5V/2A



Power Cord
4.9-Foot

Figure 4: Charging Station. This image details the integrated charging station, showing two AC power outlets and two USB charging ports, ready for device connection.

6. Maintenance

- **Cleaning:** Wipe the dresser surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust the surfaces to prevent buildup.
- **Drawer Care:** Ensure drawers slide smoothly. If they become stiff, check the tracks for debris and clean as necessary. Do not force drawers open or closed.
- **Fastener Check:** Periodically inspect all screws and fasteners to ensure they remain tight. Re-tighten if any looseness is detected.
- **Avoid Overloading:** Adhere to the specified weight limits for drawers and the countertop to maintain the dresser's structural integrity and longevity.

7. Troubleshooting

- **LED Lights Not Working:**
 - Check if the power cable for the LED lights is securely plugged into an outlet.
 - Ensure the LED controller is properly connected to the light strip and power source.
 - Verify that the remote control or mobile app is functioning correctly and has power (e.g., fresh batteries for remote).
- **Charging Station Not Providing Power:**
 - Confirm the dresser's main power cord is fully plugged into a working wall outlet.
 - Test the outlet with another device to ensure it is functional.
 - Check if the devices being charged are properly connected to the AC outlets or USB ports.
- **Drawers Are Sticking or Difficult to Open/Close:**
 - Ensure the dresser is placed on a level surface. Uneven surfaces can cause misalignment.
 - Check that the drawer slides are clean and free of obstructions.
 - Verify that the drawer slides are correctly installed and all screws are tight.
 - Ensure drawers are not overloaded beyond their weight capacity.
- **Dresser Feels Unstable:**
 - Confirm all assembly fasteners are securely tightened.
 - Ensure the anti-tip device is properly installed and anchored to the wall.
 - Verify the dresser is on a flat, stable surface.

8. Specifications

Feature	Detail
Brand	WLIVE
Model Number	ASNG135WH
Product Dimensions	15.75"D x 27.56"W x 38.07"H
Color	White
Room Type	Bedroom, Closet, Guest Room, Living Room, Playroom
Assembly Required	Yes
Item Weight	58.2 pounds
LED Lights	12 Scene Modes, 6000+ Colors, Music Sync, Remote/APP Control
Charging Station	2 AC Outlets (125V/12A), 2 USB Ports (5V/2A), UL/ETL Certified
Countertop Weight Capacity	66 lbs
Drawer Weight Capacity	22 lbs per drawer

9. Warranty and Support

WLIVE is committed to providing quality products and excellent customer service. If you encounter any issues with your dresser, require replacement parts, or have questions regarding assembly or operation, please contact our professional after-sales support team.

For warranty information, please refer to your purchase documentation or contact WLIVE customer service directly. Specific warranty terms and conditions may vary.

Contact Information: Please refer to the contact details provided with your product packaging or visit the official WLIVE website for support.

© 2025 WLIVE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question