



[Manuals.plus](#) /

› [WLIVE](#) /

› WLIVE Farmhouse 4-Drawer Dresser Instruction Manual

WLIVE ASNG134ZX

WLIVE Farmhouse 4-Drawer Dresser Instruction Manual

Model: ASNG134ZX | Brand: WLIVE

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your WLIVE Farmhouse 4-Drawer Dresser. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image 1.1: The WLIVE Farmhouse 4-Drawer Dresser, showcasing its rustic brown finish and decorative metal handles.

2. SAFETY INFORMATION

To ensure safe use of your dresser, please adhere to the following guidelines:

- Always attach the dresser to the wall using the provided anti-tipping device to prevent accidental tipping, especially in households with children.
- Do not allow children to climb on the dresser or open multiple drawers simultaneously, as this can destabilize the unit.
- Ensure the dresser is placed on a flat, stable surface.
- Do not overload drawers. Distribute weight evenly.



Image 2.1: Illustration of the anti-tipping device installation, emphasizing child safety.

3. PACKAGE CONTENTS

Before assembly, verify that all components and hardware are present. Refer to the included assembly guide for a detailed list of parts. If any items are missing or damaged, please contact customer support.

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this dresser. Follow the step-by-step illustrations provided in your assembly manual. It is recommended to have two people for assembly to ensure stability and ease of construction.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify each part using the labels and the assembly diagram.
3. Attach the drawer slides to the side panels of the dresser frame.
4. Assemble the drawer boxes by connecting the side, front, and back panels, then insert the bottom panel.
5. Install the Roman metal handles onto the drawer fronts.
6. Insert the assembled drawers into the dresser frame, ensuring smooth operation.
7. Attach the anti-tipping device to the back of the dresser and secure it to a wall stud.

Your browser does not support the video tag.

Video 4.1: An official WLIVE video demonstrating the features and general use of the Farmhouse Dresser, which can aid in understanding assembly and functionality.

5. OPERATING THE DRESSER

The WLIVE Farmhouse 4-Drawer Dresser is designed for ease of use and efficient storage.

- **Drawer Operation:** Each drawer is equipped with smooth metal slides, allowing for easy opening and closing. Pull the Roman metal handles gently to access the contents.
- **Storage Capacity:** The four deep drawers provide ample space for various items such as clothing, accessories, or household essentials.

LARGE STORAGE SPACE

Willa



15+
TOYS



50+
SOCKS



25+
STATIONERY



25+
CLOTHES



10+
SHORTS



25+
SNACKS

Image 5.1: Detailed view of the dresser's features, including the Roman column handles and the smooth drawer slides.

PRODUCT SIZE



Image 5.2: Visual representation of the dresser's spacious drawers and its ability to organize various items.

6. CARE AND MAINTENANCE

To maintain the appearance and longevity of your dresser, follow these care instructions:

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Spills:** The wooden board surface is water-resistant. Promptly wipe up any spills to prevent staining or damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood finish.
- **Humidity:** Maintain a stable humidity level in the room to prevent wood warping or cracking.



Image 6.1: The water-resistant surface of the dresser, making it easy to clean and maintain.

7. SPECIFICATIONS

Attribute	Detail
Brand	WLIVE
Model Name	ASNG134ZX
Product Dimensions (D x W x H)	15.75" x 31.5" x 38.98"
Color	Rustic Brown
Item Weight	71.9 pounds
Material	Durable Engineered Wood
Number of Drawers	4
Assembly Required	Yes



Image 7.1: Detailed product dimensions for the dresser and its drawers.

8. TROUBLESHOOTING

If you encounter any issues with your dresser, please refer to the following common solutions:

- **Drawers not sliding smoothly:** Check if the metal slides are properly aligned and free from obstructions. Ensure all screws are tightened.
- **Dresser wobbles:** Verify that the dresser is on a level surface. Re-tighten all assembly screws. Ensure the anti-tipping device is securely installed.
- **Missing parts:** If any parts were missing upon delivery, please contact customer support for replacements.

9. WARRANTY AND SUPPORT

WLIVE stands behind the quality of its products. If you experience any problems or have questions regarding your dresser, please contact WLIVE customer support for assistance. Refer to your purchase documentation for specific warranty details and contact information.

