

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [WHYKJTEK](#) /

› [WHYKJTEK A10 Wireless Earbuds User Manual](#)

## WHYKJTEK A10

# WHYKJTEK A10 Wireless Earbuds User Manual

Model: A10

## INTRODUCTION

Thank you for choosing the WHYKJTEK A10 Wireless Earbuds. These earbuds are designed to provide a high-quality audio experience with advanced features such as Bluetooth 5.3 connectivity, clear call technology, and a comfortable, waterproof design. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

## SETUP

### 1. Package Contents

- WHYKJTEK A10 Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual
- Multiple sizes of ear tips for optimal fit



## 2. Initial Charging

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the USB charging cable to the charging port on the case and a power source. The LED display on the charging case will show the battery level during charging.



Image: Earbuds in charging case with LED power display.

## 3. Pairing with Your Device

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth.
4. Search for available Bluetooth devices and select "A10" from the list.
5. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

The earbuds feature Bluetooth 5.3 for stable transmission and a longer range. After the initial pairing, they will automatically connect to the last paired device when removed from the case.



Image: Advanced Bluetooth 5.3 technology features.

#### 4. Wearing the Earbuds

Select the ear tips that provide the most comfortable and secure fit for your ears. Gently insert the earbuds into your ear canal and twist slightly to ensure a snug seal for optimal sound quality and noise isolation.

# 40 Hrs Long Battery Life



Image: Proper wearing of the earbuds for comfort and secure fit.

## OPERATING INSTRUCTIONS

The WHYKJTEK A10 earbuds feature smart touch controls for easy management of music, calls, and voice assistant functions.



Image: Detailed smart touch control functions.

### Touch Control Functions:

- **Play/Pause:** Click the left/right earbud MFB button 1 time.
- **Answer Phone Calls:** Click the left/right earbud MFB button 1 time.
- **Hang Up Call:** Click the left/right earbud MFB button 1 time during a call.
- **Reject Calls:** Long press the left/right earbud MFB key for 2 seconds.
- **Previous Song:** Double click the left earbud MFB key.
- **Next Song:** Double press the right earbud MFB key.
- **Voice Assistant (Siri/Google Assistant):** Four clicks on the left/right earbud MFB keys.
- **Volume Up:** Triple click the right earbud MFB key.
- **Volume Down:** Triple click the left earbud MFB key.

### Power On/Off

- **Power On:** Open the charging case, and the earbuds will power on automatically. Alternatively, long press the MFB button on both earbuds for 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid. Alternatively, long press the MFB button on both earbuds for 5 seconds.

## MAINTENANCE

### Cleaning

Regularly clean your earbuds and charging case to ensure optimal performance and hygiene. Use a soft, dry, lint-free cloth. For ear tips, you may gently wipe them with a slightly damp cloth and mild soap, then dry thoroughly before reattaching.

### Charging and Battery Life

The earbuds provide up to 8 hours of playback on a single charge, with the charging case extending total playtime to up to 48 hours. The charging case features a dual LED display to visually show the power level of both the case and individual earbuds.



Image: Battery life details for earbuds and charging case.

### **Water Resistance (IPX7)**

The WHYKJTEK A10 earbuds are IPX7 waterproof, meaning they are resistant to sweat, rain, and light splashes. They are suitable for exercise and outdoor activities. However, they are not designed for swimming or prolonged submersion in water.

# Built-in ENC Noise Reduction Chip

Enjoy high-definition and noise-free call quality



Image: IPX7 waterproof rating for the earbuds.

## TROUBLESHOOTING

### Earbuds Not Pairing/Connecting

- Ensure both earbuds are charged.
- Turn off Bluetooth on your device and turn it back on.
- Delete "A10" from your device's Bluetooth history and try pairing again.
- Place both earbuds back into the charging case, close the lid, wait a few seconds, then open the lid to re-initiate pairing mode.

### Only One Earbud Working

- Ensure both earbuds are charged.
- Try placing both earbuds back into the charging case, closing the lid, and then taking them out again to force them to reconnect to each other.
- Perform a factory reset (refer to the full user manual for specific reset instructions if needed, as this varies by model).

## Poor Sound Quality

- Ensure the earbuds are clean and free of debris.
- Adjust the ear tips for a better seal in your ear canal.
- Move closer to your connected device to avoid interference.
- Check your device's audio settings.

## Charging Case Not Charging

- Ensure the charging cable is securely connected to both the case and the power source.
- Try a different USB charging cable or power adapter.
- Clean the charging port on the case for any dust or debris.

## SPECIFICATIONS

Feature	Detail
Model Name	A10
Connectivity Technology	Wireless (Bluetooth 5.3)
Wireless Communication Technology	Bluetooth
Compatible Devices	Cellphones, Tablets, Laptops, Desktops
Water Resistance Level	IPX7 (Waterproof)
Control Method	Touch
Ear Placement	In Ear
Form Factor	In Ear
Battery Average Life (Earbuds)	8 Hours
Total Playtime with Charging Case	Up to 48 Hours
Battery Cell Composition	Lithium Polymer
Manufacturer	WHYKJTEK
Item Weight	Approximately 4g per earbud

## WARRANTY INFORMATION

The WHYKJTEK A10 Wireless Earbuds come with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging or contact customer support for detailed information regarding warranty terms and conditions.

## CUSTOMER SUPPORT

If you encounter any issues or have questions not covered in this manual, please contact WHYKJTEK customer support through the retailer's platform or the contact information provided in your product packaging.

Our support team is available to assist you.