

TCL TP200K

TCL TP200K Portable Bluetooth Party Speaker

INSTRUCTION MANUAL

[Overview](#) [Setup](#) [Operation](#) [Introduction](#) [Maintenance](#) [Safety Information](#) [Troubleshooting](#) [Product Specifications](#) [Warranty & Support](#)

1. Introduction

Welcome to your new TCL TP200K Portable Bluetooth Party Speaker. This manual provides essential information for the proper setup, operation, and maintenance of your device. Please read it thoroughly before use and retain it for future reference.

What's in the Box:

- TCL TP200K Portable Bluetooth Party Speaker
- Power Cord
- Quick Start Guide
- Warranty and Safety Information



Dimensions:

Speaker Dimensions:
14.63" x 25.68" x 14.07"

What's in the Box:

- Party Speaker
- Power Cable
- Quick Start Guide
- Warranty and Safety Information

*Features and specifications subject to change.

Figure 1: TCL TP200K Speaker with included items and dimensions. The speaker measures 14.07 inches deep, 14.63 inches wide, and 25.68 inches high.

2. Safety Information

Please observe the following safety guidelines to ensure safe operation and to prevent damage to your speaker.

IPX4 Splash-Proof Rating

The TCL TP200K speaker is rated IPX4, indicating resistance to water splashes from any direction. This makes it suitable for outdoor use where light splashes may occur. However, it is not waterproof and should not be submerged in water or exposed to direct, high-pressure water jets. Ensure all port covers are securely closed before exposure to moisture.

IPx4 Splash Proof – Built to handle spills and splashes.



Figure 2: The speaker is designed to withstand splashes, making it suitable for various environments.

3. Product Overview

The TCL TP200K is a portable party speaker engineered to deliver powerful audio and dynamic visual effects. Its design includes a versatile carry handle for easy transportation and flexible placement.

Key Features:

- **220W Maximum Output Power:** Provides clear highs and deep bass for a full audio experience.
- **12-Hour Battery Life:** Enjoy extended music playback. (*Note: Battery life is based on 25% volume with static light effects. Actual performance may vary based on usage conditions.*)
- **5 RGB Dynamic Light Show Presets:** Create a vibrant atmosphere with integrated lighting effects.
- **Bass Boost:** Enhances low frequencies for a more impactful sound.
- **IPX4 Splash-Proof:** Offers protection against water splashes.
- **Bluetooth 5.4 Connectivity:** Enables stable wireless music streaming.
- **Wireless Party Link (Auracast):** Connect multiple compatible speakers for a synchronized audio experience.
- **True Wireless Stereo (TWS) Pairing:** Pair two TP200K speakers for dedicated left and right stereo channels.
- **Microphone and Guitar Inputs:** Allows for karaoke and live instrument connection.
- **USB Playback:** Play audio files directly from a USB storage device.

Grab 'n Go Handle – Built-in handles to take the party anywhere.



Figure 3: The speaker features a built-in handle for convenient portability.



Figure 4: The intuitive control panel provides easy access to speaker functions.

4. Setup

Charging the Speaker

Before initial use, fully charge the speaker. Connect the provided power cord to the speaker's power input and then to a wall outlet. The charging indicator will display the current battery status. A full charge ensures maximum playback time.

Powering On/Off

To turn the speaker on or off, press and hold the power button located on the control panel until the indicator lights activate or deactivate.

Bluetooth Pairing

1. Turn on the speaker. The Bluetooth indicator will flash, signifying that the speaker is in pairing mode.
2. On your Bluetooth-enabled device (e.g., smartphone, tablet), navigate to the Bluetooth settings.
3. Search for available devices and select "TCL TP200K" from the list.

4. Once successfully connected, the Bluetooth indicator on the speaker will remain solid.



Figure 5: Effortlessly stream music to your speaker via Bluetooth.

5. Operation

Music Playback

After connecting your device via Bluetooth or inserting a USB drive, you can control music playback using either your connected device or the speaker's control panel:

- **Play/Pause:** Press the dedicated Play/Pause button.
- **Volume Adjustment:** Use the '+' and '-' buttons to increase or decrease the volume.
- **Track Navigation:** Use the skip buttons to move to the next or previous track.

Light Show Modes

The speaker features 5 RGB dynamic light show presets. Press the light button on the control panel to cycle through the available modes or to turn the lights off. Each press will change the light pattern or color sequence.

5 RGB Dynamic LightShow Presets – Transform any space into a party.



Figure 6: The speaker's dynamic light shows enhance the listening experience.

Bass Boost

Activate the Bass Boost feature by pressing the dedicated button on the control panel. This will enhance the low-frequency output, providing a deeper and more pronounced bass sound.

Bass Boost – Bass that brings the party to life.



Figure 7: Engage Bass Boost for enhanced low-end audio.

Karaoke Mode (Microphone & Guitar Inputs)

The speaker is equipped with input jacks for a microphone and a guitar. Connect your microphone or guitar to the respective ports. Use the dedicated controls on the speaker to adjust the volume and echo effects for your vocals or instrument. *(Note: Microphone and guitar are not included.)*

Microphone and Guitar Inputs – Sing and play all night.*

*Microphone not included.



Figure 8: Connect a microphone or guitar for karaoke or live performances.

True Wireless Stereo (TWS) Pairing

To create a true stereo soundstage, you can pair two TCL TP200K speakers together:

1. Ensure both speakers are powered on and not currently connected to any Bluetooth device.
2. On one speaker, press and hold the **TWS/LINK** button until you hear an audible confirmation tone.
3. Repeat this action on the second speaker.
4. The speakers will automatically establish a connection with each other. Once paired, connect your audio source device to one of the speakers via Bluetooth.

**True Wireless Stereo – Enjoy
powerful, stereo sound.**



Figure 9: Pair two speakers for an immersive stereo sound experience.

Wireless Party Link (Auracast)

For a larger, multi-speaker audio setup, utilize the Wireless Party Link feature (Auracast) to connect multiple TCL Party Speakers to a single audio source. This allows for synchronized music playback across several speakers, ideal for expansive spaces or larger gatherings. Refer to the Quick Start Guide for detailed instructions on Auracast pairing procedures.

Wireless Party Link (Auracast) – Multiply the fun with multiple TCL Party Speakers.



Figure 10: Connect multiple speakers for a wider sound distribution.

USB Audio Playback

Insert a USB flash drive containing compatible audio files into the USB port on the speaker. The speaker will automatically detect the drive and begin playing music. Use the speaker's playback controls to navigate through tracks and adjust volume.

USB Audio Playback – Play your favorite music, even without your smartphone.



Figure 11: Play music directly from a USB drive.

6. Maintenance

Cleaning

To clean the speaker, use a soft, dry cloth. Do not use abrasive cleaners, solvents, or strong chemicals, as these can damage the surface. For light dirt, a slightly damp cloth can be used, ensuring no moisture enters any ports or openings.

Storage

When storing the speaker for extended periods, ensure it is fully charged and then powered off. Store it in a cool, dry place, away from direct sunlight, extreme temperatures, and excessive dust. Protect it from physical impact.

7. Troubleshooting

If you encounter issues with your TCL TP200K speaker, refer to the table below for common problems and their solutions.

Problem	Possible Cause	Solution
---------	----------------	----------

Speaker does not power on.	Battery is depleted.	Connect the speaker to a power source and charge it fully.
Cannot pair via Bluetooth.	Speaker is already connected to another device or not in pairing mode.	Ensure the speaker is in Bluetooth pairing mode (flashing indicator). Disconnect from any previously paired devices. Verify Bluetooth is enabled on your source device.
No sound output.	Volume is too low or muted. Incorrect input source selected.	Increase the volume on both the speaker and your connected device. Press the 'SOURCE' button to cycle through input modes (Bluetooth, USB, AUX) until the correct source is selected.
Light show not working.	Light show is turned off or a static mode is selected.	Press the light button on the control panel to activate or change the light show mode.
Poor audio quality.	Bluetooth interference or distance. Low battery.	Move the source device closer to the speaker. Ensure no obstacles are blocking the Bluetooth signal. Charge the speaker if the battery is low.

8. Specifications

Below are the technical specifications for the TCL TP200K Portable Bluetooth Party Speaker.

Feature	Detail
Model Number	TP200K
Brand	TCL
Maximum Output Power	220 Watts
Connectivity Technology	Bluetooth 5.4, Auxiliary (AUX), USB
Audio Output Mode	Stereo
Battery Average Life	Up to 12 Hours
Water Resistance Level	IPX4 Splash-Proof
Item Dimensions (D x W x H)	14.07" x 14.63" x 25.68"
Item Weight	31.5 Pounds
Color	Black
Control Method	Touch
Woofer Diameter	6.6 Inches
Subwoofer Diameter	5.5 Inches
UPC	846042046305



Dimensions:	What's in the Box:
Speaker Dimensions: 14.63" x 25.68" x 14.07"	<ul style="list-style-type: none"> • Party Speaker • Power Cable • Quick Start Guide • Warranty and Safety Information <p><small>*Features and specifications subject to change.</small></p>

Figure 12: Detailed dimensions of the TCL TP200K speaker.

9. Warranty and Support

Warranty Information

This TCL TP200K Portable Bluetooth Party Speaker is covered by a 1-year manufacturer's limited warranty. For complete details regarding warranty coverage, terms, and conditions, please refer to the 'Warranty and Safety Information' document included in your product packaging.

Customer Support

For technical assistance, troubleshooting guidance, or to inquire about warranty claims, please visit the official TCL support website. You can also find contact information for customer service in the Quick Start Guide or on the TCL website. Please have your model number (TP200K) and proof of purchase ready when contacting support.