



[Manuals.plus](#) /

› [Omzer](#) /

› Omzer Baby Play Yard (Model 79x71x26 Inch) Instruction Manual

Omzer 79*71*26 Inch

Omzer Baby Play Yard (Model 79x71x26 Inch) Instruction Manual

INTRODUCTION

Welcome to your new Omzer Baby Play Yard. This manual provides essential information for safe assembly, operation, and maintenance of your play yard. Please read all instructions carefully before use.

The Omzer Baby Play Yard measures 79x71x26 inches, providing a spacious and secure area for infants and toddlers.

IMPORTANT SAFETY INFORMATION

- Always supervise children when they are in the play yard.
- Ensure all parts are correctly assembled and securely fastened before placing a child inside.
- Do not use the play yard if any parts are damaged or missing.
- Keep the play yard away from open flames, heaters, and other heat sources.
- The 26-inch height is designed to prevent children from climbing out. Do not add items that could assist a child in climbing.
- The external zipper door is for adult access only. Ensure it is closed and secured when a child is inside.
- This playpen is designed for children who cannot climb out and are under 36 inches tall.

BUILD A SAFE SPACE FOR BABY

Keep away from danger and say goodbye to injury.



Image showing two babies playing safely inside the Omzer Baby Play Yard. Surrounding images with red 'X' marks illustrate common household dangers like electrical outlets, stairs, and unstable furniture, emphasizing the play yard's role in creating a safe environment.

PACKAGE CONTENTS

Before assembly, verify that all components are present:




Diagram illustrating all components included in the Omzer Baby Play Yard package. It shows various tube lengths, T-shaped joints, top joints, bottom joints, pull rings, an instruction manual, and a storage bag.

- 976mm tubes: 8
- 880mm tubes: 8
- 627mm tubes: 8
- T-shaped joints: 9
- Top joints: 5
- Bottom joints: 5
- Pull rings: 2
- Instruction Manual: 1
- Storage Bag: 1

SETUP AND ASSEMBLY INSTRUCTIONS

The play yard is designed for easy assembly without tools, typically within 10 minutes. Follow these steps:

1. **Assemble the Base Frame:** Connect the longest tubes (976mm) and the 880mm tubes using the T-shaped joints and bottom joints to form the rectangular base.
2. **Assemble the Side Frames:** Insert the 627mm tubes into the vertical openings of the T-shaped joints and top joints to create the vertical supports.
3. **Attach the Fabric Cover:** Carefully slide the fabric cover over the assembled frame, ensuring the mesh panels are correctly aligned. Secure the fabric to the frame using any integrated fasteners.
4. **Final Connections:** Ensure all joints are firmly connected and the frame is stable. Verify that the anti-slip suction cups on the bottom joints are making full contact with the floor.



An image of the fully assembled Omzer Baby Play Yard, highlighting its dimensions of 79 inches by 71 inches by 26 inches. This provides a visual reference for the final product.

OPERATING INSTRUCTIONS

- **Zipper Door Access:** The play yard features an external zipper door for convenient access. This door can only be opened from the outside by an adult, ensuring the child's safety inside.

EXTERNAL ZIPPER DOOR

The external zipper door can only be opened from the outside by parents, which greatly enhances the safety of the baby.



Image showing an adult opening the external zipper door of the play yard, with a baby crawling inside. A close-up inset shows the zipper mechanism, emphasizing its external operation for child safety.

- **Visible Mesh Panels:** The 360° visible breathable mesh panels allow for constant supervision of your child while ensuring good air circulation.
- **Pull Rings:** Two pull rings are included to assist toddlers in pulling themselves up and practicing their first steps, promoting balance and confidence.
- **Stability:** The robust steel tubing and anti-slip suction cups provide a sturdy and stable play environment.

MAINTENANCE AND CARE

- **Cleaning:** The Oxford fabric material can be wiped clean with a damp cloth and mild soap. For deeper cleaning, the fabric can be hand-washed or machine-washed without losing shape or color. Ensure the fabric is completely dry before reassembling or storing.
- **Storage:** A compact carry bag is included for easy storage and transport. Disassemble the play yard by reversing the assembly steps and place all components into the storage bag.

TROUBLESHOOTING

- **Issue: Play yard feels unstable.**

Solution: Ensure all tubes are fully inserted into their respective joints. Check that the anti-slip suction cups are clean and making firm contact with a flat, dry surface.

- **Issue: Difficulty assembling parts.**

Solution: Refer to the "Setup and Assembly Instructions" section. Ensure you are using the correct tube lengths and joint types for each section. Apply gentle, even pressure when connecting parts.

- **Issue: Fabric tearing or damage.**

Solution: Inspect the fabric for any tears or damage. If significant, discontinue use and contact customer support for replacement parts or guidance. Avoid sharp objects near the play yard.

PRODUCT SPECIFICATIONS

Feature	Detail
Model	79*71*26 Inch
Dimensions (L x W x H)	79 x 71 x 26 inches
Item Weight	11.24 Pounds
Material Type	Mesh Fabric, Oxford Cloth, Steel Tubing, ABS Joints
Color	Khaki
Brand	Omzer

WARRANTY INFORMATION

Omzer products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your product or contact Omzer customer support.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need replacement parts, please contact Omzer customer support. Contact information can typically be found on the product packaging or the official Omzer website.