

LUXOAK CCS002

LUXOAK 3-Piece Farmhouse Living Room Table Set Instruction Manual

MODEL: CCS002

Brand: LUXOAK

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your LUXOAK 3-Piece Farmhouse Living Room Table Set. This set includes one coffee table and two end tables, designed with a rustic farmhouse aesthetic and featuring integrated charging capabilities.

Included Components

- 1 x Coffee Table
- 2 x End Tables with Charging Station
- Assembly Guide

Setup and Assembly

Assembly of the LUXOAK 3-Piece Farmhouse Living Room Table Set is required. Please follow the included assembly guide carefully. It is recommended that two individuals perform the assembly to ensure stability and ease of construction. A screwdriver is the primary tool recommended for assembly.

Always assemble furniture according to the provided instructions. Ensure stability and proper weight distribution to prevent tipping or collapse.

Product Features

Farmhouse Design

The set features an X-shaped barn door-inspired design, providing a rustic farmhouse aesthetic. The black oak finish

adds elegance and beauty to your living space.



Image: The complete 3-piece table set, including a coffee table and two end tables, arranged in a living room with a sofa and decorative items.



DETAILS



Wood Grain Finish



Classic X-shape



Stable Structure

Image: Detailed view of the coffee table highlighting its wood grain finish, classic X-shape design, and stable structure.

Integrated Charging Station

Each end table is equipped with an ETL-certified charging station, featuring two standard AC outlets and two USB ports. A 4.9 ft extension cord allows for flexible placement and convenient charging of your electronic devices.



Image: The 3-piece table set in a living room, with an inset showing a detailed view of the charging station on an end table, featuring two AC outlets and two USB ports.

FARMHOUSE 2-TIER END TABLE WITH CHARGING STATION



120V/12A
[2 AC Outlets]



5V/2A
[2 USB Ports]



Power Cord
[4.9 Feet]

Image: A farmhouse-style 2-tier end table with a charging station on its top surface, shown with a tablet and an alarm clock. Specifications for the AC outlets and USB ports are indicated.

Spacious Storage

The coffee table includes two-tier shelves for open storage, helping to keep your space tidy. Each end table features a large closed storage cabinet, minimizing clutter in your living room.

FARMHOUSE 2-TIER COFFEE TABLE



Image: A close-up view of the farmhouse 2-tier coffee table, showcasing its spacious tabletop and lower shelf with decorative items.

DETAILS



Charging Station



Open Storage Cubby



Retro Handle



Image: Detailed views of an end table, highlighting its charging station, open storage cubby, and retro handle on the cabinet door.

Product Dimensions

The coffee table measures 40"W x 21.6"D x 17.9"H. Each end table measures 17.3"W x 15.4"D x 25"H.



Image: A diagram illustrating the precise dimensions of both the coffee table and the end tables, including width, depth, and height.

Product Overview Video

Your browser does not support the video tag.

Video: An overview of the Farmhouse Living Room Table Sets, showcasing their design and features in various room settings.

Operating the Charging Station

To use the integrated charging station on your end tables, simply plug the table's power cord into a standard wall outlet. Once connected, you can utilize the two AC outlets for devices requiring standard power and the two USB ports for charging compatible USB devices such as phones or tablets.

Maintenance and Care

To maintain the appearance and longevity of your table set, wipe surfaces with a dry cloth. Avoid using harsh chemicals or abrasive cleaners. Keep the furniture away from direct heat sources and do not place excessively heavy objects on the shelves to prevent structural damage.

Specifications

Attribute	Detail
Brand	LUXOAK
Model Name	CCS002
Coffee Table Dimensions	40"W x 21.6"D x 17.9"H
End Table Dimensions	17.3"W x 15.4"D x 25"H
Material Type	Engineered Wood
Color	Black Oak
Item Weight	86 Pounds (Total Set)
Maximum Weight Recommendation	100 Pounds
Power Outlets (End Tables)	2 Standard AC outlets (120V/12A)
USB Ports (End Tables)	2 USB ports (5V/2A)
Power Cord Length	4.9 ft
Assembly Required	Yes
Tools Recommended For Assembly	Screw Driver

Important Safety Information

Always assemble furniture according to the provided instructions. Ensure stability and proper weight distribution to prevent tipping or collapse. Keep away from heat sources and do not place heavy objects on the shelves to avoid structural damage. Do not overload the electrical outlets or USB ports. Disconnect the power cord from the wall outlet when not in use or during cleaning.

Troubleshooting

- Loose Connections:** If any part of the furniture feels unstable, re-check all screws and fasteners to ensure they are tightened securely.
- Charging Station Not Working:** Ensure the power cord is fully plugged into a functional wall outlet. Check if the devices being charged are properly connected to the USB ports or AC outlets.
- Missing Parts:** If any components are missing during assembly, please refer to the warranty and support section for contact information.

Warranty and Support

For warranty information, replacement parts, or technical support, please contact LUXOAK customer service. Refer to the product packaging or the official LUXOAK website for the most current contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question