

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [jioeuinly](#) /

> jioeuinly Lifephone Star Phone Case CPT52 with Tempered Glass Screen Protector User Manual

jioeuinly CPT52

jioeuinly Lifephone Star Phone Case CPT52 with Tempered Glass Screen Protector User Manual

Model: CPT52

INTRODUCTION

This manual provides comprehensive instructions for the jioeuinly Lifephone Star Phone Case CPT52, which includes a PU leather kickstand magnetic wallet case and a tempered glass screen protector. This product is designed to protect your Lifephone Star while offering additional functionality such as card storage and a viewing stand.

Key features include a durable PU leather construction, a secure magnetic closure, integrated card slots, a convenient kickstand for media viewing, and a tempered glass screen protector for enhanced display protection.

WHAT'S IN THE BOX

- 1 x jioeuinly Lifephone Star Phone Case CPT52
- 1 x Tempered Glass Screen Protector

SETUP

Installing the Phone Case

1. Ensure your Lifephone Star is clean and free of dust or debris.
2. Align your Lifephone Star with the case, ensuring all ports and buttons match the case cutouts.
3. Gently press the phone into the case until it is securely seated. Ensure all edges are properly covered by the silicone ring for optimal protection.

Installing the Tempered Glass Screen Protector

1. **Clean the Screen:** Use the provided cleaning wipes (if included) or a microfiber cloth to thoroughly clean your phone's screen. Ensure no dust, smudges, or fingerprints remain.
2. **Align the Protector:** Carefully peel off the protective film from the adhesive side of the tempered glass. Align the screen protector with your phone's screen, paying attention to the speaker, camera, and home button cutouts.
3. **Apply:** Once aligned, gently lower the screen protector onto the screen. It will adhere automatically.

4. **Remove Bubbles:** If any bubbles appear, gently push them towards the edges of the screen using a soft cloth or a squeegee (if provided).



Scratch Proof

Scratch proof screen effectively avoids sharp objects scratching or abrasion



The tempered glass screen protector offers 9H high hardness, shatterproof design, perfect adhesion, case-friendly fit, 99.9% super transparency, and anti-fingerprint properties, effectively protecting against scratches and abrasions.


OPERATING INSTRUCTIONS

Using the Kickstand Feature

The case is designed with a built-in kickstand feature. To activate, simply fold the back cover of the case to create a triangular stand. This allows for adjustable viewing angles, ideal for watching videos, reading e-books, or making video calls hands-free.

Utilizing Card Storage

The wallet case includes multiple card slots on the inside flap. Carefully insert your credit cards, ID cards, or cash into these designated slots. The design allows for convenient storage while keeping your essentials secure.



The case features card slots for convenient storage of essential cards and cash.

Magnetic Closure

The case features a magnetic closure to keep the front flap securely closed, protecting your phone screen and stored items. The built-in magnet ensures your valuables remain in place.



The magnetic closure keeps the case securely shut, and the case can be folded into a stand.

MAINTENANCE

Cleaning the Case

To clean the PU leather case, gently wipe it with a soft, slightly damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the material. Allow the case to air dry completely.

Cleaning the Screen Protector

For the tempered glass screen protector, use a clean microfiber cloth to wipe away fingerprints and smudges. For more stubborn marks, lightly dampen the cloth with water or a screen cleaner specifically designed for electronics.

TROUBLESHOOTING

- **Case not fitting correctly:** Ensure that the phone model is a Lifephone Star. This case is specifically designed for the Lifephone Star.
- **Screen protector bubbles:** If bubbles appear after installation, gently press them towards the nearest edge with a soft cloth. Small bubbles may disappear on their own within 24-48 hours.
- **Magnetic closure not holding:** Check if there are too many cards or items in the card slots, which might prevent the magnet from engaging properly. Ensure no debris is obstructing the magnetic strip.
- **Difficulty accessing buttons/ports:** Verify that the phone is correctly seated within the case and that the case cutouts align perfectly with your phone's features.

SPECIFICATIONS

Product Dimensions	0.39 x 0.39 x 0.39 inches
Item Weight	2.46 ounces
Material	Polyurethane (PU Leather)
Compatible Phone Models	Lifephone Star
Form Factor	Flip Case
Special Features	Card insertion, Stash the change, Thickened anti-drop + Card Function

WARRANTY AND SUPPORT

Information regarding product warranty and customer support is not available in this manual. Please refer to the product packaging or the retailer's website for details on warranty coverage and how to contact customer service for support.