

B0F547WF27

Generic Zero Gravity Shiatsu SL Track Massage Chair User Manual

Model: B0F547WF27

1. INTRODUCTION

Thank you for choosing the Generic Zero Gravity Shiatsu SL Track Massage Chair. This manual provides essential information for the safe and effective operation, assembly, and maintenance of your new massage chair. Please read this manual thoroughly before use and retain it for future reference.



2. IMPORTANT SAFETY INFORMATION

To reduce the risk of electric shock, burns, fire, or injury, please observe the following precautions:

- Always unplug the appliance from the electrical outlet immediately after using and before cleaning.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Never use pins or other metallic fasteners with this appliance.
- Close supervision is necessary when this appliance is used by, on, or near children, invalids, or disabled persons.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water.
- Keep the cord away from heated surfaces.
- Never use while sleeping or drowsy.
- Never drop or insert any object into any opening.
- Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use on bare skin.
- Do not use on infants, invalids, or on a sleeping or unconscious person.
- Do not use on insensitive skin or on a person with poor blood circulation.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep air openings free of lint, hair, and the like.
- Do not use this massage chair if you have any medical conditions without consulting a doctor.

3. PACKAGE CONTENTS

Please check the package contents carefully. If any items are missing or damaged, contact customer support.

- Main Massage Chair Unit
- Left Armrest
- Right Armrest
- Back Cushion / Headrest
- Seat Cushion
- Remote Control
- Remote Control Holder
- Power Cord
- Assembly Tools (Hex Wrench, Screws)
- User Manual (this document)

4. SETUP AND ASSEMBLY

Follow these steps to assemble your massage chair. It is recommended to have two people for assembly.

4.1. Assembly Video Guide

For a visual guide, please refer to the official assembly video below:

Your browser does not support the video tag.

Video 4.1: Official Massage Chair Assembly Guide. This video demonstrates the step-by-step process of assembling the massage chair, including unpacking, connecting components, and securing parts.

4.2. Step-by-Step Assembly

1. **Unpack Components:** Carefully remove all parts from the packaging. Place the main chair unit on a soft, flat surface to prevent damage.
2. **Connect Air Hoses:** Locate the blue air hoses and white connectors. Connect the corresponding hoses from the main unit to the armrests. Ensure a secure fit.



Image 4.2: Illustration of the internal massage mechanism, including air hose connections.

3. **Attach Armrests:** Align the armrests with the main chair unit. Secure them using the provided screws and hex wrench. Ensure all connections are tight.
4. **Connect Power and Control Cables:** Connect the power cable and any other control cables as indicated in the video. Ensure all connections are firm.
5. **Install Back Cushion and Headrest:** Place the back cushion onto the chair. Secure the headrest/shoulder pads using the Velcro fasteners.
6. **Attach Remote Control Holder:** Insert the remote control holder into the designated slot on the armrest.



Image 4.3: Remote control holder securely attached to the chair's armrest.

7. **Final Check:** Before plugging in, ensure all connections are secure and the chair is stable.

5. OPERATING INSTRUCTIONS

This section details how to operate your massage chair using the remote control.

5.1. Remote Control Overview

The remote control allows you to select various massage programs and adjust settings.



Image 5.1: Remote control for the massage chair, showing various function buttons.

- **Power Button:** Turns the chair on/off.
- **Zero-G Button:** Activates the Zero Gravity recline position.
- **Auto Mode:** Selects pre-programmed massage routines (e.g., Shiatsu, Thai Stretch).
- **Intensity/Speed:** Adjusts the strength or speed of the massage rollers.
- **Pause:** Temporarily stops the current massage program.
- **USB Charging:** Use the integrated USB port to charge compatible devices.

5.2. Key Features

- **SL Track Massage:** The massage rollers follow the natural curve of your spine, extending from your neck to your glutes.
- **Shiatsu Massage:** Utilizes kneading, tapping, and rolling techniques to simulate a professional massage.
- **Zero Gravity Recline:** Elevates your legs above your heart, reducing pressure on the spine and enhancing relaxation.
- **Airbag Compression Massage:** Strategically placed airbags provide compression massage to various body parts, including shoulders, arms, hips, and calves.



Image 5.2: Visual representation of air massage zones within the chair.

- **Heating Function:** Lumbar heating provides soothing warmth to the lower back.
- **Foot Roller Massager:** Rollers located in the footrest provide reflexology massage to the soles of your feet.
- **Bluetooth Speaker:** Connect your device via Bluetooth to enjoy music during your massage.



Image 5.3: Bluetooth speaker functionality for audio playback.

- **Anion Function:** Releases negative ions to promote a fresh environment.

6. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your massage chair.

- **Cleaning:** Wipe the chair with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, unplug the chair and cover it to protect from dust.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the upholstery to fade or crack.
- **Regular Inspection:** Periodically check the power cord and connections for any signs of damage.

7. TROUBLESHOOTING

If you encounter any issues, please refer to the following common solutions:

Problem	Possible Cause	Solution
Chair does not power on.	Power cord not properly connected; power outlet malfunction.	Ensure power cord is securely plugged into both the chair and a working electrical outlet. Check the power switch.
Massage rollers are not moving.	Program not selected; safety feature activated.	Select an auto program or manual massage mode. Ensure no objects are obstructing the rollers.
Airbags are not inflating.	Air hose disconnected; air pump issue.	Check all air hose connections for tightness. If the problem persists, contact customer support.
Unusual noise during operation.	Loose component; normal operational sound.	Ensure all screws and connections are tight. Some operational sounds are normal. If the noise is loud or unusual, discontinue use and contact support.

8. SPECIFICATIONS

Technical details for the Generic Zero Gravity Shiatsu SL Track Massage Chair:

- **Brand:** Generic
- **Model:** B0F547WF27
- **Color:** Black
- **Material:** Polyurethane
- **Product Dimensions (D x W x H):** 57.67" x 29.72" x 33.46"
- **Pattern:** Solid
- **Manufacturer:** QiMaieeUSA
- **First Available:** April 16, 2025




Image 8.1: Detailed dimensions of the massage chair for placement and clearance.

9. WARRANTY AND CUSTOMER SUPPORT

Specific warranty details are not provided in this manual. For warranty information, technical support, or service inquiries, please contact the seller or manufacturer directly through your purchase platform.

Manufacturer: QiMaieeUSA

Documents - B0F547WF27 – B0F547WF27

no relevant documents