

POWELL POW-TARIJ-ZW

Powell 450W Carpet Cleaner User Manual

Model: POW-TARIJ-ZW | Brand: POWELL

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the appliance. Retain this manual for future reference.

- Always ensure the power supply matches the voltage specified on the rating label.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Unplug from the outlet when not in use and before cleaning.
- Keep the appliance out of reach of children and pets.
- Use only cleaning solutions recommended for carpet cleaners. Do not use flammable or abrasive liquids.
- Do not operate the appliance with a damaged cord or plug.
- Avoid cleaning electrical outlets or other electrical components.
- Do not block ventilation openings.

PRODUCT OVERVIEW

The Powell 450W Carpet Cleaner is designed for effective cleaning of various textile surfaces, including carpets, rugs, sofas, mattresses, and car upholstery. Its powerful motor and dual-tank system ensure thorough cleaning and easy disposal of dirty water.



Image: The Powell 450W Carpet Cleaner, showcasing its compact design and included accessories like the brush head and nozzle.

Components



Image: Detailed diagram illustrating the various components of the carpet cleaner, including tanks, hose, and controls.

- **Clean Water Tank:** Holds fresh water and cleaning solution.
- **Dirty Water Tank:** Collects extracted dirty water.
- **Hose:** Flexible hose for directing the cleaning nozzle.
- **Cleaning Nozzle/Brush Head:** For spraying solution, scrubbing, and suction.
- **Water Spray Button:** Activates the spray function.
- **On/Off Button:** Powers the unit on and off.
- **Power Cord:** Connects the unit to an electrical outlet.

SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Assemble Hose and Nozzle:** Connect the flexible hose to the main unit and attach the desired cleaning nozzle (e.g., brush head) securely.
3. **Fill Clean Water Tank:** Remove the clean water tank. Fill it with warm tap water (max 40°C) and the recommended amount of carpet cleaning solution. Do not overfill. Securely reattach the tank to the unit.



Image: Diagram illustrating the 1800ml clean water tank capacity and 1100ml waste water tank capacity.

4. **Empty Dirty Water Tank:** Ensure the dirty water tank is empty and properly seated before starting.
5. **Position Power Cord:** Unwind the power cord and ensure it is not tangled or obstructing your work area.

OPERATING INSTRUCTIONS

Preparing for Cleaning

- **Pre-vacuum:** For best results, thoroughly vacuum the area to be cleaned to remove loose dirt and debris.
- **Test Spot:** Always test the cleaning solution on an inconspicuous area of the carpet or upholstery for colorfastness before full application.

Cleaning Procedure

1. **Power On:** Plug the power cord into a suitable electrical outlet. Press the On/Off button to turn on the cleaner.
2. **Spray Solution:** Hold the cleaning nozzle over the area to be cleaned. Press the water spray button to release the cleaning solution onto the surface.

3. **Scrub (Optional):** For stubborn stains, gently scrub the area with the brush head while spraying.
4. **Extract Dirty Water:** Release the spray button and slowly pull the nozzle over the wet area, applying downward pressure to extract the dirty water. Repeat this step until no more dirty water is being extracted.
5. **Repeat:** Continue cleaning in small sections, overlapping slightly, until the entire area is clean.
6. **Monitor Tanks:** Periodically check the clean water tank and refill as needed. Empty the dirty water tank when it reaches the MAX fill line or when cleaning is complete.
7. **Power Off:** Once cleaning is finished, press the On/Off button to turn off the cleaner and unplug it from the outlet.




Image: The carpet cleaner being used to clean car upholstery, demonstrating its ease of use.



Image: Visual representation of the cleaner's effectiveness against dirt, unpleasant scents, and various stains.

Tips for Best Results

- Move the nozzle slowly over the surface to allow sufficient time for the solution to penetrate and for the suction to extract the dirty water.
- Do not over-wet the carpet or upholstery. Excessive moisture can lead to longer drying times and potential damage.
- For heavily soiled areas, a second pass or pre-treatment may be necessary.

MAINTENANCE

After Each Use

1. **Empty and Rinse Tanks:** Remove both the clean and dirty water tanks. Empty any remaining clean solution and dispose of the dirty water. Rinse both tanks thoroughly with clean water.
2. **Clean Nozzle/Brush Head:** Detach the cleaning nozzle/brush head and rinse it under running water to remove any debris or residue.
3. **Wipe Exterior:** Wipe down the exterior of the main unit with a damp cloth. Do not use harsh chemicals.

4. **Air Dry:** Allow all components to air dry completely before reassembling or storing.

Storage

Store the carpet cleaner in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the power cord and hose are neatly wrapped to prevent damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No spray from nozzle	Clean water tank empty; Nozzle clogged; Spray button not pressed.	Refill clean water tank; Clean nozzle; Ensure spray button is fully pressed.
Low or no suction	Dirty water tank full; Nozzle or hose clogged; Tank not properly sealed.	Empty dirty water tank; Clear any blockages in nozzle or hose; Ensure tanks are securely seated.
Water leaking	Tanks not properly seated; Damaged seal.	Check and reseal tanks; Contact customer support if seals are damaged.
Unit does not turn on	Not plugged in; Power outlet fault; On/Off button not pressed.	Ensure unit is plugged in; Test outlet with another device; Press On/Off button firmly.

SPECIFICATIONS

Feature	Value
Brand	POWELL
Model	POW-TARIJ-ZW
Power	450W
Suction Power	13000 PA
Clean Water Tank Capacity	1.8 Liters
Dirty Water Tank Capacity	1.1 Liters
Hose Length	1.2 Meters
Cable Length	5 Meters
Product Dimensions (L x W x H)	18.2 x 30.4 x 36.2 cm
Product Weight	3 kg
Power Source	Corded Electric

WARRANTY AND SUPPORT

This product comes with a manufacturer's warranty. For detailed warranty information, please refer to the

warranty card included in your product packaging or contact POWELL customer support.

If you encounter any issues or require assistance, please contact the retailer or the manufacturer's customer service department. Have your model number and purchase date ready when contacting support.