

Juskys 51516

Juskys Rope Garden Chairs (Set of 2) - Model 51516 Instruction Manual

Brand: Juskys | Model: 51516

1. SAFETY INFORMATION

Please read all safety instructions carefully before assembly and use. Retain this manual for future reference.

- **Maximum Weight Capacity:** Each chair has a maximum weight capacity of 160 kg. Do not exceed this limit to prevent damage or injury.
- **Assembly:** Ensure all components are correctly assembled and tightened according to the instructions. Improper assembly can lead to instability.
- **Placement:** Place the chairs on a stable, level surface to prevent tipping.
- **Maintenance:** Regularly inspect the chairs for any signs of wear, damage, or loose parts. Address any issues promptly.
- **Outdoor Use:** These chairs are designed for outdoor use. While weather-resistant, prolonged exposure to extreme weather conditions may affect their lifespan.

2. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- 2 x Juskys Rope Garden Chairs (disassembled)
- 2 x Seat Cushions
- 2 x Back Cushions
- 1 x Assembly Hardware Kit (screws, washers, Allen key)
- 1 x Instruction Manual

3. SETUP AND ASSEMBLY

The Jusky's Rope Garden Chairs are designed for straightforward assembly. No specialized tools or prior experience are required. Please follow these general steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the included parts diagram (if available) to identify each component (e.g., chair frame sections, legs, hardware).
3. **Assemble Frame:** Attach the chair legs to the main frame sections using the provided screws and Allen key. Ensure all connections are secure but do not overtighten initially.
4. **Attach Backrest/Seat:** Connect any separate backrest or seat components to the frame as instructed. The rope weaving is pre-attached.
5. **Final Tightening:** Once all parts are loosely assembled, place the chair upright on a level surface. Then, systematically tighten all screws to ensure stability.
6. **Add Cushions:** Place the seat and back cushions onto the assembled chairs.

Assembly Tip: It is recommended to have two people for assembly to ensure easier alignment of parts.



Image 1: Assembled Jusky's Rope Garden Chair in beige. This image illustrates the final appearance of the chair with its woven rope design, dark frame, and light-colored cushions.

4. OPERATION

The Juskys Rope Garden Chairs are designed for comfortable seating in outdoor environments.

- **Intended Use:** These chairs are suitable for relaxation, reading, and dining in garden, patio, or balcony settings.
- **Seating:** Sit centrally on the chair, distributing your weight evenly. Avoid standing on the chair or using it as a step stool.
- **Movement:** When moving the chairs, lift them rather than dragging them to prevent damage to the legs or the surface below.

5. MAINTENANCE AND CARE

Proper maintenance will extend the life and appearance of your Juskys Rope Garden Chairs.

- **Cleaning the Frame:** The powder-coated steel frame is scratch-resistant and low-corrosion. Clean with a damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals.
- **Cleaning the Rope Weaving:** The polypropylene rope weaving can be wiped clean with a damp cloth.
- **Cushion Care:** The cushions are made from 100% polyester and are removable for easy cleaning. Hand wash or machine wash according to the care label instructions (typically gentle cycle with cold water). Air dry thoroughly.
- **Weather Protection:** While weather-resistant and UV-resistant, it is recommended to store the chairs indoors or cover them during prolonged periods of harsh weather (heavy rain, snow, strong sun) to preserve their condition.
- **Fastener Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.

6. SPECIFICATIONS

Model Number	51516
Dimensions (L x W x H)	58 x 58 x 78 cm
Weight per Chair	Approximately 5.4 kg (Total package weight 10.8 kg for 2 chairs)
Maximum Load Capacity per Chair	160 kg
Frame Material	Powder-coated Alloy Steel
Rope Weaving Material	Polypropylene (PP)
Cushion Cover Material	100% Polyester
Cushion Filling Material	Polyester
Seat Height	48 cm
Color	Beige (Rope and Cushions), Black (Frame)
Assembly Required	Yes

Recommended Use	Outdoor
-----------------	---------

7. TROUBLESHOOTING

This section addresses common issues you might encounter.

- **Chair feels wobbly after assembly:** Ensure all screws are fully tightened. If the issue persists, disassemble and reassemble, making sure all parts are correctly aligned before final tightening.
- **Missing parts:** Refer to the 'Package Contents' section. If any parts are missing, contact customer support with your purchase details.
- **Cushions appear flattened:** Allow cushions to air out and fluff up after unpacking. Over time, cushion filling may compress; regular fluffing can help maintain their shape.
- **Rust spots on frame:** While the frame is powder-coated for corrosion resistance, prolonged exposure to moisture or damage to the coating can lead to rust. Clean any rust spots with a rust remover and apply a protective coating if necessary.

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to your purchase documentation or contact the retailer where you purchased the Juskys Rope Garden Chairs.

Keep your proof of purchase for any warranty claims.