

IZHWSZYH

Generic DIY Wooden Dollhouse Kit with LED Lights & Music Movement (Model IZHWSZYH) Instruction Manual

[Introduction](#) [Safety Information](#) [Package Contents](#) [Setup & Assembly](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty](#) [Support](#)

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Generic DIY Wooden Dollhouse Kit with LED Lights & Music Movement, Model IZHWSZYH. This kit allows you to construct a miniature European Retro Style Romantic Villa, complete with intricate details, LED lighting, and a music movement. Please read these instructions carefully before beginning assembly to ensure a successful and enjoyable building experience.



Figure 1: Fully assembled DIY Wooden Dollhouse Kit with LED lights illuminated.

2. SAFETY INFORMATION

Please observe the following safety precautions during assembly and operation of the dollhouse kit:

- **Small Parts:** This kit contains many small parts which can be a choking hazard. Keep all components out of reach of small children.
- **Sharp Objects:** Assembly may require the use of sharp tools such as scissors or craft knives (not included). Handle these tools with care to prevent injury.
- **Adhesives:** Glue (not included) is required for assembly. Use adhesives in a well-ventilated area and follow the manufacturer's safety instructions.
- **Batteries:** The LED lighting system requires batteries (not included). Ensure correct polarity when inserting batteries. Do not mix old and new batteries, or different types of batteries. Remove batteries if the dollhouse will not be used for an extended period.
- **Electrical Components:** Handle LED lights and wiring carefully. Do not expose to water or excessive moisture.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present. The kit includes various materials for constructing the miniature villa:

- Pre-cut wooden pieces for structural elements.
- Fabric pieces for upholstery and decorations.
- Beads and other small decorative items.
- Miniature tree models and dried flowers for landscaping.
- Paper components for various details.
- LED lighting components with battery box switch.
- Music movement mechanism.
- Instruction manual (this document).

Note: Batteries, glue, and scissors are **not included** due to customs policy. You will need to prepare these items separately.

PRODUCT INFO

Product Name: **Miniature Blue Waltz**

Product Weight: **350g/0.77lb**

Product Size: **12.8×9.4×11cm/5.03×3.7×4.33in** Material: Wood, Paper, Cloth, ect.

Material



Please Note That The Size Is Small



Because glue, paint, battery, scissors can not be transported, so our products are not included, please buy it yourself.

Figure 2: Overview of kit components and product dimensions.

4. SETUP & ASSEMBLY

Assembly of this DIY dollhouse kit requires patience and attention to detail. Follow the step-by-step instructions provided in the included manual (referencing the physical manual that comes with the kit for specific diagrams and cutting guidelines).

4.1 Required Tools (Not Included)

- Craft glue (e.g., wood glue, quick-drying adhesive suitable for miniature crafts)
- Scissors or craft knife
- Ruler
- Tweezers (recommended for small parts)
- Batteries for LED lights (type specified in the kit's physical manual)

4.2 Assembly Steps

1. **Preparation:** Unpack all components and organize them. Carefully review the cutting guidelines and assembly diagrams in the physical instruction manual. Do not discard any accessories before completing the entire assembly, as this may lead to insufficient parts.
2. **Structural Assembly:** Begin by assembling the main wooden structure of the dollhouse, following the numbered steps and diagrams. Use glue sparingly but effectively to ensure strong bonds. Allow sufficient drying time for each section before proceeding.
3. **Interior & Exterior Details:** Once the main structure is stable, proceed with adding interior furniture, fabric elements, and exterior decorations such as fences, trees, and garden accessories. Pay close attention to the placement of each miniature item.
4. **LED Lighting Installation:** Install the LED lights and wiring according to the diagrams. Ensure all connections are secure. The battery box will typically be placed in an accessible, discreet location.
5. **Music Movement Integration:** Install the music movement mechanism as instructed.
6. **Final Touches:** Add any remaining decorative elements, such as beads or dried flowers, to complete your miniature villa.



Figure 3: Examples of detailed miniature accessories like the piano and telescope.

5. OPERATION

5.1 LED Lights

To activate the LED lights, ensure batteries are correctly installed in the battery box. Locate the switch on the battery box and slide it to the "ON" position. The miniature villa will illuminate, creating a warm and inviting display. To turn off the lights, slide the switch to the "OFF" position.

5.2 Music Movement

The dollhouse includes a music movement that plays the tune "Sky City." To activate the music, locate the winding key or switch associated with the music mechanism (refer to your physical manual for exact location and operation).

Turn the key or activate the switch to enjoy the melody.

6. MAINTENANCE

- **Cleaning:** Gently dust the dollhouse and its components with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, as these can damage the wood, fabric, or painted surfaces.
- **Storage:** Store the dollhouse in a dry, cool place away from direct sunlight and excessive humidity to prevent warping of wooden parts or fading of colors.
- **Battery Replacement:** If the LED lights dim or stop working, replace the batteries in the battery box. Ensure to use the correct battery type and dispose of old batteries responsibly.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
LED lights do not turn on.	<ul style="list-style-type: none">◦ Batteries are dead or incorrectly inserted.◦ Battery box switch is off.◦ Loose wiring connection.	<ul style="list-style-type: none">◦ Check and replace batteries, ensuring correct polarity.◦ Ensure the switch on the battery box is in the "ON" position.◦ Inspect wiring for secure connections.
Music movement does not play.	<ul style="list-style-type: none">◦ Mechanism not fully wound.◦ Mechanism is jammed or damaged.	<ul style="list-style-type: none">◦ Ensure the music mechanism is fully wound (if applicable).◦ Gently check for obstructions. If damaged, contact support.
Missing or damaged parts during assembly.	<ul style="list-style-type: none">◦ Oversight during unpacking.◦ Manufacturing defect or shipping damage.	<ul style="list-style-type: none">◦ Double-check all packaging materials.◦ Contact customer support with details of the missing/damaged part.

If you encounter issues not listed here or require further assistance, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Product Name	DIY Wooden Dollhouse Kit with LED Lights & Music Movement
Model Number	IZHWSZYHH
Brand	Generic
Finished Product Size (approx.)	25.5 cm (L) x 34 cm (W) x 29 cm (H) (without dust cover) 25.5 cm (L) x 34 cm (W) x 31 cm (H) (with dust cover)
Weight (approx.)	2.2 KG (without dust cover), 2.8 KG (with dust cover)
Light Source	LED light with battery box switch
Music	"Sky City" melody
Main Materials	Wood, cloth, beads, tree model, paper, dried flowers, etc.
Assembly Time (approx.)	3 to 5 days (depending on individual pace)
Recommended Age	Adults and Teens (Manufacturer Minimum Age: 36 months, Maximum Age: 216 months)

9. WARRANTY INFORMATION

Specific warranty details for this product are typically provided with the product packaging or can be obtained directly from the seller. Please retain your proof of purchase for any warranty claims. In general, products are covered against manufacturing defects for a limited period. Damage resulting from improper assembly, misuse, or neglect is not covered.

10. CUSTOMER SUPPORT

For any questions, missing parts, or assistance with assembly or operation, please contact the seller directly through the platform where the product was purchased. Provide your order number and a detailed description of your inquiry for prompt assistance.

Seller: Tai Yuan Hao Ya Ya Kua Jing Dian Shang You Xian Gong Si

ASIN: B0F54HTZ4Q