Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ChooChoo End Table

ChooChoo 24-Inch End Table with 2-Tier Storage Shelf Instruction Manual

Model: End Table

Introduction | Product Overview | Assembly Instructions | Usage Scenarios | Care & Maintenance | Troubleshooting | Warranty & Support

Introduction

This manual provides detailed instructions for the assembly, usage, and maintenance of your ChooChoo 24-Inch End Table. Designed for versatility and durability, this end table features two spacious shelves for ample storage and a sleek square design with decorative X-frame sides, complementing various interior styles including modern, farmhouse, and transitional. Constructed from high-quality MDF with an eco-friendly, water-based paint coating, it offers a strong and reliable structure for everyday use.
Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Product Overview

The ChooChoo End Table is a functional and stylish furniture piece designed to enhance any room. Its robust construction and thoughtful design make it suitable for various applications.

Key Features:

- **Ample Storage:** Two spacious tiers provide convenient storage for books, remotes, decor, and other essentials.
- **Durable Construction:** Made from high-quality Engineered Wood (MDF) with an eco-friendly, water-based paint finish.
- **Stable Design:** Features a sturdy X-frame structure for enhanced stability.
- **Versatile Style:** Its timeless design seamlessly integrates with modern, farmhouse, and transitional decor.

Specifications:

Attribute	Detail
Brand	ChooChoo
Model	End Table
Product Dimensions	23.62"D x 23.62"W x 23.62"H
Item Weight	25.13 Pounds
Frame Material	Engineered Wood
Color	Oak




Image: ChooChoo End Table with detailed dimensions, showing 23.6" (60cm) for depth, width, and height, and 18.5" (47cm) for the shelf height.

Assembly Instructions

Assembly of the ChooChoo End Table is designed to be straightforward. All necessary hardware is included, except for a screwdriver. Please follow the steps below carefully.

Tools Required:

- Phillips Head Screwdriver (not included)

Assembly Steps:

1. **Step 1: Prepare Side Panels**
   Insert the wooden dowels into the designated holes on the side panels (parts with X-frame design). Ensure they are securely in place.
2. **Step 2: Attach Cam Bolts**
   Screw the cam bolts into the pre-drilled holes on the side panels. Turn gently until snug, do not overtighten.
3. **Step 3: Prepare Shelf Board**
   Insert wooden dowels into the four sides of the bottom shelf board (labeled as part 4 in some instructions). Then, attach four cam bolts into the corresponding holes on the shelf board, tightening them down.
4. **Step 4: Attach Side Panels to Shelf**
   Align the side panels with the bottom shelf board, ensuring the cam bolts and dowels fit into their respective holes. Secure by tightening the cam locks with a Phillips head screwdriver.
5. **Step 5: Attach Remaining Side Panel**
   Repeat Step 4 for the remaining side panel, attaching it to the bottom shelf and securing with cam locks.
6. **Step 6: Insert Top Support Bars**
   Place the two top support bars (part 3) into the top slots of the assembled frame. These will hold the structure together temporarily.
7. **Step 7: Secure Top Support Bars**
   Insert the long screws with the E-bolts into the corners of the top support bars, securing them to the side panels. Use a flat-head screwdriver to hold the E-bolt while tightening with a Phillips head screwdriver.
8. **Step 8: Prepare Top Board**
   Insert cam screws into the underside of the top board. Ensure they are straight and secure. There will be eight of these.
9. **Step 9: Attach Top Board**
   Carefully place the top board onto the assembled frame, aligning the cam screws with the cam locks. Secure by tightening the cam locks with a Phillips head screwdriver until the top is firmly attached.

Assembly Video (Dark Brown Variant):

Your browser does not support the video tag.

Video: A detailed step-by-step assembly guide for the ChooChoo End Table in a dark brown finish. The video demonstrates inserting dowels, attaching cam bolts, and securing panels to form the table structure.

Assembly Video (Light Wood/White Variant):

Your browser does not support the video tag.

Video: A step-by-step assembly demonstration for the ChooChoo End Table in a light wood and white finish. This video highlights the ease of assembly using provided hardware.

Usage Scenarios

The ChooChoo End Table is designed for versatility and can be utilized in various settings throughout your home or office.

Living Room Side Table:

Place next to a sofa or armchair to hold beverages, books, or decorative items. The two-tier design offers convenient storage for remotes or magazines.



Image: The ChooChoo End Table in an oak finish, positioned next to a sofa in a living room, holding a lamp, books, and a woven basket on the lower shelf.

Bedroom Nightstand:

Ideal as a nightstand, providing space for a lamp, alarm clock, and personal items. The lower shelf can store books or a small basket.



Image: The ChooChoo End Table serving as a nightstand beside a bed, holding a lamp, a glass of water, and books, with a woven basket on the lower shelf.

Office Printer Stand or Accent Table:

Its sturdy top can support a printer, while the lower shelf can store paper or office supplies. It also functions as a stylish accent table.



Image: The ChooChoo End Table in an office setting, holding a printer on its top surface and a woven basket with documents on the lower shelf.

Mini Fridge Stand:

The robust design makes it suitable for holding a mini-fridge, providing a convenient beverage station in a living area or office.



Image: The ChooChoo End Table supporting a mini-fridge on its top, with bottles and a decanter on a tray on the lower shelf, positioned between two sofas.

Product Overview Video:

Your browser does not support the video tag.

Video: A promotional video showcasing the ChooChoo End Table's versatility in various settings, including living rooms, as a mini-fridge stand, and as a printer table. It also highlights different color options.

Care and Maintenance

- **Cleaning:** Wipe clean with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can

damage the finish.

- **Spills:** Blot spills immediately with a clean, dry cloth to prevent staining.
- **Heat and Moisture:** Use coasters under drinks and hot pads under warm items to protect the surface from heat and moisture damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Moving:** When moving the table, lift it rather than dragging to prevent damage to the legs and frame.

Troubleshooting

- **Wobbly Table:**
  - Ensure all screws and cam locks are tightened securely.
  - Check that the table is placed on a flat, even surface.
- **Missing Parts:**
  - Carefully review the parts list in the assembly instructions. If any parts are missing, contact ChooChoo customer support.
- **Difficulty Assembling:**
  - Re-read the instructions and watch the assembly videos provided. Ensure all components are oriented correctly before tightening.
  - Do not force parts together; if they don't fit, recheck the orientation.

Warranty and Support

ChooChoo products are manufactured with quality and durability in mind. For specific warranty details, please refer to the documentation included with your purchase or visit the official ChooChoo website.
If you encounter any issues or have questions regarding your ChooChoo End Table, please contact our customer service team for assistance. Our friendly team is ready to help.
Contact Information:

Visit the ChooChoo Store on Amazon

Refer to your product packaging for direct customer service contact details.

© 2023 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F59427MG

More documents and user manuals: **https://manuals.plus/**