

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [HP](#) /
- > [HP 17.3 inch Touchscreen Laptop \(Model 17-cn4065cl\) User Manual](#)

## HP 17-cn4065cl

# HP 17.3 inch Touchscreen Laptop User Manual

Model: 17-cn4065cl

## INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your HP 17.3 inch Touchscreen Laptop, model 17-cn4065cl. Please read these instructions carefully to ensure proper use and longevity of your device.



## 1. SETUP

### 1.1 Unboxing and Initial Inspection

Carefully remove all components from the packaging. Verify that all items listed in the "What's in the box" section are present and undamaged.



Image: Contents of the HP laptop box, including the laptop, 45W Smart AC power adapter, and setup instructions.

#### What's in the Box:

- HP 17.3 inch Touchscreen Laptop
- 45 W Smart AC power adapter
- Setup instructions

### 1.2 Powering On and Initial Configuration

1. Connect the power adapter to the laptop and a power outlet.
2. Open the laptop lid and press the power button.
3. Follow the on-screen prompts to complete the Windows 11 Pro setup, including language selection, network connection, and user account creation.

### 1.3 Charging the Battery

For optimal battery life, fully charge the laptop before its first use. The HP Fast Charge feature allows for rapid charging.

## 2. OPERATING INSTRUCTIONS

### 2.1 Basic Interaction

Your HP laptop features a 17.3-inch HD+ touchscreen display, a full-size backlit keyboard with a numeric keypad, and a precision touchpad. Use the touchscreen for direct interaction, the keyboard for typing (with adjustable backlight), and the touchpad for cursor control and gestures.

# Power through



Multitasking feels easy and fast with an Intel® processor, powerful graphics and Wi-Fi 6.



Image: HP laptop screen showing multiple applications, including YouTube and Microsoft Excel, demonstrating multitasking capabilities.

## 2.2 Windows 11 Pro and Software

The laptop comes pre-installed with Windows 11 Pro. Microsoft Office Pro is also included for lifetime use, providing applications such as Word, Excel, and PowerPoint.



Image: HP laptop with Intel Core 7 branding, highlighting the processor.


## 2.3 Connectivity

The laptop supports Wi-Fi 6 for wireless internet and Bluetooth 5.3 for connecting wireless peripherals. Physical ports include:

- 2 x USB Type-A ports
- 1 x USB Type-C port
- 1 x HDMI 1.4b port
- 1 x Headphone/Microphone Combo jack

- 1 x AC Smart Pin for power adapter

# Thoughtfully crafted



Newly engineered lift-hinge enables ease of movement and comfort while you type.



Image: Side profile of the HP laptop, illustrating the engineered lift-hinge and available ports.

## 2.4 Battery Management

The laptop offers up to 10 hours and 45 minutes of video playback or 7 hours and 15 minutes of mixed usage. To extend battery life, adjust screen brightness, close unused applications, and utilize power-saving modes in Windows settings.

## 3. MAINTENANCE

### 3.1 Cleaning the Laptop

- Use a soft, lint-free cloth slightly dampened with water or a screen cleaner for the display.
- For the keyboard and chassis, use a soft cloth. Avoid harsh chemicals.
- Periodically use compressed air to clear dust from vents.

## 3.2 Software Updates

Regularly check for and install Windows updates and HP driver updates to ensure optimal performance and security. Access Windows updates via *Settings > Windows Update*.

## 3.3 Storage Management

Your laptop is equipped with a 4 TB SSD. Regularly manage your files, uninstall unused applications, and consider cloud storage to maintain free space and system performance.

## 4. TROUBLESHOOTING

---

If you encounter issues with your laptop, refer to the following common troubleshooting steps:

- **No Power:** Ensure the power adapter is securely connected and the outlet is functional. Try a different outlet.
- **Display Issues:** Restart the laptop. If using an external monitor, check cable connections.
- **Connectivity Problems:** Restart your Wi-Fi router. Check Wi-Fi and Bluetooth settings in Windows to ensure they are enabled.
- **Slow Performance:** Close unnecessary applications. Check for background processes in Task Manager. Ensure sufficient free storage space.

For more complex issues, consult the HP support website or contact HP customer service.

## 5. SPECIFICATIONS

---

The following table details the technical specifications of the HP 17.3 inch Touchscreen Laptop (Model 17-cn4065cl):



## Bigger screen, smaller footprint





Image: Visual overview of key specifications including processor, graphics, memory, and storage.

Feature	Detail
<b>Model</b>	17-cn4065cl
<b>Operating System</b>	Windows 11 Pro
<b>Processor</b>	Intel 10-Core 7 150U (Up to 5.4 GHz)
<b>Graphics</b>	Integrated Intel Graphics
<b>Display</b>	17.3 inch HD+ (1600 x 900) Touchscreen, Anti-Glare, 250 Nits
<b>RAM</b>	64 GB DDR4
<b>Storage</b>	4 TB PCIe NVMe M.2 SSD

<b>Feature</b>	<b>Detail</b>
<b>Wireless Connectivity</b>	Wi-Fi 6, Bluetooth 5.3
<b>Ports</b>	2x USB Type-A, 1x USB Type-C, 1x HDMI 1.4b, 1x Headphone/Microphone Combo, 1x AC Smart Pin
<b>Keyboard</b>	Full-Size Backlit with Numeric Keypad
<b>Webcam</b>	720p Privacy Camera with Physical Shutter
<b>Audio</b>	HD Audio with Stereo Speakers, Integrated Dual Array Digital Microphones
<b>Battery Life</b>	Up to 10 hours 45 minutes video playback; Up to 7 hours 15 minutes mixed usage
<b>Dimensions (LxWxH)</b>	15.78 x 10.15 x 0.81 inches
<b>Weight</b>	4.84 lbs

# Portable performance



Up to 7 hours & 15 minutes mixed usage<sup>1</sup>  
Up to 10 hours & 45 minutes video playback<sup>1</sup>



4.84 lb

<sup>1</sup>Battery life tested by HP using MobileMark 25 benchmarking. Battery life will vary depending on various factors including product model, configuration, loaded applications, features, use, wireless functionality, and power management settings. The maximum capacity of the battery will naturally decrease with time and usage. See [bapco.com/products/mobilemark-25/](http://bapco.com/products/mobilemark-25/) for additional details.

Image: Diagram illustrating the dimensions (width, depth, height) and estimated battery life of the HP laptop.

## 6. WARRANTY AND SUPPORT

### 6.1 Manufacturer's Warranty

Your HP laptop is covered by a manufacturer's warranty. The duration and terms of this warranty are provided by HP. Please note that if the product has undergone modifications by a reseller, the original manufacturer's seal may have been opened for testing and installation of upgrades to meet advertised specifications. This process is intended to ensure the product meets its stated configuration.

For specific warranty details and registration, please visit the official HP support website or refer to the warranty documentation included with your product.

### 6.2 Customer Support

For technical assistance, warranty claims, or service inquiries, please contact HP customer support through their official website or the contact information provided in your product documentation.

