

Kuulaa KL-YD71

Kuulaa Ultra Slim MagSafe Power Bank KL-YD71 User Manual

Model: KL-YD71

1. PRODUCT OVERVIEW

The Kuulaa Ultra Slim MagSafe Power Bank (Model KL-YD71) is a compact and lightweight portable charger designed for convenience and efficiency. With a 5000 mAh capacity, it provides reliable power for your mobile devices, featuring both magnetic wireless charging and wired fast charging capabilities. Its ultra-slim design makes it ideal for travel and everyday use.



Image: The Kuulaa Power Bank highlighting its ultra-slim profile (6.9mm) and light weight (110g).

Key Features:

- **Ultra-Slim & Lightweight:** Weighs approximately 110 grams and is 6.9mm thin, designed for portability.
- **Dual Charging Methods:** Supports 7.5W magnetic wireless charging and 20W USB-C wired fast charging.
- **Strong Magnetic Attachment:** Features a 10N super-strong magnet for secure attachment to compatible devices.
- **Advanced Safety Protections:** Built-in mechanisms protect against overcharging, over-discharging, and overheating.

- **Sleek Design:** A simple, black design with an aluminum alloy shell for durability and aesthetic appeal.

2. PACKAGE CONTENTS

Please check the package for the following items:

- Kuulaa 5000mAh Magnetic Power Bank (Model KL-YD71) x 1
- Leather Organizer Pouch (85x125mm) x 1
- USB-A to USB-C Charging Cable x 1
- User Manual x 1

What You Get

- 5000mAh Magnetic Power Bank *1
- Leather Organizer Pouch (85x125mm)*1
- USB A to C Cable *1
- Manual *1



Image: All items included in the product package.

3. SAFETY INSTRUCTIONS

To ensure safe operation and prolong the lifespan of your Kuulaa Power Bank, please read and follow these safety guidelines:

- Do not expose the power bank to extreme temperatures (hot or cold), direct sunlight, or high humidity.
- Avoid dropping, disassembling, or attempting to repair the device yourself. This may void the warranty and pose safety risks.
- Keep the power bank away from water and other liquids.
- Use only the provided or certified charging cables and adapters.
- Do not place metal objects or magnetic cards between the power bank and your device during wireless charging, as this can interfere with charging or damage the power bank.
- If the power bank becomes excessively hot, emits an odor, or shows any signs of damage, discontinue use immediately.
- Store the power bank in a cool, dry place when not in use.

Skin Friendly Touch Design Aluminum Alloy Shell



Image: Overview of the power bank's superior safety features.

4. SETUP AND CHARGING THE POWER BANK

Charging the Power Bank:

1. Connect the provided USB-A to USB-C cable to the USB-C port on the power bank.
2. Plug the USB-A end of the cable into a compatible USB wall adapter (not included) or a computer's USB port.
3. The LED indicators on the power bank will illuminate to show the charging status. When all LEDs are solid, the power bank is fully charged.




Image: Power bank charging via USB-C.

Checking Battery Level:

Press the power button once to view the current battery level indicated by the LED lights.

- 1 LED: 0-25%
- 2 LEDs: 26-50%
- 3 LEDs: 51-75%
- 4 LEDs: 76-100%



Lightweight & Portable

Fits in your pocket or bag

Image: LED indicators displaying battery charge status.

5. OPERATING INSTRUCTIONS

Magnetic Wireless Charging:

1. Ensure your device is compatible with MagSafe (iPhone 12 series and newer) or has a MagSafe-compatible case.
2. Align the power bank with the back of your iPhone. The strong magnets will automatically snap it into place.
3. Wireless charging will begin automatically. The LED indicators on the power bank may show charging activity.
4. **Note:** For optimal magnetic attachment and charging efficiency, use without a case or with a MagSafe-compatible case. Non-magnetic phone cases are not supported.



Image: Magnetic attachment for wireless charging.

Wired Charging (USB-C PD 20W):

1. Connect one end of a USB-C to USB-C cable (or the provided USB-A to USB-C cable with an appropriate adapter) to the USB-C port on the power bank.
2. Connect the other end of the cable to your device's charging port.
3. The power bank will automatically detect and begin charging your device.

Seamlessly Attached

Strong Built-in magnets snap your power bank right into place




Image: Wired charging via USB-C port.

6. COMPATIBILITY

The Kuulaa Ultra Slim MagSafe Power Bank is compatible with:


- iPhone 12, 13, 14, 15, and 16 Series (for magnetic wireless charging).
- Other devices that support USB-C charging (for wired charging).

Important Note for Magnetic Charging:

- Magnetic charging works best without a phone case or with an official MagSafe case/MagSafe-compatible case.
- Non-magnetic phone cases are **not** supported for magnetic attachment and wireless charging.
- Not recommended for use with iPhone 12 mini and iPhone 13 mini due to size.

Compatible with iPhone 12/13/14/15/16 Series

Match with MagSafe Cases



iPhone 12-16 Series



iPhones with MagSafe
Official/ MagSafe Cases



Image: Compatibility guide for MagSafe cases and iPhone models.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the power bank. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the power bank in a cool, dry environment, away from direct sunlight and extreme temperatures.
- **Battery Care:** To maintain battery health, fully charge the power bank at least once every three months if not in regular use.

8. TROUBLESHOOTING

- **Power Bank Not Charging:**
 - Ensure the charging cable is securely connected to both the power bank and the power source.
 - Verify that the wall adapter or USB port is functional.
 - Try using a different USB-C cable or power adapter.
- **Device Not Charging Wirelessly:**
 - Check if your device is MagSafe compatible (iPhone 12 series or newer).
 - Ensure there are no foreign objects between the power bank and your device.
 - Remove any non-MagSafe compatible phone cases.
 - Verify the power bank has sufficient charge.
- **Weak Magnetic Attachment:**
 - Ensure your phone case is MagSafe compatible or remove the case entirely.
 - Clean the magnetic surfaces on both the power bank and your device/case.
- **Slow Charging:**
 - For wired charging, ensure you are using a 20W PD compatible wall adapter for fast charging.
 - For wireless charging, ensure proper alignment and that no foreign objects are interfering.
 - Check the power bank's charge level; charging speed may decrease at very low battery levels.

9. SPECIFICATIONS

Feature	Detail
Model Number	KL-YD71
Battery Capacity	5000 mAh
Product Dimensions	4.05 x 2.67 x 0.28 inches
Item Weight	5.3 ounces (approx. 150g)
Wireless Charging Output	7.5W (Max)
Wired Charging Output (USB-C)	20W Power Delivery (PD) Max
Connector Type	USB Type-C
Special Features	Ultra-Slim, Magnetic, Wireless Charging, Fast Charging
Manufacturer	Shenzhen Kula Technology Co., Ltd.

10. WARRANTY AND SUPPORT

The Kuulaa Power Bank KL-YD71 comes with a 24-hour warranty to ensure your peace of mind. If you encounter any issues or have questions regarding your product, please contact our customer support team.

Customer Support:

- For assistance, please visit the official Kuulaa website or contact the seller directly through your purchase platform.
- Please have your model number (KL-YD71) and purchase details ready when contacting support.