HOGOKIDS HG1016

HOGOKIDS HG1016 Gingerbread House Building Set Instruction Manual

1. Product Overview

The HOGOKIDS HG1016 Gingerbread House Building Set allows for the construction of a detailed Christmas-themed snow village. This set includes approximately 1477 pieces and features a two-story cottage design with decorative elements such as a snow-covered roof, candy cane columns, gingerbread figures, and Christmas trees. The completed model can be configured into three distinct styles without requiring complete disassembly, offering versatile display options.



Image: The HOGOKIDS HG1016 Gingerbread House Building Set, illustrating the primary assembled model and two alternative configurations.

A key feature of this building set is the integrated lighting kit, designed to illuminate the gingerbread house and enhance its festive appearance. The set is intended for individuals aged 6 years and up, providing an engaging building experience.

2. Important Safety Information

WARNING: CHOKING HAZARD - Small Parts. This product contains small parts and is not suitable for children under 3 years of age. Adult supervision is required during assembly and play to prevent choking hazards.

WARNING: THIS PRODUCT CONTAINS A BUTTON BATTERY. If swallowed, a lithium button battery can cause severe or fatal injuries within 2 hours. Keep batteries out of reach of children. If you think batteries may have been swallowed or placed inside any part of the body, seek immediate medical attention.



Image: Product information panel detailing safety warnings, including choking hazard and button battery risks, alongside manufacturer contact details.

3. Assembly Instructions

Follow the included full-color instruction manual for step-by-step guidance. The building blocks are organized into numbered bags to correspond with the assembly stages outlined in the manual. Ensure all pieces are firmly connected during construction.

3.1. Building Process

1. **Unpack Components:** Carefully open the packaging and sort the numbered bags of building blocks.
2. **Review Instructions:** Familiarize yourself with the instruction manual before beginning assembly.
3. **Follow Steps Sequentially:** Assemble the model by following the numbered steps in the manual. Each step provides detailed illustrations for clarity.
4. **Ensure Firm Connections:** Press each block firmly into place to ensure a stable and secure structure.



Image: The building set showcasing its three distinct transformable styles, which can be achieved without full disassembly.

3.2. Multiple Configurations

This set is designed to be built in three unique styles. The instruction manual provides guidance on how to achieve these different configurations. A clever quick-swap design allows for changes between styles without requiring complete disassembly of the entire model.



Image: Close-up views of the gingerbread house's interior and exterior details, emphasizing the modularity for different styles.

4. Operating Instructions

4.1. Lighting System

The Gingerbread House includes a lighting kit to create an illuminated display. Follow the specific instructions within the manual for installing the lighting components and activating them. Ensure batteries are correctly inserted according to polarity markings.



Image: A visual comparison of the gingerbread house with its internal lighting system turned off and on, illustrating the warm glow.

The lighting system is designed to add an enchanting glow, making the model suitable for display in various settings, particularly during the evening or in dimly lit environments.

5. Care and Maintenance

To maintain the appearance and integrity of your HOGOKIDS Gingerbread House Building Set, follow these guidelines:

- **Cleaning:** Gently wipe the assembled model with a soft, slightly damp cloth. Avoid using harsh chemicals,

abrasive cleaners, or excessive water, as these can damage the plastic components or electrical parts.

- **Storage:** Store the building set in a cool, dry place away from direct sunlight and extreme temperatures. Prolonged exposure to sunlight can cause colors to fade.
- **Battery Replacement:** If the lighting system dims or stops working, replace the button battery according to the instructions provided in the assembly manual. Always dispose of used batteries responsibly.

6. Troubleshooting Guide

This section addresses common issues that may arise during assembly or use.

- **Missing Pieces:** If you discover any missing pieces, please contact HOGOKIDS customer support directly using the contact information provided in Section 7.
- **Lights Not Working:**
  - Check that the button battery is correctly inserted with the correct polarity.
  - Ensure the battery is not depleted and replace it if necessary.
  - Verify all electrical connections for the lighting kit are secure and properly seated.
- **Loose Connections/Unstable Structure:** Ensure that all building blocks are pressed firmly together. Some pieces may require additional pressure to snap into place securely.

7. Product Specifications

Specification	Detail
Brand	HOGOKIDS
Model Number	HG1016
Product Name	Building Blocks (Gingerbread House)
Number of Pieces	Approximately 1477
Recommended Age	6 years and up
Product Material	Plastic
Product Dimensions (approx.)	32cm x 20cm x 19.5cm (12.6 x 7.9 x 7.7 inches) for one configuration
Item Weight	3.34 pounds



Image: Dimensional specifications for the HOGOKIDS Gingerbread House in different assembled forms.

8. Warranty and Customer Support

HOGOKIDS is committed to providing high-quality products. For any inquiries, missing parts, or support needs, please contact our customer service team.

- **Manufacturer:** Shenzhen C-tronics Co., Ltd
- **Email:** info@hogokidstoys.com
- **Website:** www.hogokidstoys.com
- **Address:** 5#A602, Zone A, Bao'an Internet Industrial Park, Baoyuan Road, Bao'an, Shenzhen, 518102, China

Please retain your proof of purchase for any warranty claims or support requests.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question