

[Manuals.plus](#) /

› [ARVIDSSON](#) /

› ARVIDSSON 500ml Essential Oil Diffuser Instruction Manual (Model 200024BL)

ARVIDSSON 200024BL

ARVIDSSON 500ml Essential Oil Diffuser Instruction Manual

Model: 200024BL

INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your ARVIDSSON 500ml Essential Oil Diffuser. Please read this manual thoroughly before operation and retain it for future reference.

IMPORTANT SAFETY INFORMATION

- Avoid direct skin contact with undiluted essential oils.
- Keep out of reach of children and pets.
- Ensure proper ventilation during use.
- Automatic shut off when the water runs out, ensuring safety and convenience.

SETUP GUIDE

1. **Unpack the Diffuser:** Carefully remove all components from the packaging.



Image: The ARVIDSSON 500ml Essential Oil Diffuser in Red, showcasing its metallic Moroccan design.

2. **Place the Diffuser:** Position the diffuser on a flat, stable surface away from direct sunlight, heat sources, and electronic devices.
3. **Remove the Cover:** Gently lift the outer metallic cover and then the inner lid to access the water tank.

Your browser does not support the video tag.

Video: Demonstrates how to open the diffuser and fill it with water and essential oils. This video is provided by Mats Technology (Seller).

4. **Fill the Water Tank:** Using a measuring cup, fill the water tank with clean tap water up to the maximum fill line (500ml). Do not overfill.
5. **Add Essential Oils:** Add 5-10 drops of your preferred essential oil directly into the water tank. Adjust the amount based on desired scent intensity.
6. **Replace Covers:** Securely place the inner lid back on, followed by the metallic outer cover.
7. **Connect Power:** Plug the power adapter into the diffuser's power port and then into a wall outlet.

OPERATING INSTRUCTIONS

The diffuser features intuitive controls for mist, timer, and lighting.



Image: Close-up of the diffuser's base showing the 'POWER', 'TIMER', and 'LIGHT' buttons.

Mist Control:

- **POWER Button:** Press once to turn on continuous mist. Press again to cycle through mist modes (continuous, intermittent). Hold to turn off.
- **Mist Density:** The diffuser offers strong or weak mist output. Refer to the remote control for direct adjustment.

Timer Settings:

- **TIMER Button:** Press to set the operating time. Available settings include 1 hour, 3 hours, and 6 hours. The diffuser will automatically shut off when the selected time expires or when water runs out.
- The 500ml capacity allows for extended misting up to 12-15 hours depending on the mist mode.

Light Control:

- **LIGHT Button:** Press once to turn on the 7-color LED mood light. Press again to cycle through individual colors or set it to a color-changing mode. Hold to turn off the light.
- The color-changing mood light creates a peaceful ambiance.



Image: The diffuser displaying its color-changing mood light feature, illuminating the Moroccan design.

Remote Control:

The diffuser comes with a remote control for convenient operation from a distance. Use the remote to power on/off, adjust mist mode (intermittent/continuous), set timing, change mist output (big/small), and control light colors.

MAINTENANCE

Regular cleaning ensures optimal performance and longevity of your diffuser.

1. **Power Off and Unplug:** Before cleaning, always ensure the diffuser is turned off and unplugged from the power outlet.

- 2. **Empty Water Tank:** Remove the covers and carefully pour out any remaining water from the tank.
- 3. **Clean the Water Tank:** Wipe the inside of the water tank with a soft cloth. For stubborn residue, use a cotton swab dipped in white vinegar to gently clean the ultrasonic plate located at the bottom of the tank. Rinse thoroughly with clean water.
- 4. **Clean the Covers:** Wipe the metallic outer cover and inner lid with a soft, damp cloth.
- 5. **Dry Thoroughly:** Ensure all parts are completely dry before reassembling or storing the diffuser.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No mist or low mist output	Insufficient water, clogged ultrasonic plate, or improper cover placement.	Ensure water is at the correct level. Clean the ultrasonic plate. Verify covers are securely in place.
Diffuser not turning on	No power, water level too low (auto-shutoff activated), or loose connection.	Check power connection. Refill water tank. Ensure power adapter is firmly connected.
Unusual noise	Water level too low or diffuser not on a flat surface.	Add water. Place diffuser on a stable, flat surface.

SPECIFICATIONS

Brand: ARVIDSSON

Model Name: 500ml - Red Bronze (Model Number: 200024BL)

Capacity: 500 Milliliters

Material: Iron (outer shell), BPA-Free Plastic (inner tank)

Power Source: Corded Electric

Special Features: Automatic Shut-Off, Long Lasting Aroma, Multiple Light Setting, Silent Operation, Timer Setting

Light Source Type: LED (7-color changing mood light)

Coverage: Medium to Large Room

Product Dimensions: 3"L x 7"W x 5.5"H

Item Weight: 2.25 pounds

Manufacturer: Mats Technology

WARRANTY AND SUPPORT

For any questions, concerns, or warranty claims regarding your ARVIDSSON Essential Oil Diffuser, please contact the manufacturer, Mats Technology, directly through their official support channels. Please refer to your purchase documentation for specific warranty terms and contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question