

Tikom V450

Tikom V450 Cordless Vacuum Cleaner

INSTRUCTION MANUAL

INTRODUCTION

Thank you for choosing the Tikom V450 Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

WHAT'S IN THE BOX

Your Tikom V450 package includes the following components:

- Vacuum Cleaner (Main Unit) x1
- Wall Dock x1
- Wall Screws with Plastic Expansion Anchor x4
- Plastic Expansion Anchor x1
- Battery x1
- Motorized Cleaner Head x1
- Crevice Tool x1
- 2-in-1 Soft Dusting Brush x1
- Length Adjustable Extension Wand x1
- Adapter x1
- User Manual x1

One Click to Clear



1.3L Large Dust Cup

Image: All components of the Tikom V450 Cordless Vacuum Cleaner laid out, including the main unit, various attachments, wall mount, and charger.

PRODUCT OVERVIEW

The Tikom V450 is a versatile cordless stick vacuum cleaner designed for efficient home cleaning. Key features include:

- **Powerful Suction:** Equipped with a 450W motor, delivering up to 40Kpa suction power for effective cleaning of pet hair, crumbs, and debris.
- **LED Smart Touch Screen:** An intuitive color display shows working status, suction level, remaining battery, and malfunction warnings.
- **6-in-1 Versatility:** Easily converts from a stick vacuum to a handheld vacuum for various cleaning tasks, including car seats, pet beds, stairs, and hard-to-reach areas.
- **Large Dust Cup:** Features a 1.3L dust cup with a one-touch emptying design for hygienic disposal and less frequent emptying.
- **Advanced Filtration:** A 7-stage HEPA Filtration Cyclone System captures 99.99% of microscopic dust particles, preventing secondary pollution.

- **Maneuverability & LED Headlight:** Offers 90° vertical and 180° horizontal rotation with 6 LED headlights to illuminate dark corners.



Image: Tikom V450 Cordless Vacuum Cleaner in use, highlighting its 450W upgraded motor and 40KPa suction power, effectively cleaning dust, hair, debris, and pet food from a carpet.

SETUP

Assembly

1. Attach the Length Adjustable Extension Wand to the main vacuum cleaner body until it clicks into place.
2. Connect the Motorized Cleaner Head to the other end of the extension wand, ensuring it locks securely.
3. For handheld use, attach desired accessories (Crevice Tool or 2-in-1 Soft Dusting Brush) directly to the main unit or the extension wand.

180°+90° Rotatable Roller Brush



Image: A collage of images showing the Tikom V450 Cordless Vacuum Cleaner in its various 6-in-1 configurations, including stick vacuum, handheld with brush, handheld with crevice tool, and extended for high reach.

Charging the Battery

1. The 6*2000 mAh rechargeable battery can be charged in two ways:
2. **Direct Charging:** Connect the adapter directly to the battery pack.
3. **Wall-Mounted Charging Dock:** Install the wall dock using the provided screws. Place the vacuum cleaner onto the dock for automatic charging and convenient storage.

2000mAh Removable Battery

Detachable battery for easy charging



16 Mins

High Suction



32 Mins

Low Suction



6*2000mAh

Battery



Detachable

Image: A close-up view of the Tikom V450's detachable 2000mAh battery, showing it being removed from the main unit for separate charging.

OPERATING INSTRUCTIONS

Power and Suction Control

1. Press the power button on the LED Smart Touch Screen to turn the vacuum on/off.
2. Tap the suction level icon on the touch screen to cycle through different power modes (e.g., Low, High). The display will show the current suction level and remaining battery.

ALL-in-One LED Display

One-touch adjustment of suction level



Low
suction



High
suction



Image: A close-up of the Tikom V450's LED Smart Touch Screen, displaying battery percentage and allowing one-touch adjustment of suction levels.

Cleaning Different Surfaces

- The Motorized Cleaner Head is suitable for all floor types, including carpet and hard floors. Its 90° vertical and 180° horizontal rotation allows for easy navigation around furniture.
- The integrated LED headlights illuminate dark areas, making hidden dust visible.
- Use the Crevice Tool for narrow gaps and edges.
- The 2-in-1 Soft Dusting Brush is ideal for delicate surfaces, upholstery, and pet hair on furniture.

What's in the box:



Image: The Tikom V450's motorized cleaner head demonstrating its 180° rotatable brush and LED headlights, effectively cleaning under furniture and along edges.

Official Product Videos

Video: Demonstrates the lightweight design and quiet operation of the Tikom V450 vacuum cleaner, showcasing its ease of use in various home environments.

Video: Highlights the versatility and lightweight nature of the Tikom V450, showing how it meets various cleaning needs around the home.

Video: Showcases the powerful suction capabilities of the Tikom V450 vacuum cleaner, demonstrating its effectiveness on different surfaces.

MAINTENANCE

Emptying the Dust Cup

The 1.3L dust cup features a hygienic one-touch emptying design. Simply press the release button to open the bottom flap and dispose of dirt and debris directly into a trash bin.

Anti-tangle V-shaped Roller Brush



Our-anti-tangle



Other-Blockages



Image: A hand operating the one-touch emptying mechanism of the Tikom V450's 1.3L dust cup, releasing collected debris into a trash can.

Filter Cleaning

The 7-stage HEPA Filtration Cyclone System requires regular cleaning to maintain optimal performance. Refer to the detailed instructions in the included User Manual for proper filter removal and washing procedures.

Brush Roll Maintenance

The anti-tangle V-shaped roller brush is designed to minimize hair tangles. Periodically check the brush roll for any entangled hair or debris and remove it to ensure efficient cleaning.

6 in 1 Multi-functional



Image: A detailed view of the Tikom V450's anti-tangle V-shaped roller brush, showing its design compared to other brushes that often get blocked by hair.

TROUBLESHOOTING

If you encounter any issues with your Tikom V450, please refer to the comprehensive troubleshooting guide in the included User Manual. Common issues and solutions are detailed there to help you resolve problems quickly.

SPECIFICATIONS

Brand	Tikom
Model Name	V450
Wattage	450 watts
Suction Power	40Kpa

Battery Life	32 minutes (Max Runtime)
Capacity	1.3 Liters (Dust Cup)
Filter Type	HEPA Filter (7-stage Cyclonic System)
Item Weight	5.5 pounds
Product Dimensions	6.89"L x 16.93"W x 11.22"H
Special Features	Cordless, Lightweight, Portable, Headlight, LED Smart Touch Screen, Anti-Tangle, Easy to Clean

WARRANTY & SUPPORT

For detailed warranty information and customer support, please refer to the dedicated section in your included User Manual. You may also visit the official Tikom website for further assistance and product registration.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question