

CO905KS

Ninja CO905KS Deluxe Kitchen System

USER MANUAL

Model: CO905KS | Brand: Generic

1. INTRODUCTION AND OVERVIEW

The Ninja CO905KS Deluxe Kitchen System is a versatile 1600-watt appliance designed for comprehensive food preparation. It combines the functionality of a powerful blender with a robust food processor, offering solutions for blending, chopping, mixing, and more. This system is engineered for efficiency and convenience, featuring Auto-iQ programs and precision speed control to handle a wide range of ingredients from ice to dough.



Image: The Ninja CO905KS Deluxe Kitchen System, showcasing its main components: the motor base, large blender pitcher, food processor bowl, and two single-serve cups. The blender pitcher is filled with colorful fruits and vegetables, and the food processor bowl contains processed dough, illustrating the system's diverse capabilities.

2. COMPONENTS AND WHAT'S INCLUDED

Your Ninja CO905KS Deluxe Kitchen System includes the following components:

- **1600-Peak-Watt Motor Base:** The central unit with digital control panel and Auto-iQ programs.
- **72 oz. Total Crushing Blender Pitcher:** Extra-large capacity for blending large batches.
- **9-Cup Food Processor Bowl with Lid:** For chopping, slicing, shredding, and dough mixing.
- **Dough Blade:** Specifically designed for mixing dough.
- **Multi-Purpose Blade:** For general food processing tasks.
- **(2) 24 oz. Single-Serve Cups with To-Go Lids:** For individual servings and portability.
- **Total Crushing Blades Assembly:** For the blender pitcher.



Image: An overhead view displaying all the individual components of the Ninja CO905KS Deluxe Kitchen System, including the motor base, various pitchers, bowls, blades, and lids, arranged neatly on a flat surface.

3. SETUP INSTRUCTIONS

Before first use, wash all components that will come into contact with food in warm, soapy water. Rinse thoroughly and dry. Ensure the motor base is placed on a clean, dry, and level surface.

1. **Assemble the Pitcher/Bowl:** Place the desired blade assembly onto the drive gear inside the pitcher or food processor bowl.
2. **Add Ingredients:** Place your ingredients into the pitcher or bowl, ensuring not to exceed the MAX fill line.
3. **Secure the Lid:** Place the lid onto the pitcher or bowl and press down firmly until it clicks into place. Ensure the handle is aligned and locked.
4. **Attach to Motor Base:** Carefully place the assembled pitcher or bowl onto the motor base. Rotate clockwise until it locks securely into place. You should hear a click.
5. **Plug In:** Plug the power cord into a standard electrical outlet. The power button on the motor base will illuminate.

4. OPERATING INSTRUCTIONS

The Ninja CO905KS features Auto-iQ programs and precision speed control for optimal results.



Image: A detailed view of the control panel on the Ninja CO905KS Deluxe Kitchen System, showing the power button, Auto-iQ dial with various preset functions (Smoothie, Frozen, Extract, Dough, Chop, Disc, Purée), manual speed settings (Low, Med, High), and a Pulse button.

Using Auto-iQ Programs:

Auto-iQ programs are intelligent, pre-programmed settings that combine unique pulsing, blending, and pausing patterns to achieve specific results. Simply select the desired program on the dial, and press the start button (usually the illuminated power button or a dedicated start button if present).

- **Smoothie:** Ideal for fresh or frozen fruit smoothies.
- **Frozen:** Perfect for frozen drinks and desserts.
- **Dough:** Designed for mixing various types of dough, up to 2.5 lbs.
- **Chop:** For precise chopping of vegetables and other ingredients.
- **Extract:** For nutrient and vitamin extraction from whole fruits and vegetables.

Manual Speed Control:

For customized blending, use the manual speed settings:

- **Low:** For gentle mixing and combining ingredients.
- **Medium:** Suitable for sauces and batters.
- **High:** For crushing ice, pulverizing whole fruits, and tough ingredients.
- **Pulse:** Provides short bursts of power for controlled chopping and processing. Hold the button for continuous pulsing.




Image: A grid displaying eight different food preparations, including various smoothies, salsa, cookie dough, sliced cucumbers, and shredded cabbage, demonstrating the versatility of the Ninja Kitchen System.

5. MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and optimal performance of your Ninja Kitchen System.

Cleaning Instructions:

- **Unplug Before Cleaning:** Always ensure the motor base is unplugged from the power outlet before

cleaning.

- **Dishwasher Safe Parts:** All removable parts, including the blender pitcher, food processor bowl, single-serve cups, lids, and blade assemblies, are top-rack dishwasher safe.
- **Hand Washing:** For best results and to prolong the life of the blades, hand wash components with warm, soapy water using a non-abrasive cleaning brush. Exercise extreme caution when handling blade assemblies as they are sharp.
- **Motor Base:** Wipe the motor base clean with a damp cloth. Do not immerse the motor base in water or any other liquid.
- **Storage:** Store the system with the pitcher/bowl and lid securely attached to prevent dust accumulation.



Image: The blender pitcher, food processor bowl, and lids of the Ninja Kitchen System are shown placed in the top rack of a dishwasher, illustrating their dishwasher-safe design for easy cleaning.

BPA-Free Construction:

All food-contact components of the Ninja CO905KS Deluxe Kitchen System are made from BPA-free materials, ensuring safe food preparation.

6. TROUBLESHOOTING

If you encounter issues with your Ninja Kitchen System, refer to the following common solutions:

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; Pitcher/bowl not properly assembled or locked.	Ensure power cord is securely plugged in. Verify pitcher/bowl is fully seated and locked onto the motor base.
Ingredients not blending/processing.	Too much or too little liquid; Overloaded; Blades jammed.	Add more liquid if ingredients are too thick. Reduce ingredient quantity. Unplug, remove pitcher/bowl, clear any obstructions around blades.
Lid not locking.	Lid not aligned correctly; Pitcher/bowl not seated.	Ensure lid handle is aligned with the pitcher/bowl handle and pressed down firmly until it clicks. Check pitcher/bowl is fully locked onto the base.
Motor smells or overheats.	Overloaded; Continuous operation.	Unplug the unit and allow it to cool down for at least 15 minutes. Reduce ingredient load for future use. Avoid continuous operation for extended periods.

7. SPECIFICATIONS

Detailed technical specifications for the Ninja CO905KS Deluxe Kitchen System:

Feature	Detail
Brand	Generic
Special Feature	Safety Lock, Dishwasher Safe Parts, Adjustable Speed Control, Removable Parts
Product Dimensions	8.78"D x 9.33"W x 18.5"H
Color	Silver
Bowl Capacity	9 Cups
Recommended Uses	Mixing, Chop, Ice Crush, Grind
Number of Speeds	3
Product Care Instructions	Dishwasher Safe
Included Components	Chopping Blade, Lid, Jar, Slicing Disc
Model Name	Generic

Feature	Detail
Is Dishwasher Safe	Yes
Blade Material	Stainless Steel
Power Source	Corded Electric
Manufacturer	Generic
Item Weight	8.8 pounds
Country of Origin	China
Item model number	CO905KS
Date First Available	April 17, 2025

Specifications

Brand	Ninja
Capacity	88 Ounce
Container Material	Plastic
Cord Length	31.5 in.
Dimensions: W x L x H	8.78 in. x 9.33 in. x 18.5 in.
Dishwasher Safe Parts	Blades
Dishwasher Safe Parts	Jar
Dishwasher Safe Parts	Lid

Features	BPA Free Container
Features	Dishwasher Safe
Model	CO905KS
Number of Attachments	6
Number of Containers	2
Number of Speed Settings	3

Image: A digital display of the product specifications for the Ninja CO905KS, listing details such as brand, capacity, dimensions, and features.

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product packaging or contact the manufacturer directly. Keep your purchase receipt as proof of purchase for any warranty claims.

Related Documents - CO905KS

 <p>IMPORTANT SAFETY INSTRUCTIONS PLAQUE PRISE ET INSTRUCTIONS D'USAGE SEULE. POUR CONSULTATION SEULE</p> <p>AVERTISSEMENT Afin de réduire les risques d'incendie, d'électrocution et de blessures, lire toutes les instructions. NE PAS utiliser à l'extérieur.</p> <p>AVERTISSEMENT Afin de réduire les risques d'incendie, d'électrocution et de blessures, lire toutes les instructions. NE PAS utiliser à l'extérieur.</p>	<p>Ninja Deluxe Kitchen System with Auto-iQ CO905KS Owner's Guide</p> <p>Comprehensive owner's guide for the Ninja Deluxe Kitchen System with Auto-iQ, model CO905KS. Includes important safety instructions, parts identification, features, operating instructions for various programs and attachments, care and maintenance, troubleshooting, and warranty information.</p>
---	---



[Ninja Deluxe Kitchen System with Auto-iQ® User Manual & Safety Instructions](#)

Comprehensive user manual for the Ninja Deluxe Kitchen System with Auto-iQ®, covering important safety instructions, parts, operation, care, and troubleshooting for various blending and processing tasks.