

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [PHILIPS](#) /

› [PHILIPS TAH2209 Bluetooth Headphone Instruction Manual](#)

PHILIPS TAH2209

PHILIPS TAH2209 Bluetooth Headphone User Manual

Model: TAH2209

1. INTRODUCTION

The PHILIPS TAH2209 Bluetooth Headphone offers a high-quality wireless audio experience with an ergonomic design. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your headphones to ensure optimal performance.

Package Contents

- PHILIPS TAH2209 Headphone
- USB-C Charging Cable
- Quick Start Guide



Image 1: The PHILIPS TAH2209 Bluetooth Headphone in black, showcasing its sleek design.

2. SETUP

Charging the Headphones

Before first use, fully charge your headphones. Connect the supplied USB-C cable to the charging port on the headphone and to a USB power source. A full charge takes approximately 2 hours and provides up to 25 hours of playback. A quick 15-minute charge can provide an additional 1 hour of use.

Bluetooth Pairing

1. Ensure the headphones are turned off.
2. Press and hold the multi-function button until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "PHILIPS TAH2209" from the list of devices.
5. Once connected, the LED indicator will flash blue slowly.



Conexão Bluetooth

Conecte dois dispositivos simultaneamente com som estável e sem interrupções



Image 2: Illustration of the Bluetooth connection process, showing the headphone connecting wirelessly. The headphones can connect to two devices simultaneously, allowing seamless switching between music on one device and calls on another.

3. OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Press and hold the multi-function button for approximately 3 seconds until the LED indicator flashes blue.

- **Power Off:** Press and hold the multi-function button for approximately 5 seconds until the LED indicator flashes red and then turns off.

Music Playback

- **Play/Pause:** Press the multi-function button once.
- **Next Track:** Press and hold the 'Next' button (usually marked with '>>').
- **Previous Track:** Press and hold the 'Previous' button (usually marked with '<<').
- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.

Call Management

The integrated microphone with noise reduction ensures clear communication during calls.

- **Answer/End Call:** Press the multi-function button once.
- **Reject Call:** Press and hold the multi-function button for 2 seconds.
- **Activate Voice Assistant:** Double-press the multi-function button.



Botão multifuncional

Controle chamadas, reprodução de músicas e volume com praticidade



Image 3: Detailed view of the multi-function button and volume controls located on the right earcup.



Image 4: Visual representation of clear call quality with noise reduction technology.

4. MAINTENANCE

Cleaning

To maintain the condition of your headphones, wipe them regularly with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these can damage the surface. Do not immerse the headphones in water.

Storage

The PHILIPS TAH2209 headphones feature a foldable design for easy storage and portability. When not in use, fold the earcups inward to protect them from damage. Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.



Compacto e dobrável

Design dobrável que facilita o armazenamento para levar a qualquer lugar

Image 5: The headphone shown in its compact, folded state, highlighting its portability.

5. TROUBLESHOOTING

If you encounter any issues with your PHILIPS TAH2209 headphones, please refer to the following common solutions:

- **Headphones do not power on:** Ensure the headphones are fully charged. Connect them to a power source using the USB-C cable.
- **Cannot pair with a device:** Make sure the headphones are in pairing mode (LED flashing blue and red). Ensure Bluetooth is enabled on your device and it is within range. Try unpairing and re-pairing the headphones.
- **No sound or low volume:** Check the volume levels on both the headphones and your connected device. Ensure the headphones are properly connected via Bluetooth.
- **Intermittent connection:** Move closer to your connected device to reduce interference. Ensure there are no obstacles between the headphones and the device.
- **Poor call quality:** Ensure the microphone is not obstructed. Check for strong Bluetooth signal.

If the problem persists, consult the official PHILIPS support resources.

6. SPECIFICATIONS

Feature	Specification
Model Name	TAH2209BK/00
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth
Noise Control	Passive Noise Cancellation
Sensitivity	113 dB
Impedance	32 Ohm
Ear Placement	Circumaural (Over-Ear)
Material	Plastic
Average Battery Life	25 Hours
Charging Time	Approx. 2 Hours (for 25 hours playback)
Water Resistance Level	Not Water Resistant
Product Weight	141 g
Product Dimensions	4 x 16.1 x 18.5 cm
Compatible Devices	Mobile Phones, Notebooks, Tablets

7. WARRANTY AND SUPPORT

Manufacturer's Warranty

The PHILIPS TAH2209 Bluetooth Headphone comes with a **1-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For further assistance, technical support, or warranty inquiries, please visit the official PHILIPS support website or contact their customer service. Refer to the Quick Start Guide included in your package for specific contact details in your region.