Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aroepurt CPT15

Aroepurt CPT15 Phone Case & Tempered Glass Screen Protector User Manual

Compatible with Eudora E55 Plus Phone

1. Introduction

Thank you for choosing the Aroepurt CPT15 Phone Case with Tempered Glass Screen Protector. This product is designed to provide comprehensive protection and enhanced functionality for your Eudora E55 Plus phone. The case features high-quality PU leather, a magnetic closure, card slots, and a convenient kickstand. The included tempered glass screen protector offers additional defense against scratches and impacts.

2. What's in the Box

- 1 x Aroepurt CPT15 Phone Case
- 1 x Tempered Glass Screen Protector

3. Product Features

- **Integrated Kickstand:** Allows for hands-free viewing of movies and videos.
- **Durable Material:** Constructed from high-quality PU leather with fine stitch edge sealing for enhanced durability and a premium feel.
- **Card Slots:** Features dedicated slots for storing cards and cash, reducing the need for a separate wallet.
- **Magnetic Closure:** Securely keeps the case closed, protecting your phone and contents.
- **Comprehensive Protection:** Flip PU leather design combined with a silicone ring provides robust protection against drops and impacts.
- **Tempered Glass Screen Protector:** Offers 9H high hardness, shatterproof design, perfect adhesion, case-friendly fit, 99.9% super transparency, and anti-fingerprint properties.



Image: The Aroepurt CPT15 Phone Case in various configurations, highlighting its design, kickstand functionality, and card storage.

4. Setup Instructions

4.1. Installing the Phone Case

1. Ensure your phone is clean and free of dust or debris.
2. Gently align your Eudora E55 Plus phone with the silicone inner shell of the case.
3. Press the phone firmly into the case, ensuring all corners and edges are securely seated.
4. Verify that all ports, buttons, and camera cutouts align correctly with your phone.

4.2. Applying the Tempered Glass Screen Protector

1. **Clean the Screen:** Use a microfiber cloth to thoroughly clean your phone's screen, removing all dust, smudges, and fingerprints. For best results, use an alcohol wipe if available, then dry with the cloth.
2. **Align the Protector:** Carefully peel off the protective film from the adhesive side of the tempered glass. Align the screen protector with your phone's screen, paying close attention to the edges, camera, and speaker cutouts.
3. **Apply:** Once aligned, gently lower the screen protector onto the screen. It will naturally adhere.
4. **Remove Bubbles:** If any bubbles appear, gently push them towards the edges of the screen using a soft cloth or a credit card wrapped in a cloth.




Image: Key features of the tempered glass screen protector, including its hardness, adhesion, and clarity.



Image: Visual representation of the screen protector's scratch-proof and shatterproof capabilities.

5. Operating Instructions

5.1. Using the Kickstand Feature

To use the kickstand, simply fold the back cover of the case outwards. The case is designed to prop up your phone at an optimal viewing angle, ideal for watching videos, making video calls, or browsing content hands-free.

5.2. Utilizing Card Slots

The inner flap of the case includes multiple slots for credit cards, ID cards, or small amounts of cash. Gently slide your cards into the designated slots. Avoid overfilling the slots to prevent stretching the material or damaging the magnetic closure.

5.3. Magnetic Closure

The case features a magnetic strap that ensures the front flap stays securely closed when not in use. This protects your

screen and contents from accidental opening. To open, simply pull the magnetic strap away from the case.



Image: Illustration of the magnetic closure mechanism and the adjustable stand feature.



Image: Close-up view of the card storage slots, demonstrating capacity for two cards.

6. Maintenance

To maintain the appearance and longevity of your Aroepurt CPT15 Phone Case and Tempered Glass Screen Protector, follow these guidelines:

- **Cleaning the Case:** Wipe the PU leather surface with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive water, as these can damage the material.
- **Cleaning the Screen Protector:** Use a microfiber cloth to gently wipe the screen protector. For stubborn smudges, a small amount of screen cleaner designed for electronics can be applied to the cloth (not directly to the screen).

- **Avoid Extreme Conditions:** Do not expose the case to extreme temperatures, direct sunlight for prolonged periods, or sharp objects that could scratch the material.

7. Troubleshooting

- **Case does not fit:** Ensure you have the correct model (Eudora E55 Plus). Double-check that the phone is inserted correctly and fully seated within the silicone shell.
- **Screen protector bubbles:** Small bubbles can often be pushed out to the edges using a soft cloth. If large bubbles persist, it may indicate dust particles. Carefully lift a corner of the protector, remove the dust with a dust-absorber sticker, and reapply.
- **Magnetic closure not strong enough:** Ensure no excessive items (e.g., too many cards or bulky cash) are placed in the card slots, as this can prevent the magnet from engaging properly.

8. Specifications

Product Dimensions	0.39 x 0.39 x 0.39 inches
Item Weight	2.46 ounces
ASIN	B0F5BSV5J3
Special Features	Card insertion, Stash the change, Stylish design
Form Factor	Basic Case
Color	CPT15
Manufacturer	GX2503-169 CPT1 ARO
Date First Available	April 17, 2025

9. Warranty and Support

For any questions, concerns, or support regarding your Aroepurt CPT15 Phone Case and Tempered Glass Screen Protector, please refer to the seller's contact information on the platform where the product was purchased. Please retain your proof of purchase for any warranty claims.

© 2025 Aroepurt. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F5BSV5J3

More documents and user manuals: **https://manuals.plus/**