

Sharp B0F5CL9626

SHARP Smart Microwave Drawer Oven

USER MANUAL

Model: B0F5CL9626

1. Introduction

Thank you for choosing the SHARP Smart Microwave Drawer Oven. This appliance is designed for convenient and efficient cooking, featuring a 24-inch width, 1.2 cubic feet capacity, and 950 watts of cooking power. Its innovative "Easy Wave Open" function allows for touchless operation, and the concealed glass touch control panel provides a sleek, modern look. With Alexa certification, you can enjoy hands-free cooking using voice commands.

This manual provides essential information for the safe and effective use of your new microwave drawer oven, including installation, operation, maintenance, and troubleshooting.

2. Important Safety Information

Please read all instructions carefully before using the appliance to reduce the risk of fire, electric shock, injury to persons, or exposure to excessive microwave energy.

- Do not attempt to operate this oven with the door open as this can result in harmful exposure to microwave energy.
- Do not place any object between the oven front face and the door, or allow soil or cleaner residue to accumulate on sealing surfaces.
- Do not operate the oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the: (1) door (bent), (2) hinges and latches (broken or loosened), (3) door seals and sealing surfaces.
- The oven should not be adjusted or repaired by anyone except properly qualified service personnel.
- Always ensure proper ventilation around the appliance.
- Do not heat sealed containers, as they may explode.
- Use only microwave-safe cookware.

3. Setup and Installation

Proper installation is crucial for the performance and safety of your microwave drawer oven. It is recommended that installation be performed by a qualified installer.

3.1 Unpacking

- Carefully remove all packaging materials and accessories.
- Inspect the oven for any damage, such as dents or a misaligned door. Do not install if damaged.
- Retain the carton and packing materials for future use or dispose of them properly.

3.2 Location Requirements

- The microwave drawer oven is designed for under-the-counter installation.
- Ensure the cabinet opening dimensions meet the product specifications for proper fit and ventilation.
- The appliance requires a dedicated, properly grounded electrical outlet. Refer to the electrical requirements section in the full installation guide for details.
- The unit comes with adjustable feet for leveling.

3.3 Pedestal Installation

This model includes a 24-inch width under-the-counter microwave drawer oven pedestal. Follow the separate pedestal installation instructions provided with the unit for secure and level placement.



Figure 1: Front view of the SHARP Smart Microwave Drawer Oven with its pedestal.

4. Operating Instructions

Your SHARP Smart Microwave Drawer Oven offers intuitive controls and smart features for a seamless cooking experience.

4.1 Control Panel Overview

The concealed glass touch control panel is located at a convenient 45° angle for easy visibility and operation. It includes various buttons for power levels, cooking time, sensor cooking, and special functions.

4.2 Opening and Closing the Drawer

- **Easy Wave Open:** Gently wave your hand in front of the sensor to automatically open the drawer for quick, touchless access.
- **Open/Close Button:** Press the **OPEN** or **CLOSE** button on the control panel to open or close the drawer.

- **Manual Close:** The drawer can also be gently pushed closed.

4.3 Basic Cooking

- Place food in a microwave-safe container inside the drawer.
- Close the drawer.
- Enter the desired cooking time using the numeric keypad.
- Select the power level if different from 100% (e.g., press**POWER LEVEL** and then a number for percentage).
- Press **START**.

4.4 Smart Features (Alexa & Sharp Kitchen App)

This microwave drawer oven is Alexa certified, allowing for convenient voice control. It also integrates with the Sharp Kitchen App.

- **Alexa Voice Commands:** Connect your microwave to your Amazon Alexa account via the Alexa app. Use over 35 voice commands for hands-free cooking, such as "Alexa, microwave for 2 minutes on high" or "Alexa, defrost 1 pound of chicken."
- **Sharp Kitchen App:** Download the Sharp Kitchen App from the App Store or Google Play. The app provides additional control, recipes, and monitoring features for your appliance.

5. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your microwave drawer oven.

- **Interior:** Clean the oven interior regularly with a mild detergent and a soft cloth. For stubborn food splatters, place a bowl of water with lemon slices inside and microwave for a few minutes to loosen residue before wiping.
- **Exterior:** Wipe the stainless steel front drawer panels and glass control panel with a soft, damp cloth. Avoid abrasive cleaners or scouring pads.
- **Door Seals:** Keep the door seals and adjacent parts clean. Wipe with a damp cloth as needed.
- **General Care:** Do not immerse the appliance in water. Always unplug the oven before cleaning.

6. Troubleshooting

If you encounter issues with your microwave drawer oven, refer to the table below for common problems and solutions. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Oven does not start	Power cord unplugged; Door not closed properly; Fuse blown or circuit breaker tripped.	Ensure power cord is securely plugged in; Close the drawer completely; Check household fuse or reset circuit breaker.
Drawer does not open/close	Obstruction in drawer path; Control panel locked.	Remove any obstructions; Check if child lock is activated and deactivate it.
Food not cooking evenly	Improper stirring/turning; Incorrect power level/time.	Stir or turn food halfway through cooking; Adjust cooking time and power level as needed.

Problem	Possible Cause	Solution
Alexa commands not working	Microwave not connected to Wi-Fi; Alexa device not linked or not hearing commands.	Ensure microwave is connected to your home Wi-Fi; Verify Alexa device is properly set up and linked to the microwave.







7. Specifications

Feature	Detail
Brand	Sharp
Model Number	B0F5CL9626
Capacity	1.2 Cubic Feet
Cooking Power	950 Watt
Width	24-inch
Control Type	Concealed Glass Touch Control Panel
Special Features	Easy Wave Open, Works with Alexa Certified, Edge Glass, Stainless Steel with Pedestal
Date First Available	April 17, 2025

8. Warranty and Customer Support

For warranty information and details regarding your SHARP Smart Microwave Drawer Oven, please refer to the warranty card included with your product or visit the official Sharp website. For technical assistance, parts, or service, please contact Sharp customer support. You can find contact information and additional resources on the [Sharp Official Store on Amazon](#) or the main Sharp website.



	<p>Sharp Microwave Drawer™ Quick Start Guide: SMD2489ES & SMD2479JS</p> <p>Quick start guide for Sharp Microwave Drawer™ models SMD2489ES and SMD2479JS, covering setup, app connectivity, and basic operation.</p>
	<p>Sharp Built-In Appliance Design Guide: Microwaves, Ovens & Kitchen Layouts</p> <p>Explore Sharp's comprehensive design guide for built-in kitchen appliances, featuring Microwave Drawers, SuperSteam+™ Ovens, Over-the-Counter microwaves, and installation dimensions for creating your dream kitchen.</p>
	<p>Sharp SMD2499FS Microwave Drawer Safety and Regulatory Information</p> <p>Detailed safety precautions, wireless LAN guidelines, and FCC/IC regulatory compliance for the Sharp SMD2499FS Home Use Convection Microwave Drawer.</p>
	<p>Sharp SMD2499FS Convection Microwave Drawer Installation Manual</p> <p>Detailed installation manual for the Sharp SMD2499FS Convection Microwave Drawer. Covers essential safety warnings, required clearances and dimensions for standard and flush mounting, unpacking instructions, electrical and grounding requirements, and step-by-step drawer installation procedures.</p>
	<p>Sharp Induction Cooktop Installation Manual</p> <p>Installation manual for Sharp Induction Cooktops SCH2443GB and SCH3043GB, providing detailed instructions for electrical connection, cutout dimensions, and safety precautions.</p>
	<p>SHARP R-1855A Over-the-Range Microwave Oven Service Manual</p> <p>This service manual provides detailed operational procedures, specifications, troubleshooting guides, component replacement instructions, and safety precautions for the SHARP R-1855A Over-the-Range Microwave Oven.</p>