

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Fisher & Paykel](#) /
- › [Fisher & Paykel 836524 Small Bin Instruction Manual](#)

Fisher & Paykel 836524

Fisher & Paykel 836524 Small Bin Instruction Manual

1. PRODUCT OVERVIEW

The Fisher & Paykel 836524 Small Bin is a replacement or supplementary storage component designed for specific Fisher & Paykel refrigerators. This bin is suitable for models where the freezer is located at the bottom and the bins are designed to sit on a roll-out tray. It is identified as the larger of two bin sizes available for these refrigerator types.

This bin specifically suits Fisher & Paykel refrigerator model E522B.



An image showing the transparent Fisher & Paykel 836524 Small Bin. The bin features a clear plastic construction, a ribbed base for drainage or air circulation, and a slight cut-out on one side, likely for easier handling or fitting into a specific refrigerator slot. Its approximate dimensions are 15.5 x 13.5 x 7.5 inches.

2. SETUP AND INSTALLATION

The 836524 bin is designed for easy installation into compatible Fisher & Paykel refrigerators. It functions as both a fridge bin and a freezer bin, depending on the specific compartment it is placed in.

1. **Identify Location:** Locate the designated roll-out tray within your refrigerator or freezer compartment where the bin is to be placed.
2. **Insert Bin:** Gently slide the 836524 bin onto the roll-out tray. Ensure it is seated securely and slides smoothly along the tray's runners.
3. **Verify Fit:** Confirm that the bin does not obstruct the closing of the refrigerator or freezer door and that it sits level.

3. OPERATING INSTRUCTIONS

The bin is intended for storing food items within your refrigerator or freezer. To ensure optimal performance and longevity:

- **Placement:** Place food items securely within the bin to prevent spillage or damage.
- **Loading:** Avoid overloading the bin. Overloading can hinder proper air circulation and make it difficult to move the bin on its roll-out tray.
- **Temperature:** Ensure items placed in the bin are suitable for the temperature of the compartment (refrigerator or freezer).

4. MAINTENANCE AND CARE

Regular cleaning will help maintain the hygiene and appearance of your bin.

1. **Removal:** Carefully remove the bin from the refrigerator or freezer compartment.
2. **Cleaning:** Wash the bin with warm, soapy water. Use a soft cloth or sponge to avoid scratching the surface.
3. **Rinsing:** Rinse thoroughly with clean water to remove all soap residue.
4. **Drying:** Allow the bin to air dry completely before returning it to the appliance.
5. **Avoid Harsh Cleaners:** Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the bin's material and finish.

5. TROUBLESHOOTING

- **Bin does not slide smoothly:** Ensure the roll-out tray is clean and free of any food debris or obstructions. Check for any items placed in the bin that might be catching on the refrigerator interior.
- **Bin does not fit:** Verify that your refrigerator model is compatible with the 836524 bin. This bin is specifically designed for Fisher & Paykel refrigerators with a bottom freezer and roll-out trays, such as model E522B. It is the larger of two available bin sizes for these models.

6. SPECIFICATIONS


Manufacturer	Fisher & Paykel
Part Number	836524
Item Model Number	836524

Included Components	BIN SMALL 790
Product Dimensions	15.5 x 13.5 x 7.5 inches
Item Weight	2.66 pounds
Compatibility	Fisher & Paykel Refrigerator Model E522B (bottom freezer, roll-out tray)

7. WARRANTY AND SUPPORT

For warranty information or further support regarding your Fisher & Paykel product, please refer to the documentation provided with your main appliance or visit the official Fisher & Paykel website for detailed customer service options.

Related Documents - 836524

	<p>Fisher & Paykel Toe Kick for Dual Install Refrigerator/Freezer - Model 25397</p> <p>Product specifications and dimensions for the Fisher & Paykel stainless steel Toe Kick designed for 76+61cm Dual Install Column Refrigerators and Freezers. Compatible with models RS7621S, RS6121F, RS6121S, RS7621F. Includes contact information and support details.</p>
	<p>Fisher & Paykel ActiveSmart™ Refrigerator Installation Guide</p> <p>This guide provides comprehensive installation instructions for Fisher & Paykel ActiveSmart™ refrigerators, including French Door and Bottom Mount models. It covers safety warnings, product and cabinetry dimensions, unpacking, water connection, positioning, and final installation checks for models such as RF522A, RF540A, RF610A, E372B, E402B, E442B, E522B, RF372B, RF402B, RF442B, RF522B, and RF522W.</p>
	<p>Fisher & Paykel ActiveSmart™ Refrigerator Installation Guide</p> <p>Comprehensive installation guide for Fisher & Paykel ActiveSmart™ refrigerators, covering safety, product and cabinetry dimensions, unpacking, water connection, positioning, and final checks. Includes model numbers RF522A, RF540A, RF610A, E372B, E402B, E442B, E522B, RF372B, RF402B, RF442B, RF522B, and RF522W.</p>
	<p>Fisher & Paykel Professional Round Flush Handle Kit for Integrated Refrigerator Freezer, 60cm - Quick Reference Guide</p> <p>Quick reference guide for the Fisher & Paykel Professional Round Flush Handle Kit for Integrated Refrigerator Freezer, 60cm. Provides product details, dimensions, SKU, compatibility information, and customer support contact details.</p>
	<p>Fisher & Paykel ActiveSmart™ Refrigerator Special Features Guide</p> <p>Detailed overview of Fisher & Paykel ActiveSmart™ refrigerator features, including fruit and vegetable bins, humidity control, storage drawers, bottle holders, and manual ice systems for optimal food preservation and convenience.</p>



[Fisher & Paykel 76.2cm Series 11 Integrated Refrigerator Freezer, Ice & Water - Quick Reference Guide](#)

Detailed quick reference guide for the Fisher & Paykel 76.2cm Series 11 Integrated Refrigerator Freezer, Ice & Water (RS7621WRUE1), covering features, dimensions, specifications, and performance.