

[Manuals.plus](#) /

> [Newbealer](#) /

> Newbealer 1.2L Detachable Water Tank for NB318A Steamer - Instruction Manual

Newbealer NB318A-tank

Newbealer 1.2L Detachable Water Tank for NB318A Steamer - Instruction Manual

INTRODUCTION

This manual provides instructions for the Newbealer 1.2L Detachable Water Tank, a replacement part specifically designed for the Newbealer Steamer Model NB318A. This accessory is intended to replace a lost or damaged water tank, ensuring continued functionality of your garment steamer.

Compatibility: This water tank is exclusively compatible with the Newbealer Steamer Model NB318A. It is not designed for use with other steamer models.

Newbealer Replacement Parts

1 Piece

Only Fit for Garment Steamer
Model NB318A
(Not include garment steamer)



Image: The Newbealer 1.2L Detachable Water Tank shown alongside the compatible NB318A garment steamer, highlighting its purpose as a replacement part.

PACKAGE CONTENTS

- 1x Newbealer 1.2L Detachable Water Tank (Garment steamer not included)

SETUP AND INSTALLATION

The water tank features an easy installation process. Follow these steps to attach the replacement water tank to your Newbealer NB318A steamer:

1. Ensure the steamer is switched off and unplugged from the power outlet.
2. If a previous tank is installed, press the "release" button on the steamer to remove it.
3. Open the water inlet cover on the new tank.
4. Fill the tank with water through the valve cover hole. (Refer to the "Operating Instructions" section for details on filling).
5. Close the water inlet cap securely.
6. Align the new water tank with the designated slot on the Newbealer NB318A steamer.
7. Firmly push the water tank into place until it clicks, indicating a secure attachment.



Image: A step-by-step diagram illustrating how to fill the water tank and then firmly attach it to the Newbealer NB318A steamer unit.

OPERATING INSTRUCTIONS

This section details how to fill and use the water tank with your Newbealer NB318A steamer.

Filling the Water Tank

1. Remove the water tank from the steamer unit by pressing the release button.
2. Locate the water inlet cover on the top of the tank and open it.
3. Carefully pour clean, distilled water into the tank. The tank has a maximum capacity of 1.2 liters. Do not overfill.
4. Close the water inlet cap securely to prevent leaks.
5. Reattach the filled water tank to the steamer unit as described in the "Setup and Installation" section.

A full 1.2L water tank allows for approximately 40 minutes of continuous steaming, depending on the steam setting used.

Water Tank With Durable Material



Image: The water tank design, emphasizing its 1.2L maximum capacity, 360-degree leak-proof design, sturdy and lightweight construction, and ease of filling and removal.



Large Capacity Water Tank

Enjoy 40 minutes of
uninterrupted steaming



Image: A user operating the Newbealer steamer, demonstrating the large capacity water tank in use for extended steaming sessions.

MAINTENANCE

Regular maintenance of the water tank is important for hygiene and optimal steamer performance.

- **Cleaning:** Periodically rinse the water tank with clean water. Do not use harsh chemicals or abrasive cleaners.
- **Replacement:** It is recommended to replace the water tank every 6-12 months. This helps maintain hygienic conditions and ensures efficient operation of your steamer, especially if mineral deposits accumulate over time.

TROUBLESHOOTING

If you encounter issues related to the water tank, consider the following:

- **Water Leakage:** Ensure the water inlet cap is closed tightly and the tank is firmly seated in the steamer unit. Check for any visible cracks or damage to the tank.

- **Steamer Not Producing Steam:** Verify that the water tank is filled with water and correctly installed. If the issue persists, consult the main instruction manual for your Newbealer NB318A steamer.
- **Difficulty Removing/Attaching Tank:** Ensure you are pressing the release button firmly when removing the tank. When attaching, align it correctly and push until it clicks into place.

SPECIFICATIONS

Feature	Detail
Product Dimensions	9.06 x 2.36 x 5.12 inches
Item Weight	7.2 ounces
Manufacturer	Newbealer
Item Model Number	NB318A-tank
Water Capacity	1.2 Liters
Compatibility	Newbealer Steamer Model NB318A only

Water Tank Dimension



Image: A visual representation of the water tank's dimensions: 9.06 inches length, 2.36 inches width, and 5.12 inches height.

WARRANTY AND SUPPORT

Specific warranty information for this replacement part is not provided in the product details. For any support inquiries or to obtain warranty details, please contact Newbealer customer service directly or refer to the original Newbealer NB318A steamer manual.

You can visit the official Newbealer store for more information: [Newbealer Store](#)

