

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [ODK](#) /

› ODK 48-Inch Gaming Desk User Manual

ODK B01171801003

ODK 48-Inch Gaming Desk User Manual

Model: B01171801003

Brand: ODK

1. INTRODUCTION

Thank you for choosing the ODK 48-Inch Gaming Desk. This desk is designed to enhance your gaming or work setup with its integrated LED lighting, convenient power outlet, ample storage, and durable carbon fiber surface. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new desk.



The ODK 48-Inch Gaming Desk, ready for your setup.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembling and using this product. Failure to follow these instructions may result in injury or damage to the product.

- Keep all small parts and packaging materials away from children and pets.
- Ensure all connections are secure before use. Do not overtighten screws.
- Do not exceed the maximum weight capacity of the desk or shelves.
- Use only in dry indoor environments. Avoid exposure to moisture or extreme temperatures.
- When using the power outlet, ensure that the total power consumption of connected devices does not exceed the rated capacity.
- Do not attempt to modify or disassemble the electrical components.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Desk Frame Components (Metal Legs, Support Bars)
- Main Desktop Panel (Carbon Fiber Surface)
- Monitor Shelf
- Side Storage Shelves (Adjustable)
- 2 Fabric Drawers
- LED Light Strip with Controller
- Built-in Power Outlet (3 AC, 2 USB)
- Headphone Hook
- Assembly Hardware (Screws, Allen Wrench, etc.)
- Instruction Manual

4. ASSEMBLY INSTRUCTIONS

Assembly typically requires two people and takes approximately 1.5 hours. All necessary tools are included. Follow the step-by-step diagrams provided in the separate assembly guide for detailed instructions.

1. **Unpack and Identify Parts:** Lay out all components and hardware. Match them with the parts list in the assembly guide.
2. **Assemble the Main Desk Frame:** Connect the metal legs and support bars according to the diagrams. Do not fully tighten screws until all parts are aligned.
3. **Attach Desktop Panel:** Secure the main carbon fiber desktop to the assembled frame.
4. **Install Side Storage Shelves:** The side storage unit can be assembled on either the left or right side of the desk to suit your space. The shelves are adjustable; choose the desired height for your PC tower or other items.
5. **Attach Monitor Shelf:** Secure the monitor shelf to the top of the desk.
6. **Insert Fabric Drawers:** Assemble the fabric drawers and slide them into their designated slots under the main desktop.
7. **Install LED Light Strip and Power Outlet:** Affix the LED light strip under the monitor shelf and install the built-in power outlet into its designated cutout.
8. **Attach Headphone Hook:** Secure the headphone hook to the side of the desk.
9. **Final Tightening:** Once all components are in place and aligned, fully tighten all screws.

How to Control

C

Static Color Button

M

Dynamic Mode Button

⏻

Speed & Brightness and Power Button



STATIC COLOR BUTTON

Press this button once to switch to the static color mode, and then each pressing can change the color.

DYNAMIC MODE BUTTON

Press this button once to switch to the dynamic mode effect, and then each pressing can change the dynamic mode.
Press this button for more than 3s to switch to the demo mode; In the demo mode, the strip will automatically cycle through various dynamic modes.

SPEED & BRIGHTNESS AND POWER BUTTON

A. In the static mode, press this button to adjust the brightness of the light bar; each press can switch to a brightness level.
B. In the dynamic mode, press this button to adjust the dynamic mode speed; each press can switch to a speed level.
C. Press and hold this button to shut it down when the strip is on. Press this button to turn it on when the strip is off.

The product has a power-off memory function: the strip can restore the color, brightness, and mode in the next power-on.

Product dimensions and reversible design for flexible setup.

5. FEATURES OVERVIEW

5.1. LED Lights

The desk features an integrated RGB LED light strip under the monitor shelf, offering customizable lighting to enhance your environment. It provides 10 static colors and 10 dynamic modes.



Dynamic RGB LED lighting for an immersive experience.

5.2. Built-in Power Outlet

A convenient power outlet is integrated into the monitor shelf, providing easy access to power for your devices. It includes 3 standard AC outlets (125V/12A) and 2 USB ports (5V/2A).



Integrated power outlet for convenient charging.

5.3. Reversible Display Storage Shelf

The large side shelf unit can be installed on either the left or right side of the desk, adapting to your room layout. It also features an adjustable shelf, allowing you to accommodate larger items like a PC tower or display models.



Adjustable and reversible storage shelves for versatile use.

5.4. Durable Fabric Drawers

Two fabric drawers are included, providing discreet storage for small items such as gamepads, CDs, or office supplies, helping to keep your desktop tidy.



Convenient fabric drawers for organized storage.

5.5. Carbon Fiber Surface

The desktop features a carbon fiber textured surface, which is designed to be scratch-resistant, anti-collision, and waterproof, ensuring durability and a sleek aesthetic.

5.6. Headphone Hook

A dedicated hook is provided for convenient storage of your headphones, keeping them within reach and off the desktop.



Headphone hook for easy access and organization.

5.7. Product Video

Watch the official product video for a visual guide to the ODK Gaming Desk's features and design.

Official video showcasing the ODK Gaming Desk with its features, including LED lights and drawers.

6. OPERATING INSTRUCTIONS

6.1. LED Light Control

The LED light strip is controlled by a wired remote. Refer to the diagram below for button functions:



- **Static Color Button (C):** Press once to switch to static color mode. Each subsequent press changes the color.
- **Dynamic Mode Button (M):** Press once to switch to dynamic mode. Each subsequent press changes the dynamic effect. Press and hold for 3 seconds to enter demo mode, which cycles through various dynamic modes automatically.
- **Speed & Brightness & Power Button (S/B):**
 - In static mode, press to adjust brightness levels.
 - In dynamic mode, press to adjust dynamic mode speed.
 - Press and hold to shut down the strip when it is on. Press briefly to turn it on.

The product has a power-off memory function, retaining the last color, brightness, and mode settings upon next power-on.

6.2. Power Outlet Usage

Simply plug your devices into the available AC outlets or USB ports on the built-in power strip. Ensure devices are compatible with the provided voltage and current specifications.

7. MAINTENANCE

- **Cleaning:** Wipe the carbon fiber surface with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals. For the metal frame, use a dry or slightly damp cloth.
- **Tightening:** Periodically check and tighten all screws to ensure the desk remains stable.
- **Electrical Components:** Keep the power outlet and LED strip dry. Do not immerse in water.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk is wobbly/unstable	Loose screws; uneven floor.	Check and tighten all assembly screws. Adjust the leveling feet at the bottom of the desk legs.
LED lights not working	Power connection loose; controller malfunction; power outage.	Ensure the LED strip is securely plugged into the power source. Check the power outlet it's connected to. Try pressing the power button on the controller.
Power outlet not providing power	Desk power cord unplugged; circuit breaker tripped; device malfunction.	Ensure the desk's main power cord is fully plugged into a working wall outlet. Check your home's circuit breaker. Test the device on another outlet.
Drawers do not slide smoothly	Improper assembly; obstruction.	Ensure the fabric drawers are assembled correctly and nothing is obstructing their path.

9. SPECIFICATIONS

Feature	Detail
Brand	ODK
Model Number	B01171801003
Product Dimensions	18.9"D x 47.2"W x 35"H
Color	Carbon Fiber Black
Material	Carbon Fiber (Top), Metal (Base)
Special Features	Monitor Stand, Built-in Outlet, Built-in USB Port, Headphone Hook, LED Lights, Fabric Drawers, Reversible Design
Power Outlet	3 AC Outlets (125V/12A), 2 USB Ports (5V/2A)
Item Weight	14.8 Kilograms
Assembly Required	Yes (Tools Included)

10. WARRANTY AND SUPPORT

ODK products come with a standard manufacturer's warranty. For specific warranty details, claims, or technical support,

please refer to the warranty card included with your product or visit the official ODK website. You can also contact ODK customer service through the retailer where you purchased the product.
For further assistance, please visit the [ODK Store on Amazon](#).

© 2025 ODK. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question