Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bubbacare Solarbetriebener

Bubbacare Solar-Powered Ultrasonic Bark Control Device User Manual

Model: Solarbetriebener

1. Introduction

Thank you for choosing the Bubbacare Solar-Powered Ultrasonic Bark Control Device. This device is designed to help manage excessive barking in dogs by emitting a safe, high-frequency ultrasonic sound that is typically inaudible to humans. Please read this manual thoroughly before use to ensure proper operation and maximize effectiveness.



Image 1.1: The Bubbacare Solar-Powered Ultrasonic Bark Control Device shown with a dog, illustrating its intended use.

2. Product Overview and Package Contents

The Bubbacare Bark Control Device features a robust design suitable for both indoor and outdoor use. It incorporates solar charging capabilities and multiple ultrasonic speakers for effective coverage.

2.1 Device Components




Image 2.1: A detailed view of the device highlighting its key components: 1. Display, 2. ON/OFF switch, 3. Sensors, 4. Type-C charging port, 5. 3 Levels Operation knob, 6. Solar charging panel, 7. Ultrasonic Speakers (x3).

2.2 Package Contents

Upon unpacking, please ensure all items are present:

- 1x Bubbacare Ultrasonic Bark Control Device
- 1x USB Type-C Charging Cable
- 1x User Manual



Image 2.2: The device, USB cable, and user manual as included in the product packaging.

3. Features

- **Solar-Powered:** Equipped with a solar charging panel for continuous outdoor operation.
- **Adjustable Frequencies:** Three distinct ultrasonic frequency modes (23-27kHz, 25kHz, 25kHz) to prevent dogs from becoming accustomed to the sound.
- **Wide Coverage:** Effective barking control range of up to 50 feet (approximately 15 meters).
- **IPX5 Waterproof:** Designed to withstand splashes and rain, suitable for outdoor use in various weather conditions.
- **Long Battery Life:** Built-in 2000mAh battery provides up to 90 days of standby time on a full charge.
- **Suitable for Most Dogs:** Effective for dogs between 6 months and 8 years old.*Note: Not effective for deaf or hearing-impaired dogs.*



Image 3.1: The device illustrating its solar charging capability and effective range of 50 feet.



Image 3.2: The device shown in a rainy environment, emphasizing its IPX5 waterproof design for outdoor use.



Image 3.3: An illustration showing the device's compatibility with various dog breeds, with a specific note that it is not effective for deaf or hearing-impaired dogs.

4. Setup and Installation

4.1 Initial Charging

Before first use, it is recommended to fully charge the device using the provided USB Type-C cable. Connect the cable to the Type-C port (4) on the device and a standard USB power adapter (not included). A full charge typically takes approximately 4 hours.

4.2 Placement Guidelines

For optimal performance, place the device in an area where the dog's barking is most frequent and within the 50-foot effective range. Ensure the ultrasonic speakers (7) are facing the area where the dog barks. The device can be mounted on a wall or fence using the integrated hanging holes, or placed on a flat surface.

- **Outdoor Use:** Position the device in an open area, ensuring the solar panel (6) receives direct sunlight for efficient charging. Avoid placing it behind obstacles that could block the ultrasonic waves.

- **Indoor Use:** Place the device in a central location within the room where barking occurs.



Image 4.1: Examples of the device being used in indoor environments, such as a living room, dog home, and bedroom.

5. Operating Instructions

5.1 Powering On/Off

Locate the ON/OFF switch (2) on the side of the device. Slide the switch to the 'ON' position to activate the device. Slide it to 'OFF' to power down.

5.2 Frequency Adjustment

The device offers three frequency modes to prevent dogs from becoming desensitized to the ultrasonic sound. Rotate the '3 Levels Operation' knob (5) to select the desired frequency:

- **Level I:** 25kHz (Constant)
- **Level II:** 25kHz (Variable pattern)
- **Level III:** 23-27kHz (Sweeping frequency)

It is recommended to change the frequency mode once a week to maintain effectiveness. The selected frequency will be shown on the display (1).



Image 5.1: The device display indicating the 25kHz frequency setting, along with a graphic showing different ultrasonic patterns for various modes and the recommended dog age range (6 months to 8 years).

5.3 Operation

Once powered on and a frequency is selected, the device will automatically detect barking within its range using its sensors (3). Upon detection, it will emit the chosen ultrasonic sound to deter the barking. The device is designed to activate only when barking is detected.

6. Charging

The device can be charged via its solar panel (6) or the Type-C charging port (4).

- **Solar Charging:** For outdoor use, ensure the solar panel is exposed to direct sunlight for optimal charging.
- **USB Type-C Charging:** For faster charging or when sunlight is limited, use the provided USB Type-C cable to connect to a power source.

The display (1) will indicate the battery status.

7. Maintenance

- Clean the device regularly with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure the solar panel is kept clean and free of debris to maintain charging efficiency.
- While the device is IPX5 waterproof, avoid submerging it in water.

8. Troubleshooting

Problem	Possible Cause	Solution
Device not turning on	Low battery or OFF switch engaged	Charge the device fully. Ensure the ON/OFF switch is in the 'ON' position.
Device not effective	Incorrect placement, dog is deaf/hearing impaired, or dog is accustomed to frequency	Reposition the device closer to the barking area. Change the frequency mode. Confirm the dog's hearing ability.
Short battery life	Insufficient solar charging or frequent activation	Ensure solar panel is clean and receives direct sunlight. Charge via USB Type-C more frequently if used in low-light conditions or high-barking environments.

9. Specifications

- **Model:** Solarbetriebener
- **Battery:** Built-in 2000mAh
- **Charging Time:** Approximately 4 hours (USB-C)
- **Standby Time:** Up to 90 days
- **Effective Range:** Up to 50 feet (approx. 15 meters)
- **Frequency Modes:** 3 adjustable levels (23-27kHz, 25kHz, 25kHz)
- **Waterproof Rating:** IPX5
- **Number of Items:** 1

10. Important Safety Information

- This device is intended for use with dogs only. Do not use on other animals or for purposes other than bark control.
- Keep out of reach of children.
- Do not modify or disassemble the device. This may void the warranty and pose safety risks.
- Avoid prolonged exposure to extreme temperatures or direct sunlight beyond normal operating conditions.
- If the device appears damaged, discontinue use immediately.

11. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact your retailer. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F5H3ZQYL

More documents and user manuals: **https://manuals.plus/**