

MZEIBO tv soundbar

MZEIBO Sound Bar with Subwoofer User Manual

Model: tv soundbar

Brand: MZEIBO

INTRODUCTION

Thank you for purchasing the MZEIBO Sound Bar with Subwoofer. This manual provides essential information for setting up, operating, and maintaining your new audio system. Please read it thoroughly before use to ensure optimal performance and longevity of your device.



Image: The MZEIBO sound bar, its accompanying wireless subwoofer, and the remote control, illustrating the complete system.

PACKAGE CONTENTS

Before proceeding with the setup, please verify that all items listed below are included in your package:

- MZEIBO Sound Bar (detachable into two tower speakers)
- Wireless Subwoofer
- Remote Control
- Power Supply
- HDMI Cable (ARC compatible)
- Optical Cable
- AUX Cable
- Quick User Guide
- User Manual (this document)
- Stand Bases (for tower configuration)
- Wall Plugs and Screws (for wall mounting)



Image: A flat lay of all components included in the MZEIBO sound bar package, including the sound bar, subwoofer, remote, cables, and mounting hardware.

PRODUCT FEATURES

- **Powerful 2.1CH Sound System with Deep Bass:** Experience immersive audio with 120W peak power and a powerful subwoofer that delivers rich, deep bass, ideal for movies, music, and games.

Extra 60W Subwoofer Epic Deep Bass

60Hz




Image: A detailed view of the subwoofer, highlighting its internal components and the powerful bass output at 60Hz.

- **Detachable Design – Use Together or Separately:** The sound bar can be used as a single unit or detached into two separate tower speakers, offering flexible placement options to suit your space and audio preferences.



Image: Two configurations of the sound system: as a single sound bar unit and as two separate tower speakers with the subwoofer, demonstrating its versatile design.

- **Multiple Connection Options:** Easily connect to your TV, PC, gaming console, or other devices using ARC, Optical, or AUX inputs.



Image: A close-up view of the sound bar's rear panel, showing the DC IN, OPT (Optical), AUX, and ARC (HDMI) connection ports.

- **Bluetooth 5.0 Wireless Streaming:** Stream your favorite music wirelessly with stable, high-quality Bluetooth 5.0 transmission, perfect for home parties or casual listening.
- **Easy Setup with Remote Control:** Set up your sound system in minutes. The included remote control allows for convenient volume, input, and EQ mode adjustments.

SETUP GUIDE

1. Sound Bar Assembly

The MZEIBO Sound Bar offers two primary configurations:

1. **Single Sound Bar:** Keep the two halves of the sound bar connected. Ensure the central connection point is securely fastened.
2. **Two Tower Speakers:** Gently detach the two halves of the sound bar. Attach the provided stand bases to the bottom of each speaker half. Place them upright on a flat, stable surface.

2. Subwoofer Placement

Place the wireless subwoofer on the floor, ideally near the sound bar or your TV. Ensure it has adequate ventilation and is not obstructed.

3. Power Connection

1. Connect the power adapter to the "DC IN" port on the sound bar.
2. Plug the power adapter into a wall outlet.
3. Connect the subwoofer to its power source. The subwoofer will automatically pair with the sound bar when both are powered on.

4. Connecting to Your TV/Device

Choose one of the following connection methods:

1. HDMI ARC (Recommended):

Connect one end of the HDMI cable to the "ARC" port on the sound bar and the other end to the "HDMI ARC" port on your TV. This allows for audio return channel functionality, controlling the sound bar with your TV remote.

2. Optical:

Connect one end of the Optical cable to the "OPT" port on the sound bar and the other end to the Optical Digital Audio Out port on your TV. Ensure your TV's audio output is set to "PCM" if you experience no sound.

3. AUX (3.5mm):

Connect one end of the AUX cable to the "AUX" port on the sound bar and the other end to the 3.5mm audio output (headphone jack) on your TV or device.

4. Bluetooth:

Power on the sound bar. Select the Bluetooth input mode using the remote or buttons on the sound bar. On your device (phone, tablet, PC), search for "MZEIBO Sound Bar" in the Bluetooth settings and pair. The sound bar will indicate successful pairing.



Image: An illustration showing various devices (TV, projector, desktop, laptop, tablet, mobile phone) connecting to the sound bar via Bluetooth, ARC, Optical, and 3.5mm Aux inputs.

OPERATING INSTRUCTIONS

Power On/Off

Press the **Power** button on the remote control or the sound bar to turn the unit on or off.

Input Selection

Press the **Input** button on the remote control or the sound bar to cycle through available input sources: ARC, Optical, AUX, and Bluetooth.

Volume Control

Use the **Volume Up (+)** and **Volume Down (-)** buttons on the remote or sound bar to adjust the volume. Press the **Mute** button to temporarily silence the audio.

EQ Modes

The sound bar features optimized sound modes for different content types. Press the corresponding EQ mode button on the remote control to switch between:

- **News Mode:** Enhances vocal clarity for news broadcasts and dialogue-heavy content.
- **Movie Mode:** Provides a more dynamic and immersive soundstage for films, with enhanced bass and surround effects.
- **Music Mode:** Optimizes audio for music playback, delivering balanced highs, mids, and lows.



Image: A visual representation of the three sound effects modes: News, Movie, and Music, each depicted with a relevant screen content example.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your MZEIBO Sound Bar system.

- **Cleaning:** Use a soft, dry cloth to wipe down the surfaces of the sound bar and subwoofer. Do not use liquid cleaners, sprays, or abrasive materials, as they may damage the finish or internal components.
- **Ventilation:** Ensure the subwoofer and sound bar have adequate airflow. Do not block any ventilation openings.
- **Placement:** Avoid placing the unit in direct sunlight, near heat sources, or in areas with high humidity or dust.
- **Power Off:** If the unit will not be used for an extended period, unplug it from the power outlet.

TROUBLESHOOTING

If you encounter issues with your MZEIBO Sound Bar, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No Power	Power cable not connected; outlet not working.	Ensure power cable is securely plugged into the sound bar and a working wall outlet.

Problem	Possible Cause	Solution
No Sound	Incorrect input selected; volume too low; TV audio settings incorrect; cable loose.	<ul style="list-style-type: none"> Verify the correct input source (ARC, Optical, AUX, Bluetooth) is selected. Increase the volume on both the sound bar and your TV. For Optical connection, set TV audio output to "PCM". Check all audio cables for secure connections.
Bluetooth Disconnection/Cannot Pair	Device too far; interference; sound bar not in pairing mode.	<ul style="list-style-type: none"> Ensure the sound bar is in Bluetooth pairing mode. Move your Bluetooth device closer to the sound bar. Clear previous Bluetooth pairings on your device and try again. Restart both the sound bar and your Bluetooth device.
Subwoofer Not Producing Bass	Subwoofer not powered; not paired with sound bar.	<ul style="list-style-type: none"> Ensure the subwoofer is plugged in and powered on. The subwoofer should automatically pair. If not, power cycle both the sound bar and subwoofer.

SPECIFICATIONS

Feature	Detail
Brand	MZEIBO
Model Name	tv soundbar
Speaker Type	Soundbar with Subwoofer
Speaker Maximum Output Power	120 Watts
Connectivity Technology	Bluetooth 5.0, HDMI (ARC), Optical, AUX (3.5mm)
Audio Output Mode	Stereo (2.1 Channel)
Frequency Response	20 KHz (upper limit provided)
Product Dimensions	33"D x 2.36"W x 2.36"H (Soundbar)
Item Weight	12.36 pounds
Mounting Type	Tabletop Mount / Wall Mount (with included hardware)

WARRANTY AND SUPPORT

Limited Warranty

MZEIBO products are manufactured to the highest quality standards. This product is covered by a limited warranty against defects

in materials and workmanship from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear.

Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact MZEIBO customer support. Refer to the contact information provided on the product packaging or the official MZEIBO website. When contacting support, please have your product model number and purchase date available.

© 2025 MZEIBO. All rights reserved.