

[Manuals.plus](#) /

› [WUNIAK](#) /

› WUNIAK Soft Silicone Protective Case for Garmin GPSMAP 64S/62s/63 User Manual

WUNIAK 65s/62s/63

WUNIAK Soft Silicone Protective Case User Manual

For Garmin GPSMAP 64S, 62s, and 63 Series GPS Handheld Devices

INTRODUCTION

This manual provides instructions for the proper use and maintenance of your WUNIAK Soft Silicone Protective Case. This case is designed to safeguard your Garmin GPSMAP 64S, 62s, or 63 series GPS handheld device from scratches, bumps, and drops, ensuring its longevity and performance.

COMPATIBILITY

This protective case is specifically designed for and compatible with the following Garmin GPSMAP models:

- Garmin GPSMAP 65s
- Garmin GPSMAP 62s
- Garmin GPSMAP 63
- Garmin GPSMAP 62
- Garmin GPSMAP 62SC
- Garmin GPSMAP 621sC
- Garmin GPSMAP 631sC
- Garmin GPSMAP 6363sc
- Garmin GPSMAP 63csx
- Garmin GPSMAP 629sc
- Garmin GPSMAP 64
- Garmin GPSMAP 64S
- Garmin GPSMAP 64SC
- Garmin GPSMAP 64ST

Note: This case is not compatible with other GPS models.

KEY FEATURES

- **High-Quality Material:** Constructed from soft, durable, and elastic silicone material, offering comprehensive protection against scratches, bumps, and shocks. The surface is treated for anti-fingerprint and dustproof properties.
- **Precision Engineering:** Features laser-cut ports to ensure full access to charging interfaces, maintain button responsiveness, and preserve GPS signal stability. The non-slip texture enhances grip, especially in wet conditions.
- **360° Protection:** The soft silicone material is designed to absorb approximately 85% of impact force. A raised bezel design

further protects the equipment screen from scratches and drops during outdoor activities like mountain or gravel cycling.

- **Lightweight Design:** Adds minimal weight to your device, maintaining portability.

■ Lightweight and easy to use without adding weight



Image: The WUNIAK silicone case encasing a Garmin GPSMAP device, illustrating its lightweight and protective design.

Precise positioning

The perfect detail craftsmanship can not only reflect the use of the original machine, but also effectively protect the host



Image: A detailed view of the WUNIAK silicone case, emphasizing its precise cutouts for device functionality and ergonomic design.

Anti-drop and anti-bump

Perfect package. Ensure that the host unit is in the event of an impact. It can protect the host from collision and damage in an all-round way



Image: The WUNIAK silicone case shown in an anti-drop scenario, illustrating its ability to protect the device from impacts.

INSTALLATION INSTRUCTIONS

Installing the WUNIAK protective case is a straightforward process due to its flexible design.

1. Ensure your Garmin GPSMAP device is clean and free of dust or debris.
2. Gently align the top of your GPSMAP device with the top opening of the silicone case.
3. Carefully slide the device into the case, ensuring all edges and corners are properly seated within the silicone.
4. Adjust the case as needed to ensure all ports, buttons, and the screen are correctly aligned with the case's cutouts. The flexible nature of the silicone allows for easy adjustment.
5. Verify that the case fits snugly around your device, providing full protection without obstructing any functions.

Easy to install

Reasonable design can ensure that the operation during installation is simpler, and it can be gently put on it



Image: The WUNIAK silicone case, illustrating its simple and gentle installation process for the GPS device.

USAGE AND HANDLING

Once installed, the WUNIAK protective case allows for normal operation of your Garmin GPSMAP device while providing

enhanced protection.

- The case's design ensures that all buttons remain responsive and accessible.
- Charging ports are unobstructed, allowing for convenient power access.
- The silicone material provides an improved grip, reducing the risk of accidental drops during outdoor use.
- The raised bezel protects the screen from direct impact when placed face down.



Image: A Garmin GPSMAP device securely fitted within the WUNIAK case, positioned on a desk, demonstrating its seamless integration.



Image: A hand holding a Garmin GPSMAP device protected by the WUNIAK case in an outdoor setting, highlighting its suitability for rugged use.

CARE AND MAINTENANCE

To ensure the longevity and appearance of your WUNIAK silicone case, follow these simple care instructions:

- **Cleaning:** The silicone material is easy to clean. Use a soft, damp cloth with mild soap and water to wipe down the case. Avoid harsh chemicals or abrasive cleaners, as these can damage the material.
- **Stain Resistance:** The surface is treated to be resistant to oil stains and fingerprints, making it easier to keep clean.
- **Durability:** The case is designed to be durable and resistant to deformation, maintaining its shape and protective qualities over time.

Excellent material

Good material ensures a comfortable experience during use



Easy to clean



Resistant
to oil stains



It is not easy
to deform



Image: An illustration highlighting the excellent material properties of the WUNIAK case, including ease of cleaning, resistance to oil stains, and anti-deformation.

If you encounter any issues with your WUNIAK protective case, consider the following:

- **Improper Fit:** Ensure the case is correctly aligned and fully seated around your GPSMAP device. Remove the device and re-install the case, making sure to gently stretch and position it over all edges.
- **Button Obstruction:** If buttons are not responsive, check for any misalignment of the case. Adjust the case slightly to ensure the button cutouts are perfectly aligned.
- **Damage:** In the event of significant impact or damage to the case, inspect it for cracks or tears. While designed for durability, extreme forces can compromise its protective integrity.

For further assistance, please refer to the "Warranty and Support" section.

PRODUCT SPECIFICATIONS

Brand	WUNIAK
Model Number	65s/62s/63 (Compatible with Garmin GPSMAP 64S/62s/63 series)
Color	BLACK
Compatible Devices	Garmin GPSMAP 65s/62s/63/62/62SC/621sC/631sC/6363sc/63csx/629sc/64/64S/64SC/64ST
Form Factor	Case
Shell Type	Soft
Material	Silicone
Additional Features	Heavy Duty Protection, Slim Fit, Scratch Resistant, Shock Resistant, Anti-fingerprint, Dustproof
Item Dimensions (Approx.)	0.1 x 0.1 x 0.1 inches

WARRANTY AND SUPPORT

WUNIAK is committed to customer satisfaction. If you have any questions, concerns, or require assistance with your product, please contact WUNIAK customer support. Refer to the product packaging or the retailer's website for specific contact information. The package includes one (1) GPS handheld case. The GPS handheld device is not included.

© 2024 WUNIAK. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F5HJF7ZG>

More documents and user manuals: <https://manuals.plus/>