

[Manuals.plus](#) /

› [XP-Pen](#) /

› XPPen Magic Note Pad 10.95-inch Standalone Drawing Tablet User Manual

XP-Pen MNP1095

XPPen Magic Note Pad 10.95-inch Standalone Drawing Tablet User Manual

Model: MNP1095

1. INTRODUCTION

The XPPen Magic Note Pad is a versatile 10.95-inch standalone drawing tablet designed for sketching, drawing, and digital note-taking. It combines the tactile feel of traditional paper with the advanced capabilities of an Android 14 device, offering a seamless creative and productivity experience.

Key features include a realistic X-Paper display, 16K pressure sensitivity with the X3 Pro battery-free Pencil 2, multiple color modes, and eye-protection technology.



Image 1.1: XPPen Magic Note Pad with X3 Pro Pencil 2 and essential accessories.

2. PACKAGE CONTENTS

Before you begin, please verify that all items are present in your package:

- XPPen Magic Note Pad (10.95-inch tablet)
- Magnet Folio

- X3 Pro Pencil 2
- Replacement Nibs (8 pieces)
- USB-C Cable
- Power Adapter
- Quick Guide
- Warranty Card
- Nib Extractor

Perfect Accessory for Creation



Magic Note Pad
x1



Magnet Folio
x1



X3 Pro Pencil 2
x1



Replacement Nibs
x8



USB-C Cable
x1



Power Adapter
x1



Quick Guide
x1



Warranty Card
x1



Nib Extractor
x1

Image 2.1: Detailed view of all items included in the product package.

3. SETUP GUIDE

3.1 Initial Power On

1. Unpack the XPPen Magic Note Pad and all accessories.
2. Press and hold the power button (usually located on the side or top edge) until the XPPen logo appears on the screen.
3. Follow the on-screen prompts to complete the initial Android 14 setup, including language selection, Wi-Fi connection, and Google account login.

3.2 Charging the Device

Connect the provided USB-C cable to the tablet's USB-C port and the power adapter. Plug the power adapter into a wall outlet. The battery indicator on the screen will show charging status. A full charge is recommended before first use.

3.3 Using the X3 Pro Pencil 2

The X3 Pro Pencil 2 is battery-free and does not require pairing or charging. Simply pick it up and begin using it on the tablet screen. It features 16384 pressure levels and tilt support for precise control in drawing and writing applications.



Image 3.1: Features of the X3 Pro Pencil 2, including pressure sensitivity and shortcut keys.

4. OPERATING INSTRUCTIONS

4.1 Display Modes

The Magic Note Pad offers three distinct color modes to optimize your viewing and creative experience:

- **Nature Mode:** Presents original colors vividly, ideal for general use and annotating notes.
- **Light Color Mode:** Features low saturation for sketching and reduced eye fatigue.
- **Black & White Mode:** Provides a paper-like black-and-white display for immersive reading and focused grayscale art.

Three Color Modes for Immersive Reading




Image 4.1: Visual representation of the three available display color modes.

Image 4.2: Example of using the Black & White Mode for grayscale artwork.

4.2 Eye Comfort Features

The tablet's 10.95-inch X-Paper display features AG nano-etching technology and is TÜV-certified for low blue light and anti-glare. This design reduces eye strain and ambient light interference, providing a comfortable viewing and writing experience even during

AG Nano-etched Screen is Friendly for Your Eyes



Feels like drawing on paper



Without Anti-glare Screen



With Anti-glare Screen

Image 4.3: Anti-glare screen technology reduces reflections for better visibility.

Exceptional Eye Comfort

The AG nano-etched display comes with TCL NXTpaper 3.0 technology and two TÜV SÜD certifications, reducing up to 95% of ambient light interference and 75% of harmful blue light effectively when you read or write.



TÜV SÜD Low Blue
Light Certification



TÜV SÜD Paper-like
Display Certification

Image 4.4: The tablet's display is certified for eye comfort and a paper-like experience.

4.3 Applications and Creativity

Running on Android 14, the Magic Note Pad allows you to download a wide range of applications from the Google Play Store. This includes popular creative apps for sketching and drawing, as well as productivity tools for note-taking and PDF annotation.

Drawing Anytime Anywhere

Portable, efficient, and perfect for sketching, designing, and grayscale art.




Image 4.5: The tablet supports various creative applications for drawing and sketching.

Image 4.6: Access a wide range of applications through the Google Play Store.

4.4 XPPen Notes App

The XPPen Notes app is pre-installed and offers a lifetime free membership. It provides multi-brush tools, multi-color selections, and features like AI Assistant, recording that follows handwriting, and PDF import/editing, enhancing your note-taking and

XPPen Notes Permanent Membership for You

XPPen Notes, the powerful native note-taking app, Multi-brush tools, and multi-color selections help you take notes and annotate PDF documents. Just enjoy seamless note-taking for free!



- AI Assistant
- Recording Follows Handwriting
- Wake Inspiration by One Click
- Convert Handwriting to Text
- Multiple Pen Brushes Selection
- Screen Splitting
- Pen Floating Button
- Device & Cloud Storage
- PDF Files Import & Editing

Image 4.7: Overview of the XPPen Notes app features for enhanced productivity.

4.5 Split-Screen Functionality

Utilize the split-screen feature to view multiple applications or documents simultaneously. This is particularly useful for referencing images while drawing or taking notes alongside a presentation.



Image 4.8: Using split-screen mode for drawing with reference images.

4.6 Portability

Weighing only 495g and with a thickness of 7mm, the Magic Note Pad is designed for portability, allowing you to carry your creative tools wherever inspiration strikes.



Image 4.9: The tablet's slim and lightweight design for on-the-go use.

5. MAINTENANCE

5.1 Cleaning the Screen

To clean the screen, gently wipe it with a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaning solution. Avoid harsh chemicals or abrasive materials.

5.2 Replacing Stylus Nibs

Over time, the stylus nib may wear down. Use the included nib extractor tool to carefully pull out the old nib. Insert a new replacement nib firmly into the stylus until it clicks into place.

5.3 Battery Care

To prolong battery life, avoid exposing the tablet to extreme temperatures. For long-term storage, charge the battery to approximately 50% and power off the device.

6. TROUBLESHOOTING

6.1 Tablet Does Not Power On

- Ensure the tablet is sufficiently charged. Connect it to the power adapter and wait a few minutes before attempting to power on again.
- Press and hold the power button for 10-15 seconds to perform a forced restart.

6.2 Stylus Not Responding

- Check if the stylus nib is properly seated. Replace it if it appears worn or damaged.
- Ensure the stylus is within the active area of the screen.
- Restart the tablet.

6.3 Screen Freezes or Apps Crash

- Close any background applications that may be consuming excessive resources.
- Restart the tablet.
- If the issue persists, consider performing a factory reset (backup your data first).

7. SPECIFICATIONS

Portable Tablet for Your Creativity

1920x1200

Resolution

90Hz

Refresh Rate

16.7 Million

Colors

207

PPI



Image 7.1: Key display and performance specifications.



Image 7.2: Additional hardware specifications of the XPPen Magic Note Pad.

General Specifications

Brand	XP-Pen
-------	--------

Model Name	MNP1095
Operating System	Android 14
Screen Size	10.95 Inches
Screen Resolution	1920 x 1200 pixels
Refresh Rate	90Hz
Colors	16.7 Million
Stylus Pressure Levels	16384
Item Weight	495g (1.09 lbs)
Thickness	7mm
Battery	8000mAh
Wireless Type	802.11a/b/g/n/ac
Processor Brand	ARM

8. WARRANTY AND SUPPORT

Your XPPen Magic Note Pad comes with a Warranty Card included in the package. Please refer to this card for detailed information regarding warranty coverage, terms, and conditions.

For technical support, product registration, or further inquiries, please visit the official XP-Pen website or contact their customer service department. Contact information can typically be found on the warranty card or the manufacturer's website.

Online resources, including FAQs and driver downloads, may also be available on the official support page.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question