Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VEVOR P870B

VEVOR P870B Mattress Vacuum Cleaner User Manual

Model: P870B

1. Introduction

Thank you for choosing the VEVOR P870B Mattress Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your device. Please read it thoroughly before first use and keep it for future reference.
The VEVOR P870B is a powerful 550W handheld vacuum cleaner designed specifically for mattresses, beds, and upholstery. It features 18Kpa suction, a high-speed roller brush, HEPA filtration, and a 60°C hot air function for deep cleaning and odor removal.

2. Important Safety Instructions

- Read all instructions before using this appliance.
- Always disconnect from the power supply before cleaning or performing maintenance.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with a damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.

- Do not use without dust bin and filters in place.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Store the appliance indoors.
- The heating function only works when the machine is in direct contact with the mattress.

3. Package Contents

Upon unpacking, please verify that all items listed below are present and in good condition:

- VEVOR P870B Mattress Vacuum Cleaner Unit
- HEPA Filter (pre-installed)
- Extra HEPA Filter
- Mini Cleaning Brush
- Aromatherapy Pads (x4)
- User Manual



Image: The VEVOR P870B Mattress Vacuum Cleaner, showcasing its design and primary components.

4. Product Diagram and Components

Familiarize yourself with the parts of your VEVOR P870B Mattress Vacuum Cleaner:



Image: Detailed diagram highlighting key features such as the 550W motor, 18Kpa strong suction, 27000r/min roller brush, cleaning light, ultrasound, 60°C warm air system, and dual cup filtration system with HEPA filter and dust collection bin.

- **Power Button:** To turn the vacuum on/off.
- **Mode Selection Button:** To switch between cleaning modes.
- **LED Smart Display:** Shows working status and selected functions.
- **Dust Bin:** Collects dust and debris. Features dual cup filtration.

- **HEPA Filter:** Captures fine particles.
- **Roller Brush:** High-speed silicone brush for effective cleaning and preventing hair tangling.
- **Hot Air Outlet:** Emits 60°C warm air for dehumidification and fragrance diffusion.
- **Cleaning Lights:** Illuminates the cleaning area.

5. Setup

Before first use, ensure the vacuum cleaner is properly assembled and ready for operation.

1. **Unpack:** Carefully remove all components from the packaging.
2. **Check Filters:** Ensure the HEPA filter and dust bin are correctly installed in the unit.
3. **Power Connection:** Plug the power cord into a standard 110V electrical outlet. The unit is corded electric.
4. **Optional Aromatherapy:** If desired, insert an aromatherapy pad into the designated slot near the hot air outlet for a fresh fragrance during cleaning.

6. Operating Instructions

Follow these steps for effective cleaning with your VEVOR P870B Mattress Vacuum Cleaner.

6.1 Powering On and Mode Selection

1. Press the power button to turn on the vacuum cleaner. The LED smart display will illuminate, showing the current working status.
2. Use the mode selection button to cycle through available cleaning modes, if applicable. The display will indicate the selected mode.

6.2 Cleaning Surfaces

The VEVOR P870B is designed for various soft surfaces:

- **Mattresses:** Glide the vacuum cleaner slowly and evenly across the mattress surface. The powerful suction and roller brush will remove dust, hair, and skin flakes. The 60°C hot air function will activate upon contact, aiding in dehumidification and odor removal.
- **Sofas and Upholstery:** Use the vacuum cleaner on fabric sofas, chairs, and other upholstered furniture to remove dust and allergens.
- **Pet Beds:** Effectively clean pet beds to remove pet hair and dander.
- **Baby Bedding:** Maintain a clean environment for baby bedding by regularly vacuuming.




Image: This illustration demonstrates the versatility of the VEVOR P870B, showing its application on mattresses, couches, pet beds, and baby bedding for comprehensive cleaning.

6.3 Hot Air Function

The 60°C hot air feature helps to dehumidify and remove odors from fabrics. This function is automatically activated when the vacuum head is in direct contact with the surface being cleaned.



Image: An illustration depicting the 60°C warm air dehumidification system in action, along with the inclusion of aromatherapy pads for a fresh fragrance.

7. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

7.1 Emptying the Dust Bin

1. Ensure the vacuum cleaner is unplugged from the power outlet.
2. Press the release button to detach the dust bin from the main unit.
3. Open the dust bin and empty its contents into a waste receptacle.

7.2 Cleaning Filters and Dust Bin

The HEPA filter and dust bin are detachable and washable.

1. After emptying, separate the HEPA filter from the dust bin.
2. Rinse the HEPA filter and dust bin under running water until clean.
3. Allow all parts to air dry completely before reassembling and reattaching to the vacuum cleaner. Do not use the vacuum with wet filters.
4. It is recommended to replace the HEPA filter every 3-6 months to maintain optimal suction performance. An extra HEPA filter is included for convenience.




Image: A visual guide demonstrating the process of disassembling, emptying, and cleaning the dustbin and roller brush components of the vacuum cleaner.

7.3 Cleaning the Roller Brush

The full silicone roller brush is designed to prevent hair tangling, but occasional cleaning may be necessary.

1. Ensure the vacuum cleaner is unplugged.
2. Press the release button to eject and remove the roller brush from the vacuum head.

3. Use the provided mini cleaning brush or a pair of scissors to remove any tangled hair or debris from the roller brush.
4. Rinse the roller brush if necessary and allow it to air dry completely before reinserting.

8. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on.	Not plugged in; power outlet malfunction; damaged cord/plug.	Ensure the power cord is securely plugged into a working outlet. Check for damage to the cord or plug.
Loss of suction.	Full dust bin; clogged filter; blocked roller brush/nozzle.	Empty the dust bin. Clean or replace the HEPA filter. Check the roller brush and nozzle for blockages and clear them.
Hot air function not working.	Vacuum not in direct contact with surface.	Ensure the vacuum head is pressed firmly against the mattress or fabric surface. The heating function activates upon contact.
Unusual noise during operation.	Foreign object in roller brush; motor issue.	Turn off and unplug the vacuum. Inspect the roller brush area for any foreign objects and remove them. If the noise persists, contact customer support.

9. Specifications

Model Number	P870B
Brand	VEVOR
Rated Power	550W
Vacuum Degree	18KPa
Roller Brush Speed	27,000 rpm
Heating Temperature	60°C / 140°F
Maximum Capacity (Dust Bin)	650 ml
Filter Type	HEPA Filter (2 Layers: HEPA + Stainless Steel Mesh)
Power Source	Corded Electric
Voltage	110 volts
Noise Level	80 dB
Item Weight	4.2 lbs / 1.9 kg
Product Dimensions (L x W x H)	10.6"L x 9.1"W x 8.3"H (270 x 230 x 210 mm)
Main Materials	ABS, 304 Stainless Steel, Aluminum Alloy
UPC	197988871903



Image: An image detailing the physical dimensions and key technical specifications of the VEVOR P870B mattress vacuum cleaner.

10. Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or visit the official VEVOR website. Keep your purchase receipt as proof of purchase.

VEVOR Official Website: www.vevor.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F5NSSTC1

More documents and user manuals: **https://manuals.plus/**