



1752898

## Generic L.a.Z.-Boy Manager Office Chair

Model: 1752898

### INTRODUCTION

---

This instruction manual provides essential information for the assembly, operation, and maintenance of your new Generic L.a.Z.-Boy Manager Office Chair. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of the product. Retain this manual for future reference.



Figure 1: The Generic L.a.Z.-Boy Manager Office Chair, featuring a black faux leather finish and ergonomic design.

## PRODUCT FEATURES

---

The Generic L.a.Z.-Boy Manager Office Chair is designed for comfort and functionality, incorporating several key features:

- **Padded Flip-Up Arms:** Armrests can be raised to allow the chair to be pushed closer to a desk or for easier entry/exit.
- **Integrated Controls:** Conveniently located controls for quick recline and tilt adjustments.
- **Pneumatic Height Adjustment:** A gas lift mechanism provides a 3.75-inch range for seat height adjustment.
- **360° Dual-Wheel Swivel Casters:** Smooth-rolling casters allow for easy movement across various floor surfaces.
- **Mid-Back Design:** Provides support for the mid-to-upper back.
- **Faux Leather Material:** Durable and easy-to-clean upholstery.
- **Weight Capacity:** Supports up to 275 pounds.




Figure 2: Close-up view of the padded flip-up armrest in its raised position, allowing for versatile use.




Figure 3: Detailed view of the comfortable, padded armrest, designed for forearm support.




Figure 4: Close-up of the generously padded seat cushion, upholstered in black faux leather.

## SETUP AND ASSEMBLY

---

Assembly of the L.a.Z.-Boy Manager Office Chair typically involves a few straightforward steps. While specific instructions may vary, the general process is as follows:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all components are present according to the packing list (not provided in this manual).
2. **Assemble Base:** Insert the dual-wheel swivel casters into the holes at the end of each leg of the chair base. Ensure they are securely seated.
3. **Install Gas Lift:** Place the pneumatic gas lift cylinder into the center hole of the assembled chair base.
4. **Attach Seat Mechanism:** Secure the seat mechanism to the underside of the seat cushion using the provided screws. Ensure the front of the mechanism aligns with the front of the seat.
5. **Connect Backrest:** Attach the backrest to the seat mechanism or seat plate using the designated screws.
6. **Attach Armrests:** Secure the padded flip-up armrests to both the seat and backrest using the provided hardware.
7. **Mount Seat to Base:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring it is

centered and fully seated.

After assembly, sit on the chair to ensure all components are properly engaged and stable.

## OPERATING INSTRUCTIONS

---

Familiarize yourself with the chair's adjustment mechanisms for optimal comfort.

### 1. Seat Height Adjustment

To adjust the seat height, locate the lever on the right side, beneath the seat. While seated, pull the lever up to lower the seat. To raise the seat, stand up slightly to relieve weight from the seat, then pull the lever up. Release the lever at the desired height.

### 2. Recline and Tilt Adjustment

The chair features integrated controls for recline and tilt. A lever, typically located on the left side, controls the tilt lock. Pull the lever out to allow the chair to recline and tilt freely. Push the lever in to lock the chair in an upright position. A tension knob, usually located at the front center beneath the seat, adjusts the resistance of the recline motion. Turn clockwise to increase tension (more resistance) and counter-clockwise to decrease tension (less resistance).




Figure 5: Illustration of the chair's reclining capability, demonstrating the range of motion.

### 3. Flip-Up Armrests

The armrests can be flipped up and out of the way. To do so, grasp the armrest and pivot it upwards until it locks into a vertical position. To return it to the down position, gently pull it down.

## MAINTENANCE

---

Proper maintenance ensures the longevity and appearance of your office chair.

- **Cleaning:** The faux leather material should be spot cleaned. Use a soft, damp cloth with mild soap and water for spills or stains. Avoid harsh chemicals or abrasive cleaners, as these can damage the upholstery.
- **Caster Care:** Periodically check the dual-wheel swivel casters for accumulated hair or debris. Clean them as needed to ensure smooth rolling.
- **Hardware Check:** Every few months, inspect all screws and bolts to ensure they are tight. Re-tighten any loose hardware to maintain stability and safety.
- **Lubrication:** If any moving parts, such as the gas lift or tilt mechanism, begin to squeak, a small amount of silicone-based lubricant can be applied to the pivot points.

## TROUBLESHOOTING

---

This section addresses common issues you might encounter with your office chair.

- **Chair Sinks or Does Not Hold Height:** This typically indicates an issue with the pneumatic gas lift cylinder. Ensure the height adjustment lever is not stuck in the 'up' position. If the problem persists, the gas lift may need replacement.
- **Chair Squeaks:** Loose hardware is a common cause of squeaking. Check and tighten all screws and bolts, especially those connecting the seat, back, and armrests. Lubricate moving parts if necessary.
- **Casters Do Not Roll Smoothly:** Inspect casters for debris (hair, lint, etc.) wrapped around the wheels. Clean them thoroughly. Ensure the casters are fully inserted into the chair base.
- **Chair Does Not Recline or Tilt:** Verify that the tilt lock lever is disengaged (pulled out). Adjust the tilt tension knob to ensure it is not set too tightly.

## SPECIFICATIONS

---

Detailed specifications for the Generic L.a.Z.-Boy Manager Office Chair Model 1752898:



Figure 6: Diagram illustrating the key dimensions of the office chair.

| Attribute                      | Value                    |
|--------------------------------|--------------------------|
| Brand                          | Generic                  |
| Model Name                     | 1752898                  |
| Product Dimensions (D x W x H) | 29.25" x 28.75" x 41.25" |
| Item Weight                    | 41.9 pounds              |
| Maximum Weight Recommendation  | 275 Pounds               |
| Material                       | Faux Leather             |
| Color                          | Black                    |
| Back Style                     | Modern Mid-Back          |
| Arm Style                      | Flared, Flip-Up          |
| Furniture Base Movement        | Swivel                   |

---

|                          |        |
|--------------------------|--------|
| Included Components      | Caster |
| Tilting                  | Yes    |
| Reclining Position Count | 2      |

## WARRANTY AND SUPPORT

---

Specific warranty details for the Generic L.a.Z.-Boy Manager Office Chair Model 1752898 are not provided within this manual. For information regarding warranty coverage, claims, or technical support, please refer to the product packaging or contact the retailer or manufacturer directly. Ensure you have your purchase receipt and model number (1752898) available when seeking support.