



Manuals.plus /

› Anbuy /

› Anbuy White Scalloped Nursery Chests and Dresser User Manual

Anbuy DC050

Anbuy White Scalloped Nursery Chests and Dresser User Manual

Model: DC050

Brand: Anbuy

PRODUCT OVERVIEW

The Anbuy White Scalloped Nursery Chests and Dresser is a versatile storage solution designed for bedrooms, nurseries, and hallways. Featuring a distinctive scalloped design and six spacious drawers, this dresser combines aesthetic appeal with practical functionality. It is constructed from wood and includes metal handles for durability and ease of use.



Figure 1: The Anbuy White Scalloped Nursery Dresser, showcasing its design and six drawers, positioned in a room with a lamp and plant.

SAFETY INFORMATION

To prevent serious or fatal crushing injuries, this product must be permanently attached to the wall with the wall attachment device provided. Always use the anti-tip kit. Never allow children to climb or hang on drawers, doors, or shelves. Place heaviest items in the lowest drawers. Do not place heavy objects on top of the dresser that could cause it to tip over. Always ensure drawers are closed when not in use.

Keep all small parts and packaging materials away from children during assembly.

SETUP AND ASSEMBLY

Before beginning assembly, ensure all parts are present and undamaged. It is recommended to assemble the dresser on a soft, clean surface to prevent scratches. Two people are recommended for assembly.

Tools Required:

- Phillips Head Screwdriver

- Hammer (for dowels, if applicable)
- Measuring Tape (optional, for placement)

Assembly Steps:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out and identify each part using the provided hardware list and diagrams.
2. **Assemble the Frame:** Begin by connecting the side panels to the top and bottom panels using the designated screws and dowels. Ensure all connections are secure and flush.
3. **Attach Back Panel:** Secure the back panel to the assembled frame. This often involves small nails or screws.
4. **Install Drawer Glides:** Attach the drawer glides to the interior sides of the dresser frame according to the pre-drilled holes. Ensure they are level and aligned.
5. **Assemble Drawers:** For each of the six drawers, assemble the front, back, and side panels. Insert the bottom panel into the grooves. Attach the drawer glides to the sides of the assembled drawers.
6. **Attach Handles:** Secure the metal handles to the front of each drawer.
7. **Insert Drawers:** Carefully slide each assembled drawer into its corresponding slot on the dresser frame. Test for smooth operation.
8. **Attach Feet:** Screw the solid wood feet into the designated points on the bottom of the dresser.
9. **Install Anti-Tip Kit:** Securely attach the anti-tip device to the back of the dresser and to a wall stud, following the specific instructions provided with the kit. This step is critical for safety.



Figure 2: Detail of the dresser's features, highlighting the smooth operation of the drawers and the sturdy solid wood feet.

OPERATING INSTRUCTIONS

The Anbuy dresser is designed for easy and reliable use. To operate the drawers, simply pull the metal handles to open and push to close. The smooth-gliding drawer slides ensure effortless access to your stored items.

- **Drawer Capacity:** Each drawer is designed to hold a reasonable amount of clothing or other items. Avoid overloading drawers, as this can strain the glides and affect their smooth operation.
- **Weight Distribution:** For optimal stability, distribute weight evenly across the drawers. Place heavier items in the lower drawers.
- **Opening Multiple Drawers:** For safety and stability, avoid opening more than one drawer at a time, especially the top drawers, unless the unit is securely anchored to a wall.

MAINTENANCE AND CARE

Proper care will ensure the longevity and appearance of your Anbuy dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish. Dry immediately with a clean cloth.
- **Spills:** Blot spills immediately with a clean, dry cloth to prevent staining or damage to the wood.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the finish.
- **Humidity:** Maintain a consistent humidity level in the room to prevent wood from warping or cracking.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Drawers stick or do not slide smoothly.	<ul style="list-style-type: none"> ◦ Overloaded drawer. ◦ Drawer glides are misaligned or damaged. ◦ Loose screws on glides or drawer. 	<ul style="list-style-type: none"> ◦ Reduce the weight in the drawer. ◦ Check alignment of glides; adjust or replace if damaged. ◦ Tighten all screws on drawer and frame glides.
Dresser wobbles or is unstable.	<ul style="list-style-type: none"> ◦ Uneven floor. ◦ Loose assembly screws. ◦ Anti-tip kit not installed or improperly installed. 	<ul style="list-style-type: none"> ◦ Place shims under feet to level. ◦ Retighten all assembly screws. ◦ Ensure anti-tip kit is correctly installed and anchored to a wall stud.
Scalloped design appears chipped or damaged.	<ul style="list-style-type: none"> ◦ Impact during shipping or assembly. ◦ Wear and tear. 	<ul style="list-style-type: none"> ◦ Contact customer support for replacement parts if damage is significant upon arrival. ◦ Minor chips may be touched up with furniture repair paint.

SPECIFICATIONS




Figure 3: Detailed dimensions of the dresser and its drawers.

Model Number: DC050

Color: White

Material: Wood

Overall Dimensions (W x H x D): 43.1 inches x 29.1 inches x 13.8 inches

Drawer Interior Dimensions (W x H x D): Approximately 19.2 inches x 7.8 inches x 12.6 inches

Net Weight: 71 lbs

Number of Drawers: 6

WARRANTY INFORMATION

Specific warranty details for the Anbuy White Scalloped Nursery Chests and Dresser are typically provided with your purchase documentation. Please refer to the warranty card or information included in your product packaging for terms, conditions, and duration of coverage. For any warranty claims or inquiries, retain your proof of purchase.

CUSTOMER SUPPORT

Should you have any questions regarding the assembly, operation, maintenance, or troubleshooting of your Anbuy dresser, please contact Anbuy customer support. For the most up-to-date contact information, please visit the official Anbuy store on Amazon or refer to the contact details provided in your product packaging.

You can visit the Anbuy store here:[Anbuy Store](#)