

[Manuals.plus](#) /

› [Ltinist](#) /

› Ltinist Wireless Earbuds User Manual

Ltinist BX29 (X29)

Ltinist Wireless Earbuds User Manual

Model: BX29 (X29)

INTRODUCTION

Thank you for choosing Ltinist Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your new earbuds. Please read this manual carefully before use to ensure optimal performance and longevity of your device.

WHAT'S IN THE BOX

- Ltinist Wireless Earbuds (Left and Right)
- Wireless Charging Case
- USB-C Charging Cable
- Ear Tips (S/M/L sizes)
- User Manual



Image: The Ltinist Wireless Earbuds in their charging case, showcasing the rose gold color and earhook design. The charging case displays battery levels.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge both the earbuds and the charging case. Connect the USB-C charging cable to the charging port on the case and a power source. The LED display on the case will show the charging status and battery percentage.

- **Case Battery Status:** Displayed as a percentage on the LED screen.
- **Earbud Battery Status:** Individual battery icons for left and right earbuds are shown on the LED screen.
- **Total Playtime:** Up to 75 hours with the charging case.
- **Single Charge Playtime:** Up to 15 hours.

75H Long Playtime & LED Power Display



Battery Status
of the Charging Case



Power Display of
the Headphones



Type-C Fast
Charging



 +  = 75H
15H 60H

 = 
1.5H 15H

Image: The charging case with its digital LED display showing the battery status of both the case and the individual earbuds, along with charging indicators.

2. Pairing with Your Device

The earbuds feature advanced Bluetooth 5.4 technology for quick and stable connections.

1. Ensure your device's Bluetooth is turned on.
2. Open the lid of the charging case. The earbuds will automatically enter pairing mode (indicated by flashing lights on the earbuds).
3. On your device, search for Bluetooth devices and select "BX29" from the list.
4. Once connected, the earbud lights will stop flashing, and you will hear a confirmation tone.
5. For subsequent uses, the earbuds will automatically connect to the last paired device when the case lid is opened.

UPGRADED BLUETOOTH 5.4 TECHNOLOGY

Dual-channel transmission creates an unbreakable connection




Image: A visual representation highlighting the upgraded Bluetooth 5.4 technology, emphasizing dual-channel transmission for an unbreakable connection.

One-Step Auto Pairing



Close ///

Auto power off and charging



Open ///

Auto stop charging and connect




Image: An illustration demonstrating the one-step auto-pairing process, showing the earbuds connecting to a smartphone when the charging case is opened.

3. Wearing the Earbuds

The Ltinist earbuds are designed with flexible earhooks for a secure and comfortable fit, especially during sports activities. Choose the ear tips that best fit your ears for optimal sound quality and comfort.

- Select the appropriate ear tip size (S/M/L) for a snug fit.
- Place the earbud into your ear canal and adjust the earhook over your ear until it feels secure and comfortable.

Designed for Sport

Take out and put on, boost energy and burn calorie



Flexible Earhooks




Image: A model wearing the earbuds, demonstrating the secure fit of the flexible earhooks. The image also shows the three different sizes of ear tips (S, M, L) included.

OPERATING INSTRUCTIONS

1. Power On/Off

- **Power On:** Open the charging case lid, and the earbuds will automatically power on.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off and begin charging.

2. Touch Controls

The earbuds feature sensitive touch controls for easy management of music and calls.

Action	Function
Single Tap (L/R)	Play/Pause Music, Answer/End Call


Action	Function
Double Tap (L/R)	Activate Voice Assistant
Triple Tap (Right)	Next Track
Triple Tap (Left)	Previous Track
Long Press (2s, Right)	Volume Up
Long Press (2s, Left)	Volume Down
Long Press (2s, L/R during call)	Reject Call

3. Sound Quality and Calls

The earbuds are equipped with 14.2mm dual-chamber speaker drivers for balanced and exceptional 3D stereo sound. Built-in ENC (Environmental Noise Canceling) microphones ensure crystal-clear call performance by isolating your voice from ambient noise.

The Unique Hi-Fi Stereo Sound

Provide authentic sound and powerful bass sound.



The illustration shows an exploded view of the earbud's internal components, including the speaker driver, magnet, and various filters. Colorful sound waves emanate from the components, suggesting high-quality audio output. The earbud itself is shown in the bottom left corner, with its charging port visible.



Noise
Cancellation



14.2MM Drivers

Image: An exploded view of an earbud, illustrating the internal components responsible for delivering Hi-Fi stereo sound and noise cancellation, including the 14.2mm drivers.

4. IP7 Waterproof Rating

With an IP7 waterproof rating, your Ltinist earbuds are protected against sweat, rain, and splashes, making them ideal for workouts and outdoor activities. *Note: The charging case is not waterproof.*




Image: Two earbuds with water droplets, visually representing their IP7 waterproof and sweatproof capabilities, suitable for various conditions like rain, sweat, and splashes.

MAINTENANCE

- **Cleaning:** Regularly clean the earbuds and charging contacts with a soft, dry, lint-free cloth. For ear tips, remove them and wash with mild soap and water, then dry thoroughly before reattaching.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Avoid Extreme Conditions:** Do not expose the earbuds or case to extreme temperatures, humidity, or corrosive liquids.

TROUBLESHOOTING

Problem	Possible Solution
Earbuds not pairing/connecting	◦ Ensure earbuds are charged. ◦ Turn off and on Bluetooth on your device. ◦ Forget "BX29" in your device's Bluetooth settings and re-pair. ◦ Place earbuds back in case, close lid, wait 5 seconds, then open again.
No sound from one earbud	◦ Ensure both earbuds are charged. ◦ Place both earbuds back in the case, close the lid, then open again to reset. ◦ Check device's audio output settings.
Charging case not charging	◦ Check USB-C cable and power adapter. ◦ Ensure the charging port is clean and free of debris.
Poor call quality	◦ Ensure earbuds are properly seated in your ears. ◦ Move closer to your connected device. ◦ Avoid noisy environments if possible, though ENC helps.

SPECIFICATIONS

Feature	Detail
Model Name	BX29
Item Model Number	X29
Brand	Ltinist
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth
Bluetooth Version	5.4
Ear Placement	In Ear (with Earhooks)
Control Method	Touch
Audio Driver Type	Dynamic Driver (14.2mm)
Battery Life (Earbuds)	Up to 15 Hours (single charge)
Total Playtime (with Case)	Up to 75 Hours
Water Resistance Level	IP7 Waterproof
Noise Canceling	ENC (Environmental Noise Canceling) Mic

Feature	Detail
Compatible Devices	Laptops, Desktops, Tablets, Telephones, Smartphones
Product Dimensions	1.57 x 0.79 x 0.98 inches
Item Weight	5 ounces
Material	Plastic

WARRANTY & SUPPORT

Ltinist products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or customer service, please refer to the contact information provided with your purchase or visit the official Ltinist website. Please retain your proof of purchase for warranty claims.

© 2025 Ltinist. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question