

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [BESNOOW](#) /

> [BESNOOW I53 Bluetooth 5.4 Wireless Earbuds User Manual](#)

BESNOOW I53

BESNOOW I53 Bluetooth 5.4 Wireless Earbuds User Manual

Model: I53 | Brand: BESNOOW

1. INTRODUCTION

Thank you for choosing the BESNOOW I53 Bluetooth 5.4 Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds to ensure optimal performance and longevity. Please read this manual carefully before use and keep it for future reference.

2. WHAT'S IN THE BOX

- 2 x BESNOOW I53 Wireless Earbuds
- 1 x Charging Case
- 1 x USB-C Charging Cable
- 1 x User Manual
- 3 x Pairs of Eartips (S/M/L)



Image: Package contents of the BESNOOW I53 earbuds.

3. PRODUCT OVERVIEW

3.1 Earbud Components

The BESNOOW I53 earbuds feature a sleek design with integrated touch controls and a dynamic driver for high-quality audio. Each earbud is equipped with a microphone for clear calls.



Image: BESNOOW I53 earbuds with a visual representation of the internal 14.2mm dynamic driver.

3.2 Charging Case

The compact charging case not only protects your earbuds but also provides extended battery life. It features an LED display to show the battery status of both the case and the individual earbuds.




Image: LED display on the charging case indicating battery status.

4. SETUP

4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging port on the case and to a power source. The LED display on the case will show the charging progress. A full charge for the case takes approximately 1.5 hours.

- Earbuds playtime on a single charge: Up to 6 hours
- Total playtime with charging case: Up to 40 hours



Image: Battery life and charging time overview.

4.2 Pairing with a Device

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "I53" in the list of available Bluetooth devices and select it to connect.
4. Once connected, you will hear an audio prompt, and the earbuds will be ready for use.

The earbuds utilize Bluetooth 5.4 technology for stable and low-latency connections.



Image: Bluetooth pairing process with a smartphone.

4.3 Wearing the Earbuds

For optimal sound quality and comfort, choose the correct size of eartips (S, M, L) and ensure a secure fit.

1. Select the eartips that best fit your ears.
2. Insert the earbud into your ear canal, aligning it correctly.
3. Gently twist the earbud until it feels secure and comfortable.

Ajustement sécurisé et confortable



Image: Guide for secure and comfortable earbud fit.

5. OPERATING INSTRUCTIONS

5.1 Touch Controls

The BESNOOW I53 earbuds feature intuitive touch controls on each earbud. The functions are as follows:

Action	Left Earbud	Right Earbud
Play/Pause	Single Tap	Single Tap
Volume Up	1S Press	1S Press
Volume Down	N/A	N/A
Next Song	N/A	2S Press
Previous Song	2S Press	N/A
Answer Call	Single Tap	Single Tap
End Call	Single Tap	Single Tap
Reject Call	2S Press	2S Press
Activate Voice Assistant (Siri)	Triple Tap	Triple Tap
Power On/Off	5S Press	5S Press

Contrôle Intelligent Par Toucher

Rendez votre journée plus facile



Image: Detailed touch control functions.

5.2 Environmental Noise Cancellation (ENC)

The earbuds are equipped with 4 ENC microphones to effectively reduce environmental noise during calls, ensuring clear voice transmission even in noisy surroundings.




Image: Environmental Noise Cancellation (ENC) feature.

6. MAINTENANCE

6.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove eartips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Avoid using harsh chemicals or abrasive materials.

6.2 Water Resistance

The earbuds are IP7 rated for water and dust resistance, protecting them from sweat, light rain, and accidental splashes. They are suitable for sports and outdoor activities but should not be submerged in water.



Image: IP7 water and dust resistance features.

6.3 Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged.

7. TROUBLESHOOTING

- **Earbuds not pairing:** Ensure both earbuds are charged and out of the case. Turn off and on your device's Bluetooth, then try pairing again.
- **Only one earbud working:** Place both earbuds back into the charging case, close the lid, wait a few seconds, then take them out again. This should re-sync them.
- **No sound:** Check the volume level on your device and on the earbuds. Ensure the earbuds are properly connected to your device.
- **Charging issues:** Ensure the charging cable is securely connected and the power source is working. Clean the charging contacts on the earbuds and inside the case.
- **Poor call quality:** Ensure the microphones are not obstructed. Move to an area with less environmental noise.

8. SPECIFICATIONS

Feature	Detail
Model Name	I53
Brand	BESNOOW
Connectivity Technology	Wireless (Bluetooth 5.4)
Ear Placement	In-Ear
Form Factor	In Ear
Noise Control	Passive Noise Reduction, ENC Microphones
Water Resistance Level	IP7 (Waterproof)
Control Method	Touch

Feature	Detail
Battery Type	Lithium-Polymer
Charging Time	Approx. 1.5 hours (case)
Playtime (Earbuds)	Up to 6 hours (single charge)
Total Playtime (with case)	Up to 40 hours
Compatible Devices	Any Bluetooth-enabled device (e.g., iPhone, Samsung Galaxy, Xiaomi, Huawei, etc.)
Included Components	Earbuds, Charging Case, User Manual, USB-C Cable, Eartips

9. WARRANTY & SUPPORT

9.1 Manufacturer's Warranty

This product comes with a 2-year manufacturer's warranty. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For any questions, issues, or support needs, please contact BESNOOW customer service through the retailer where you purchased the product or visit the official BESNOOW store on Amazon.