

OMAIC EN2Q36H

OMAIC EN2Q36H Replacement Remote Control Instruction Manual

Model: EN2Q36H | Brand: OMAIC

INTRODUCTION

This manual provides comprehensive instructions for the OMAIC EN2Q36H replacement remote control, designed for Hisense Smart TVs. It covers essential information regarding setup, operation, and maintenance to ensure optimal performance and user experience. This remote offers a direct replacement solution without the need for complex programming.

SETUP

The OMAIC EN2Q36H remote control is designed for immediate use with compatible Hisense Smart TVs. No programming or pairing is required.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by the arrow to open it.
3. Insert two AAA alkaline batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.

Once batteries are installed, the remote is ready to operate your Hisense Smart TV.

Cover Your Needs Anywhere

More suitable for the whole family




Figure 1: Steps for battery installation. Remove the cover, insert two AAA batteries, and replace the cover.

OPERATING INSTRUCTIONS

This remote control utilizes infrared (IR) technology for communication with your Hisense Smart TV. Ensure a clear line of sight between the remote and the TV's IR receiver for optimal performance.

Key Features

- **12 Shortcut Buttons:** Quickly access popular streaming services and applications with dedicated buttons.
- **Strong IR Signal:** Provides a longer transmission distance and quick response without noticeable delay.
- **Durable Construction:** Made from high-quality ABS and silicone materials for extended lifespan.



Figure 2: The remote features 12 dedicated shortcut buttons for quick access to popular streaming services.

BUTTON FUNCTIONS

Familiarize yourself with the functions of each button on your OMAIC EN2Q36H remote control:

Button	Function
POWER	Switches the TV on or into standby mode.
INPUT	Selects input sources (HDMI, AV, etc.).
APP Buttons	Quick access buttons for specific applications (e.g., Disney+, Netflix, YouTube).
MENU	Displays the Quick Setup menu.
MEDIA Control	Buttons for Play, Pause, Stop, Fast Forward, Rewind.
Navigation (Up/Down/Left/Right)	Navigates on-screen menus and adjusts system settings.
OK	Confirms selection in on-screen menus.

Button	Function
BACK	Returns to the previous menu.
EXIT	Exits the current menu.
VOL +/-	Adjusts the volume level.
HOME	Enters the Home screen.
MUTE	Mutes or restores the TV sound.
CH ^/v	Switches channels.
SUBTITLE	Activates or deactivates subtitle mode.
TEXT	Turns teletext function on and off.
INFO	Displays current program information.
NUMBER Buttons (0-9)	Direct channel selection or number input.
GUIDE	Displays the Electronic Programme Guide (DTV input).
CH.LIST	Displays the Channel List on the screen.




Figure 3: Overview of remote control buttons and their functions.

COMPATIBLE HISENSE TV MODELS

The OMAIC EN2Q36H replacement remote control is compatible with the following Hisense VIDAA 4K HDTV Smart TV series:

- 32A4K, 40A4K, 43A4K
- 32A5KQ, 40A5KQ
- 43A6K, 50A6K, 55A6K, 58A6K, 65A6K, 70A6K, 75A6K, 85A6K
- 55U6KQ, 65U6KQ
- 43A7KQ, 50A7KQ, 55A7KQ, 65A7KQ, 75A7KQ
- 43E7KQ, 50E7KQ, 55E7KQ, 65E7KQ, 75E7KQ



Figure 4: The OMAIC EN2Q36H remote is compatible with various Hisense VIDAA Smart TV models.

MAINTENANCE

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the remote. Avoid using liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA alkaline).
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal circuitry.

TROUBLESHOOTING

If you encounter issues with your remote control, refer to the following troubleshooting steps:

Problem	Possible Cause	Solution
Remote not responding	Dead or incorrectly inserted batteries.	Replace batteries with new AAA alkaline batteries, ensuring correct polarity.
Remote not responding	Obstruction between remote and TV.	Ensure a clear line of sight to the TV's IR receiver. Remove any objects blocking the path.
Remote not responding	Remote is too far from the TV.	Move closer to the TV. The remote has an extended range, but extreme distances may affect performance.
Buttons are sticky or unresponsive	Dirt or debris under buttons.	Gently clean around the buttons with a soft, dry cloth. Avoid liquids.
Specific functions not working	TV model incompatibility (rare).	Verify your Hisense TV model is listed in the 'Compatible Hisense TV Models' section.

SPECIFICATIONS

Feature	Detail
Model Name	EN2Q36H
Brand	OMAIC
Compatible Devices	Hisense Smart TVs
Connectivity Technology	Infrared (IR)

Feature	Detail
Number of Buttons	48
Control Type	Button Control
Special Features	Universal, Comfortable
Color	Black
Battery Description	AAA (Alkaline)
Supported Devices (Max)	1
Product Dimensions (Approx.)	34.7 x 24.7 x 2.2 cm
Product Weight (Approx.)	80 grams



Replacement remote for Hisense smart TV

for VIDAA 4K HDTV FHD QLED LCD LED Smart TVs

- ✔ 32A4K / 40A4K / 43A4K
- ✔ 32A5KQ / 40A5KQ
- ✔ 43A6K / 50A6K / 55A6K / 58A6K / 65A6K / 70A6K / 75A6K / 85A6K
- ✔ 55U6KQ / 65U6KQ
- ✔ 43A7KQ / 50A7KQ / 55A7KQ / 65A7KQ / 75A7KQ
- ✔ 43E7KQ / 50E7KQ / 55E7KQ / 65E7KQ / 75E7KQ

Figure 5: The remote features an upgraded chip for signal stabilization and responsive buttons.

WARRANTY AND SUPPORT

OMAIC is committed to the quality and compatibility of its replacement remote controls. We provide

professional after-sales support to ensure customer satisfaction.

If you have any questions or concerns regarding your OMAIC EN2Q36H remote control or your order, please contact us directly. Our support team aims to respond to inquiries within 12 working hours.