

[Manuals.plus](#) /

› [Pelican](#) /

› Pelican Seek 100XP Angler Kayak User Manual

Pelican SEEK 100XP

Pelican Seek 100XP Angler Kayak User Manual

Model: SEEK 100XP

PRODUCT OVERVIEW

The Pelican Seek 100XP Angler Kayak is a 10-foot sit-on-top fishing kayak designed for stability, comfort, and ease of use. It features a twin-arched multi-chine hull for a stable ride, an adjustable Ergobreeze seating system for comfort, and versatile storage solutions including a removable ErgoFlip™ Bow Bag and a premium ripstop tankwell cover. The kayak is constructed from ultra-durable Polyethylene (PE) material, ensuring longevity and performance on the water.



Pelican Seek 100XP Angler Kayak in Forest Mist color, top-down view.

Your browser does not support the video tag.

Official product video showcasing the features and design of the Pelican Seek 100XP Angler Kayak.

KEY FEATURES

- **Twin-Arched Multi-Chine Hull:** Provides exceptional stability and a smooth ride.
- **Ergobar System and Slip-Resistant Standing Area:** Three-piece removable system bars simplify entry and exit, staying clear of paddle strokes, combined with a textured standing floor for secure kayaking.
- **Adjustable Ergobreeze Seating System:** Offers comfortable and efficient seating with soft cushioning and an adjustable backrest.
- **Removable Ripstop ErgoFlip Bow Bag:** Provides spacious, easy-to-access storage that can be flipped over while seated and is detachable for transport.
- **Premium Ripstop Tankwell Cover:** Secures gear in the rear storage area.
- **Dual-Position Bottle Holder:** Keeps beverages within reach.
- **Flush-Mount Rod Holders:** Two integrated holders for fishing rods.

- **Four Carrying Handles:** Integrated handles for easy transport.

SETUP

Adjusting Footrests

The kayak features adjustable footrests to accommodate various paddler heights. To adjust, simply pull the release tabs and slide the footrests along the track to your desired position. Ensure both footrests are set evenly for optimal comfort and control.



Adjustable footrests for personalized comfort.

Seating System Adjustment

The Ergobreeze seating system with Ergoform™ cushion is designed for comfort. Adjust the backrest angle using the straps and buckles located on the sides of the seat frame. Experiment with different settings to find the most comfortable and supportive position for your paddling style.



The adjustable Ergobreeze seating system provides comfort and support.

Utilizing the ErgoFlip Bow Bag

The removable ErgoFlip Bow Bag is located at the front of the kayak. It can be easily pulled and flipped over while seated for quick access to your essentials. Secure it using the attached straps. The bag is also detachable for convenient transport of your gear off the kayak.



The ErgoFlip bow bag offers accessible storage.

Carrying and Transport

The kayak is equipped with four carrying handles (bow, stern, and sides) to facilitate easy lifting and transport. Always use two people when lifting the kayak to prevent injury and ensure proper balance.



Side view of the kayak, highlighting the integrated carrying handles.

OPERATING THE KAYAK

Launching and Landing

When launching, ensure the kayak is in shallow water before entering. Sit down carefully, placing your weight evenly. For landing, approach the shore slowly, allowing the kayak to glide onto the bank or beach. Exit by placing your paddle across the cockpit and using it for support.

paddling Techniques

Hold your paddle with both hands, slightly wider than shoulder-width apart. Use your core muscles to rotate and propel the kayak forward, rather than just your arms. Maintain a steady rhythm and keep your strokes smooth for efficient movement. The twin-arched multi-chine hull provides inherent stability, making it forgiving for beginners.



A paddler demonstrating proper technique in the Seek 100XP Angler Kayak.

Utilizing Fishing Features

The two flush-mount rod holders are conveniently located behind the seat for easy access. The Ergobar system provides a stable platform for standing while fishing, enhancing your casting and visibility. Always ensure your gear is securely stowed to prevent loss.

MAINTENANCE

Cleaning

After each use, rinse your kayak thoroughly with fresh water to remove salt, sand, and debris. Use a mild soap and soft brush for stubborn dirt. Avoid abrasive cleaners or solvents that could damage the hull material.

Storage

Store the kayak in a cool, dry place away from direct sunlight. If storing outdoors, cover it with a UV-resistant tarp. Store the kayak on its side or upside down on sawhorses or a specialized kayak rack to prevent hull deformation. Remove all accessories, including the seat and bow bag, for separate storage.

Inspection

Regularly inspect the hull for cracks or damage, and check all straps, buckles, and hardware for wear. Ensure the drain plug is in good condition and properly sealed before each outing.

TROUBLESHOOTING

Water in Kayak

If water accumulates in the cockpit, check that the scupper plugs (if installed) are properly seated. The kayak's design allows water to drain through scupper holes, but excessive water may indicate a loose plug or a small leak. Inspect the hull for any visible damage.

Stability Issues

Ensure your weight is centered in the kayak and distributed evenly. Avoid sudden movements. If you feel unstable,

try lowering your center of gravity by adjusting your seating position or keeping your body relaxed. The twin-arched multi-chine hull is designed for stability, so significant instability may indicate improper loading or adverse water conditions.

SPECIFICATIONS

Feature	Detail
Brand	Pelican
Model Name	SEEK 100XP Angler Fishing Kayak
Item Weight	48.1 Pounds
Material	Polyethylene (PE)
Color	Forest Mist
Seating Capacity	1
Weight Capacity Maximum	300 Pounds
Item Dimensions L x W x H	120"L x 30"W x 14"H
Model Number	MKL10P505-00
UPC	776324572485
Included Components	Kayak

WARRANTY AND SUPPORT

Warranty Information

The Pelican Seek 100XP Angler Kayak comes with a lifetime limited warranty against manufacturer defects. Parts and accessories are covered by a 1-year warranty. Specific conditions may apply; please refer to the official warranty documentation provided with your purchase for full details.

Customer Support

For further assistance, technical support, or to inquire about replacement parts, please visit the official Pelican International website or contact their customer service department. Contact information can typically be found on the manufacturer's website or in your product packaging.