

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Kinglucky](#) /

› [Kinglucky ClipFree Open-Ear Headphones Model A8 User Manual](#)

Kinglucky A8

Kinglucky ClipFree Open-Ear Headphones Model A8 User Manual

Your guide to setup, operation, and care.

1. INTRODUCTION

Thank you for choosing the Kinglucky ClipFree Open-Ear Headphones Model A8. These innovative headphones combine high-quality audio with a unique jewelry-inspired design, featuring detachable butterfly earrings. Designed for comfort and awareness, they provide a secure fit without blocking your ear canal, allowing you to enjoy your audio while staying connected to your surroundings. This manual will guide you through the setup, operation, and maintenance of your new headphones.



Image: Kinglucky ClipFree Open-Ear Headphones Model A8 in Rose Gold charging case.

2. WHAT'S IN THE BOX

Your Kinglucky ClipFree Open-Ear Headphones package includes the following items:

- Kinglucky OpenEarRing A8 Headphones (Rose Gold)
- Charging Case
- Crystal Butterfly Ear Clip Charms (Detachable)
- USB-C Charging Cable
- User Manual (this document)



Image: All components included in the Kinglucky ClipFree Open-Ear Headphones package.

3. SETUP: FIRST-TIME PAIRING

Follow these steps to pair your Kinglucky headphones with your device for the first time:

1. **Remove Protective Films:** Carefully remove any protective films from the charging contacts on the earbuds.
2. **Place in Charging Case:** Place both ear clips into the charging case and close the lid. Ensure they are seated correctly.
3. **Open Lid & Pair:** Open the charging case lid. The earbuds will automatically enter pairing mode. On your device (smartphone, tablet, etc.), go to Bluetooth settings and select "Kinglucky Earbuds" from the list of available devices to connect.



Image: Visual guide for the initial pairing process of the earbuds.

4. WEARING THE EARBUDS & ATTACHING CHARMS

The Kinglucky ClipFree headphones are designed for an open-ear fit, resting gently on your ear without entering the ear canal. This ensures comfort and situational awareness.

4.1 Wearing the Earbuds

Gently place the ear clip over the helix (the outer rim) of your ear. Adjust for a secure and comfortable fit. The speaker component should be positioned near your ear canal for optimal sound delivery.



Image: The C-shaped design ensures a comfortable and stable fit on the ear.

4.2 Attaching the Butterfly Charms

To personalize your headphones, you can attach the included crystal butterfly charms:

1. **Gently Open Ear Cuff:** Locate the small opening on the earbud's cuff.
2. **Clip onto Earphone Stem:** Carefully clip the butterfly charm onto the stem of the earphone.
3. **Position:** Place the earbud with the attached charm over your ear. Ensure the charm is securely fastened.

The silicone pad helps secure the charm. The charms are detachable and not stored in the charging case.



Image: Step-by-step guide to attaching the butterfly charms to your earbuds.

5. OPERATING INSTRUCTIONS

5.1 Touch Controls

The earbuds feature intuitive touch controls for managing your audio and calls:

- **Play/Pause:** Single tap on either earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Volume Up:** Triple tap on the right earbud.
- **Volume Down:** Triple tap on the left earbud.

- **Activate Voice Assistant:** Long press (2 seconds) on either earbud.

5.2 Charging

To charge your earbuds and charging case:

1. **Earbuds:** Place the earbuds into the charging case. They will automatically begin charging. The indicator light on the case will show charging status.
2. **Charging Case:** Connect the provided USB-C charging cable to the port on the back of the charging case and to a power source. The indicator light will show charging progress.

A full charge provides up to 50 hours of total playtime with the charging case.

All-Day Battery Life

Up to **50 hours** of playtime, with fast charging to keep your playlists going

-  **6H**
Single Charge
-  **50H**
With Charging Case



Image: The charging case provides extended battery life for your earbuds.

5.3 MultiPoint Pairing

Your Kinglucky headphones support MultiPoint Pairing, allowing seamless connection to two devices simultaneously. This enables you to effortlessly switch between your phone, tablet, smartwatch, or computer without re-pairing.



Clear Calls Anytime

Noise-reducing mic delivers crisp conversations wherever you are.



Image: MultiPoint Pairing allows connection to two devices simultaneously.

6. FEATURES & BENEFITS

- **Jewelry-Inspired Design:** Unique clip-on open-ear earbuds with detachable crystal butterfly earrings, offering both audio and style.
- **Secure & Comfortable Open-Ear Fit:** Weighing just 4.0g each, they rest gently on the ear without blocking the canal, providing a pressure-free and stable fit. Ideal for small ears, long hair, or glasses.

- **Clear Audio Quality:** Tuned for clear vocals and balanced sound, allowing you to enjoy podcasts, calls, and music without the fatigue of in-ear headphones.
- **Bluetooth 6.0:** Ensures fast pairing and a stable wireless connection.
- **IP56 Water Resistance:** Designed to withstand sweat and rain, making them suitable for daily commutes, office calls, and light workouts.
- **Extended Playtime:** Up to 50 hours of listening time with the portable charging case.
- **AI-Powered Call Clarity:** Equipped with 2 beamforming microphones and advanced noise-canceling technology for crisp conversations.




Image: The unique design blends elegance with everyday comfort and functionality.

7. SPECIFICATIONS

Feature	Detail
Model Name	A8
Brand	Kinglucky
Connectivity Technology	Wireless (Bluetooth 6.0)
Ear Placement	Open Ear
Form Factor	True Wireless
Battery Life	Up to 50 Hours (with charging case)
Water Resistance Level	IP56 (Sweat and Rain Resistant)
Control Method	Touch
Material	Plastic, Metal, Rhinestones
Item Weight	3.17 Ounces
Included Components	USB-C Cable

8. MAINTENANCE

To ensure the longevity and optimal performance of your Kinglucky headphones, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the earbuds and charging case. Avoid using harsh chemicals or abrasive materials.
- **Charging Contacts:** Periodically clean the charging contacts on both the earbuds and inside the case with a dry cotton swab to ensure a good connection.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Water Exposure:** While IP56 rated for sweat and rain, avoid submerging the headphones in water. Dry them thoroughly if they get wet.
- **Charms:** Handle the detachable charms with care to prevent damage to the crystals or clips.

9. TROUBLESHOOTING

If you encounter any issues with your Kinglucky headphones, refer to the following common solutions:

- **Earbuds not pairing:**
 - Ensure both earbuds are fully charged.
 - Turn off Bluetooth on your device, then turn it back on.
 - Forget "Kinglucky Earbuds" from your device's Bluetooth list and attempt to re-pair.
 - Place earbuds back in the case, close the lid for 5 seconds, then open to reset pairing mode.
- **No sound or low volume:**
 - Check the volume levels on both your device and the earbuds (using touch controls).
 - Ensure earbuds are correctly seated on your ears.
 - Confirm the earbuds are connected to the correct device.
- **One earbud not working:**
 - Place both earbuds back in the charging case, close the lid, then open it again.
 - Ensure both earbuds are charged.
 - Try resetting the earbuds (refer to the full manual for specific reset instructions if available).
- **Charging issues:**
 - Ensure the USB-C cable is securely connected to both the case and the power source.
 - Check if the charging contacts on the earbuds and case are clean and free of debris.
 - Try a different USB-C cable or power adapter.

10. WARRANTY & SUPPORT

Kinglucky is committed to providing quality products and customer satisfaction. Your Kinglucky ClipFree Open-Ear Headphones Model A8 come with the following:

- **18-Month Warranty:** Scan the QR code on the product packaging to activate your warranty within 14 days of purchase.
- **180-Day Guarantee:** Enjoy peace of mind with our extended guarantee.
- **Free Replacement:** In case of eligible issues, a free replacement will be provided.

- **24/7 Fast Support:** For any questions, concerns, or assistance, please contact Kinglucky customer support.

If you encounter issues such as a used item, no sound, inability to pair, or charging problems, please reach out to our support team for hassle-free assistance.



Image: Kinglucky customer care details for support and warranty.