

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [VECELO](#) /

› [VECELO Gaming Chair KHD-CC-ZD04 Instruction Manual](#)

VECELO KHD-CC-ZD04

VECELO Gaming Chair Instruction Manual

Model: KHD-CC-ZD04

INTRODUCTION

Thank you for purchasing the VECELO Gaming Chair. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your chair. Please read this manual thoroughly before use and retain it for future reference.



Image: The VECELO Gaming Chair in Grey, showcasing its ergonomic design and overall appearance.

SAFETY INFORMATION

- Ensure all components are present and undamaged before assembly.
- Follow assembly instructions carefully to prevent injury or damage to the chair.
- Do not stand on the chair or use it as a step stool.
- Avoid exposing the chair to direct sunlight or extreme temperatures.
- Keep children and pets away from the chair during assembly.
- Do not use abrasive cleaners or harsh chemicals on the chair's surfaces.

SETUP AND ASSEMBLY

Assembly is required for this product. Please ensure you have sufficient space and all tools provided before beginning. Refer to the included assembly guide for detailed step-by-step instructions and diagrams.

Included Components:

- Chair Base
- Seat Cushion
- Backrest
- Armrests
- Headrest Pillow
- Lumbar Support Pillow
- Assembly Hardware (screws, washers, tools)

Assembly Tips:

- Lay out all parts on a clean, soft surface to prevent scratches.
- Do not overtighten screws during initial assembly; tighten them fully once all parts are aligned.
- Seek assistance if needed, especially when attaching the backrest to the seat.

OPERATING INSTRUCTIONS

The VECELO Gaming Chair is designed for comfort and versatility. Familiarize yourself with its adjustable features.


1. Reclining Function

90°~135°までリクライニング可能

お好みに合わせて角度を自由に調整できます。



90°



105°



135°



Image: The chair demonstrating its reclining capability, adjustable from 90 to 135 degrees for various activities like gaming or relaxing. The backrest can be adjusted to an angle of up to 135 degrees. Locate the recline lever, typically on the right side of the seat. Pull the lever up and lean back to your desired angle. Release the lever to lock the backrest in position. To return to an upright position, pull the lever and lean forward slightly.

2. 360° Rotation

360度回転ベース搭載

ゲーム、読書、テレビ鑑賞など、あらゆるシーンで快適な動きをサポート。
ストレスフリーな時間を実現します。



Image: A user comfortably rotating in the VECELO Gaming Chair, highlighting the 360-degree swivel base for unrestricted movement. The chair features a 360-degree rotating base, allowing for freedom of movement and easy access to different areas around your workspace or gaming setup. Simply rotate the chair to your desired orientation.

3. Lumbar Support and Headrest

人間工学に基づいた背もたれ設計

アジア人体型にフィットし、頭部と腰をしっかりサポート。
長時間使用しても疲れにくく、抜群の快適性を実現。



Image: An illustration demonstrating the ergonomic design of the VECELO Gaming Chair, with emphasis on how the headrest and lumbar support align with the human spine for optimal posture.

The chair includes removable headrest and lumbar support cushions. Adjust their position by sliding them along the straps to best support your neck and lower back, promoting an ergonomic posture during extended use.

MAINTENANCE AND CARE

Proper maintenance will extend the life and appearance of your VECELO Gaming Chair.

- **Cleaning:** For the PU leather surface, wipe regularly with a soft, damp cloth. For stubborn stains, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Retighten if necessary.
- **Avoid Damage:** Do not expose the chair to sharp objects, excessive weight, or prolonged direct sunlight.

快適な座り心地と優れた通気性

高品質PUレザー

高反発スポンジ

圧力に強く、
変形しにくい合板

• 究極の快適さ

長時間の使用でも快適な座り心地を実現します。

Image: A cutaway view illustrating the internal construction of the chair, showing the layers of high-quality PU leather, high-resilient sponge, and the durable wood base, which contribute to comfort and longevity.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair feels unstable or wobbly.	Loose screws or uneven assembly.	Check and tighten all assembly screws. Ensure the chair is on a flat surface.
Recline function not working smoothly.	Mechanism obstruction or damage.	Ensure no objects are obstructing the recline mechanism. If issues persist, contact customer support.
Squeaking noises.	Loose connections or friction between parts.	Tighten all screws. Apply a small amount of silicone lubricant to moving parts if necessary.

SPECIFICATIONS

Feature	Detail
Brand	VECELO
Model Number	KHD-CC-ZD04
Color	Grey
Product Dimensions (D x W x H)	28.15" x 21.46" x 37.99" (71.5 cm x 54.5 cm x 96.5 cm)
Item Weight	16.4 Kilograms (36.1 pounds)
Material	PU Leather, High-Resilient Sponge, Wood
Recline Angle	Up to 135 degrees
Rotation	360 degrees
Included Components	Headrest Pillow, Lumbar Support Pillow
Assembly Required	Yes
Batteries Required	No
UPC	840408986533

WARRANTY INFORMATION

VECELO products are manufactured to high-quality standards. For specific warranty details regarding your VECELO Gaming Chair, please refer to the warranty card included with your purchase or visit the official VECELO website. Keep your purchase receipt as proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or encounter any issues with your VECELO Gaming Chair, please contact our customer support team. You can find contact information on the VECELO official website or through your retailer.

Online Support: [Visit the VECELO Store on Amazon](#)

