HOMCOM 923-060V00WT

HOMCOM Adjustable Monitor Riser with 2 Drawers - Model 923-060V00WT

Instruction Manual

1. Introduction

Thank you for purchasing the HOMCOM Adjustable Monitor Riser. This manual provides essential information for the safe assembly, operation, and maintenance of your new monitor stand. Please read these instructions carefully before use and retain them for future reference.

This monitor riser is designed to elevate your screen to an ergonomic height, reducing strain on your neck and back. Its adjustable length and angle allow for versatile setup, accommodating single or dual monitors, and includes integrated storage solutions.

2. Safety Instructions

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the unit on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly to avoid damaging the material.
- Place the monitor riser on a stable, level surface.
- Do not exceed the maximum weight capacity of 14 kg (30.8 lbs).
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Regularly check all connections and fasteners to ensure they remain secure.

3. Package Contents

Verify that all components listed below are included in your package:

- Main Monitor Platform (3 sections)
- Support Legs (2 units)
- Drawers (2 units)

- Assembly Hardware (screws, dowels, Allen key, screwdriver)
- Instruction Manual



Image: Illustration of all components included in the HOMCOM monitor riser package.

4. Specifications

Feature	Detail
Brand	HOMCOM
Model Number	923-060V00WT
Material	Engineered Wood (Melamine)
Color	White
Adjustable Length	60 cm to 116 cm (23.6 to 45.7 inches)
Width	22 cm (8.7 inches)
Height	12 cm (4.7 inches)
Weight Capacity	14 kg (30.8 lbs)
Suitable Monitor Size	Up to 24 inches (per monitor)
Features	Adjustable angle, 2 drawers, 3 additional compartments



Image: Detailed dimensions of the HOMCOM Adjustable Monitor Riser.

5. Setup and Assembly

Follow these steps to assemble your monitor riser:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent damage.
2. **Identify Parts:** Refer to the included parts list and diagrams to identify each component.
3. **Assemble Main Platform:**
    - Connect the three main platform sections using the provided screws and dowels. Ensure they are aligned correctly.
    - Attach the two support legs to the underside of the main platform using the designated screws.
4. **Insert Drawers:** Slide the two drawers into their respective compartments on the main platform.

5. **Final Check:** Ensure all screws are tightened securely, but do not overtighten. The unit should be stable and free of wobbles.



Image: Visual guide for assembling the monitor riser components.

Your browser does not support the video tag.

Video: Assembly instructions for a similar monitor stand, demonstrating the general process of attaching legs and securing the platform. This video is provided by a seller of a related product.

6. Operating Instructions

The HOMCOM Adjustable Monitor Riser offers flexibility to optimize your workspace:

- **Placement:** Position the monitor riser on your desk.
- **Adjusting Length and Angle:** The three sections of the platform can be adjusted in length from 60 cm to 116 cm and rotated to achieve your desired angle. This allows for a straight setup, an L-shape, or a V-shape, suitable for one or two monitors.

- **Monitor Placement:** Carefully place your monitor(s) on the elevated platform. Ensure the weight is evenly distributed and does not exceed the 14 kg capacity.
- **Storage:** Utilize the two drawers and three additional compartments to store office supplies, cables, and other small items, keeping your desk tidy.



Image: Demonstrates the adjustable length and angle features of the monitor riser, showing various configurations for single or dual monitors.



Image: Shows the monitor riser with its integrated drawers and compartments used for organizing desk items.

7. Maintenance

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals that could damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.
- **Avoid Moisture:** Keep the monitor riser away from excessive moisture and direct sunlight to prevent warping or discoloration.

8. Troubleshooting

Problem	Possible Cause	Solution

Riser is wobbly or unstable.	Loose screws or uneven surface.	Check and tighten all assembly screws. Ensure the desk surface is level.
Drawers do not slide smoothly.	Obstruction or misalignment.	Remove drawers and check for any obstructions. Reinsert carefully, ensuring proper alignment.
Difficulty adjusting length/angle.	Sections are stuck or misaligned.	Gently apply pressure to adjust. Ensure no items are obstructing the sliding mechanism.

9. Warranty and Support

For warranty information or technical support, please refer to the contact details provided by your retailer or visit the official HOMCOM website. Keep your purchase receipt as proof of purchase.
For additional information or to explore other products, visit theHOMCOM Store on Amazon.

© 2025 HOMCOM. All rights reserved. Model: 923-060V00WT