Haier ETL105-CAFS8

Haier 10.5 Kg Fully Automatic Top Load Washing Machine

Model: ETL105-CAFS8

User Manual

1. Important Safety Information

Read all instructions before using the appliance. Keep this manual for future reference. Always follow basic safety precautions to reduce the risk of fire, electric shock, or injury to persons.

- Ensure the washing machine is properly grounded.
- Do not operate the machine if the power cord or plug is damaged.
- Keep children away from the appliance during operation.
- Do not wash items that are soiled with flammable substances.
- Unplug the appliance before cleaning or performing any maintenance.
- Do not attempt to repair or replace any part of the appliance unless specifically recommended in this manual.

2. Package Contents

Verify that all components are present upon unpacking:

- Haier 10.5 Kg Fully Automatic Top Load Washing Machine (Model ETL105-CAFS8)
- Drain Hose
- Fill Hose
- Power Cord
- User Manual (This document)

3. Installation and Setup

Proper installation is crucial for optimal performance and safety.

3.1 Unpacking

Carefully remove all packaging materials. Ensure no parts are left inside the drum or attached to the exterior. Remove any transit bolts or packing foam from the bottom of the machine.

3.2 Location Requirements

- Place the washing machine on a firm, level surface.
- Ensure adequate ventilation around the appliance.
- Avoid direct sunlight or heat sources.
- Maintain a minimum clearance of 10 cm from walls or other objects.

3.3 Leveling the Machine

Adjust the leveling feet at the bottom of the machine until it is stable and level. This prevents excessive vibration and noise during operation.

3.4 Water Supply Connection

- Connect the fill hose to the water inlet valve at the back of the machine and to a cold water tap.
- Ensure connections are tight to prevent leaks.
- This model supports Near Zero Pressure (NZP) operation, allowing it to function effectively even with low water pressure (0.01MPA).

3.5 Drain Hose Connection

Securely attach the drain hose to a suitable drain pipe or sink, ensuring it is not kinked or blocked.

3.6 Power Connection

Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the appliance's requirements (220 Volts).



Figure 1: Front view of the washing machine, showing the control panel and top-load access.

4. Operating Instructions

This section details how to use your Haier washing machine effectively.

4.1 Control Panel Overview

The control panel features push buttons for various functions and a digital display.



Figure 2: Control panel with options for custom wash cycles.

- **Power Button:** Turns the machine on/off.
- **Start/Pause Button:** Starts or pauses the selected wash cycle.
- **Program Selection:** Choose from 8 available wash programs.
- **Water Level:** Adjusts the water level according to the load size (Fuzzy Logic for auto-detection).
- **Child Lock:** Prevents accidental changes to settings during operation.
- **Ultra Fresh Air:** Activates the Ultra Fresh Air Technology.

4.2 Loading Laundry

Open the top lid and load clothes into the Oceanus Wave Steel Drum. Do not overload the machine; the maximum capacity is 10.5 Kg. Distribute clothes evenly to maintain balance.

4.3 Adding Detergent and Softener

Add appropriate amounts of detergent and fabric softener to their respective dispensers. Refer to detergent packaging for recommended quantities.

4.4 Selecting a Wash Program

Choose one of the 8 wash programs based on your laundry type:



Figure 3: Overview of the 8 available wash programs.

- **Wash:** Standard washing cycle.
- **Rinse:** Rinsing cycle.

- **Spin:** Spinning cycle for water removal.
- **Tub Dry:** Helps dry the inner tub to prevent mildew.
- **Smart:** Automatically detects load size and adjusts settings.
- **Soak:** Pre-soak cycle for heavily soiled items.
- **Delicate:** Gentle cycle for delicate fabrics.
- **Quick:** A fast wash cycle, approximately 15 minutes for average loads.

4.5 Special Features

- **Ultra Fresh Air Technology:** This feature circulates air within the drum after a wash cycle to remove moisture and keep clothes fresh for up to 12 hours, preventing bad odors and bacterial growth.




Figure 4: Ultra Fresh Air Technology in action.

- **Oceanus Wave Drum:** The unique design of the steel drum provides a powerful yet gentle wash, aiding in deep cleaning and minimizing creases.
- **Magic Filter:** Dual magic filters effectively collect lint and debris, ensuring cleaner clothes and preventing drain blockages.
- **Toughened Glass Lid:** Provides durability and allows visibility into the drum during operation.



Figure 5: Soft-fall lid mechanism.

- **Auto Restart:** In case of a power outage, the machine will resume the cycle from where it left off once power is restored.
- **Voltage Protection/Shock Proof:** Built-in safety features to protect the appliance and user.

4.6 Starting a Wash Cycle

After loading laundry, adding detergent, and selecting a program, press the **Start/Pause** button to begin the cycle.

Your browser does not support the video tag.

Video 1: This video demonstrates various features of the Haier washing machine, including the control panel, Ultra Fresh Air technology, Oceanus Wave Drum, Magic Filter, and Tub Clean function.

5. Maintenance

Regular maintenance ensures the longevity and efficiency of your washing machine.

5.1 Cleaning the Exterior

Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.

5.2 Cleaning the Drum (Tub Clean)

Use the dedicated **Tub Clean** program regularly to remove detergent residue and prevent mold growth. This self-cleaning function helps maintain hygiene inside the drum.

5.3 Cleaning the Magic Filter

Remove and clean the Magic Filters after every few washes to ensure efficient lint collection. Rinse them under running water and reinsert.

5.4 Cleaning the Detergent Dispenser

Periodically remove and clean the detergent dispenser to prevent buildup and blockages.

6. Troubleshooting

Refer to this section for common issues and their solutions before contacting service.

Problem	Possible Cause	Solution
Machine does not start	Power cord unplugged; Door not closed properly; No water supply.	Check power connection; Ensure lid is fully closed; Check water tap.
Excessive vibration/noise	Machine not level; Laundry unevenly distributed; Transit bolts not removed.	Adjust leveling feet; Redistribute laundry; Ensure transit bolts are removed.
Water leakage	Hoses not properly connected; Drain hose blocked.	Tighten hose connections; Clear drain hose.
Clothes not clean	Overloading; Insufficient detergent; Incorrect program selected.	Reduce load size; Use correct detergent amount; Select appropriate program.

7. Specifications

Detailed technical specifications for the Haier ETL105-CAFS8 washing machine.

Feature	Description
Model Number	ETL105-CAFS8
Brand	Haier
Capacity	10.5 Kilograms

Feature	Description
Type	Fully Automatic Top Load
Energy Rating	5 Star
Spin Speed	780 RPM
Product Dimensions (D x W x H)	59.5D x 55W x 94.5H Centimeters
Item Weight	34.5 Kilograms
Drum Material	Steel (Oceanus Wave Drum)
Wash Programs	8 (Wash, Rinse, Spin, Tub Dry, Smart, Soak, Delicate, Quick)
Special Features	Ultra Fresh Air Technology, Near Zero Pressure (NZP), Magic Filter, Fuzzy Logic, Child Lock, Auto Restart, Toughened Glass Lid, Voltage Protection
Voltage	220 Volts



Figure 6: Product dimensions and energy efficiency guide.

8. Warranty and Support

Your Haier washing machine comes with a comprehensive warranty and dedicated customer support.

8.1 Warranty Information

- **Product Warranty:** 2 years comprehensive warranty on the product.
- **Motor Warranty:** 10 years warranty on the motor.
- To avail warranty services, please retain your purchase invoice.

8.2 Customer Support

For any queries, service requests, or technical assistance, please contact Haier customer support:

- **Manufacturer:** HAIER APPLIANCES INDIA PVT LTD
- **Address:** Plot No. H-6, DMIC Integrated Industrial Township, Greater Noida, Uttar Pradesh – 201308
- **Email:** info@haierindia.com

© 2026 Haier Appliances India Pvt Ltd. All rights reserved.