

Raemon K80

Raemon K80 10-inch Android 15 Tablet User Manual

Model: K80

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Raemon K80 10-inch Android 15 Tablet. Please read this manual thoroughly before using the device and retain it for future reference.

The Raemon K80 tablet features a 10.1-inch IPS HD display, T615 Octa-Core processor, 24GB RAM, 128GB ROM (expandable up to 1TB), 5MP front and 8MP rear cameras, a 6000mAh battery, Wi-Fi 6, Bluetooth 5.4, and Widevine L1 support. It comes with a keyboard, mouse, stylus, and protective case.

2. PACKAGE CONTENTS


Verify that all items are present in your package:

- Raemon K80 10-inch Android 15 Tablet
- Keyboard
- Protective Case
- Mouse
- Stylus
- Charger
- USB-C Cable
- User Manual (this document)

T615 Octa-core High Performance Processor



Efficient computing, twice the effort
with half the effort



With the T615 octa-core processor,
data processing speed is greatly
increased.

Image: RaemonD K80 Tablet with included accessories: keyboard, mouse, stylus, charger, and USB-C cable.

3. SETUP

3.1 Initial Charge

Before first use, fully charge your tablet using the provided charger and USB-C cable. Connect the USB-C cable to the tablet's charging port and the charger to a power outlet. The battery indicator on the screen will show charging status.

Your face is the Password

Quick unlock, shorten open time
Privacy data encrypted,
personal access only



Accurate Navigation, Travel Assistant

Built-in GPS module, travel navigation is more accurate and convenient.

Image: The RaemonD K80 Tablet connected to its charger, displaying a battery icon indicating 95% charge.

3.2 Power On/Off

To power on, press and hold the power button located on the side of the tablet until the RaemonD logo appears. To power off, press and hold the power button, then select "Power off" from the options.

3.3 Connecting Accessories (Keyboard & Mouse)

The included keyboard and mouse connect via Bluetooth. Ensure Bluetooth is enabled on your tablet (Settings > Connected devices > Bluetooth). Follow the pairing instructions for each accessory:

1. **Keyboard:** Turn on the keyboard. Press the "Connect" button or a specific function key (e.g., Fn + C) to enter pairing mode. On your tablet, search for available Bluetooth devices and select the keyboard to pair.
2. **Mouse:** Turn on the mouse. It should automatically enter pairing mode or have a dedicated pairing button. On your tablet, search for available Bluetooth devices and select the mouse to pair.

Your browser does not support the video tag.

Video: Demonstrates the unboxing and setup of the RaemonD K80 tablet, including connecting the keyboard and mouse.

4. OPERATING INSTRUCTIONS

4.1 Navigation and Gestures

The RaemonD K80 tablet runs on Android 15, offering intuitive navigation. Use touch gestures for most interactions:

- **Tap:** Select an item or open an app.
- **Swipe:** Scroll through pages or lists.
- **Pinch-to-zoom:** Enlarge or shrink content.
- **Three-finger screenshot:** Swipe down with three fingers to capture a screenshot.

Your browser does not support the video tag.

Video: Demonstrates how to enable and use the three-finger screenshot gesture on the RaemonD K80 tablet.

4.2 Wi-Fi Connectivity

To connect to a Wi-Fi network:

1. Go to **Settings > Network & Internet > Wi-Fi**.
2. Toggle Wi-Fi **On**.
3. Select your desired network from the list and enter the password if prompted.

4.3 Camera Usage

The tablet features a 5MP front camera and an 8MP rear camera. Open the Camera app to take photos or record videos. Tap the screen to focus and press the shutter button to capture.

HD Dual Camera - Show Your Beauty

5MP+8MP lens, take photos and videos more



Take pictures



Video call

Image: The Raemon K80 Tablet illustrating its dual camera capabilities for taking pictures and making video calls.

4.4 Security and Privacy

Protect your tablet with a screen lock. Go to **Settings > Security & Privacy > Device unlock**. You can choose from Pattern, PIN, or Password. Face Unlock is also available for quick access.

Your browser does not support the video tag.

Video: Demonstrates how to access and configure security and privacy settings, including setting a screen lock, on the Raemon K80 tablet.



Safety Facial Recognition

Perfect for quick logins while keeping hands free

Image: The Raemond K80 Tablet showcasing its Safety Facial Recognition feature for quick and secure logins.

5. MAINTENANCE

5.1 Cleaning the Tablet

Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid using harsh chemicals or abrasive materials that could damage the surface.

5.2 Battery Care

To prolong battery life, avoid extreme temperatures and do not allow the battery to fully discharge frequently. For optimal performance, charge the tablet when the battery level is low.

Shocking Display, High-definition Enjoyment

10 Inch high-definition screen, the picture quality is delicate and realistic, enjoy the movie and television feast.



1280*800
Screen Resolution



Eye-care
CareMode



16:10
Aspec Ratio

Image: The RaemonD K80 Tablet emphasizing its 6000mAh high-capacity battery for extended usage.

5.3 Software Updates

Regularly check for system updates to ensure your tablet has the latest features and security patches. Go to **Settings > System > System updates**.

6. TROUBLESHOOTING

6.1 Tablet Not Turning On

Ensure the tablet is sufficiently charged. Connect it to the charger and wait a few minutes before attempting to power it on again. If it still doesn't turn on, try holding the power button for 10-15 seconds for a forced restart.

6.2 Apps Crashing or Freezing

Close and reopen the app. If the issue persists, clear the app's cache (Settings > Apps > [App Name] > Storage & cache > Clear cache). If problems continue, consider uninstalling and reinstalling the app.

6.3 Wi-Fi Connection Issues

Restart your tablet and your Wi-Fi router. Forget the network on your tablet (Settings > Network & Internet > Wi-Fi > [Network Name] > Forget) and then reconnect.

6.4 Slow Performance

Close unnecessary background apps. Clear cached data regularly (Settings > Storage > Cached data). Consider uninstalling apps you no longer use to free up storage space.

7. SPECIFICATIONS

Model	K80
Operating System	Android 15
Processor	T615 Octa-Core (1.8 GHz)
RAM	24GB (8GB + 16GB virtual)
Internal Storage	128GB ROM
Expandable Storage	Up to 1TB via microSD card
Display	10.1-inch IPS HD (1280x800 pixels)
Cameras	Front: 5MP, Rear: 8MP
Battery	6000mAh
Connectivity	Wi-Fi 6 (802.11a/b/g/n/ac), Bluetooth 5.4, GPS
Ports	USB-C, 3.5mm Headphone Jack
Dimensions	9.55 x 6.35 x 0.31 inches
Weight	1.18 pounds

8. WARRANTY AND SUPPORT

Your RaemonD K80 tablet comes with a**2-year warranty**. For technical assistance, setup questions, or any other inquiries, please contact RaemonD customer service. We offer **24/7 online customer service support**

Enjoy Stereo Sound Quality Dual Smart Boxes Speakers

The k80 is also equipped with a smart amplifier chip 1217 series so that you can enjoy better sound quality. It is also designed with a 3.5mm headphone jack to meet the needs of different users



Momentum
Dual Box Speakers



3.5mm
Headphone Jack



Image: A RaemonD customer service representative ready to assist with product inquiries.

Additionally, a **30-day money-back guarantee** and free returns are available.

© 2026 RaemonD. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question