

SVITOO SVITOO P10KIDS

SVITOO 10-Inch Kids Tablet User Manual

Model: SVITOO P10KIDS

INTRODUCTION

Welcome to the user manual for your new SVITOO 10-Inch Kids Tablet. This guide provides essential information for setting up, operating, maintaining, and troubleshooting your device. Please read this manual thoroughly to ensure optimal performance and a safe user experience for your child.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 10-Inch Android 15 Tablet (Pink)
- Shockproof EVA Case
- USB-C Charging Cable
- Quick Start Guide
- 1-Year Manufacturer Warranty Information

BEST GIFT FOR KID AGE 3-12 YEARS



Christmas Gifts



Birthday Gifts



Festival Gifts



Popular Gifts

PRODUCT FEATURES

- **Operating System:** Android 15 with advanced parental controls.
- **Display:** 10-inch HD IPS Touchscreen (1280 x 800 pixels) with Eye Protection Night Mode.
- **Processor:** High-Performance Octa-Core CPU (Unisoc T7200).
- **Memory & Storage:** 20GB RAM (3GB + 17GB expandable) and 64GB internal storage, expandable up to 1TB via microSD card (sold separately).
- **Battery:** 6000mAh High-Capacity Battery, providing up to 12 hours of average usage.
- **Connectivity:** Dual-Band Wi-Fi (2.4/5 GHz), Bluetooth 5.0, Built-in GPS Navigation.
- **Cameras:** 8MP Rear Camera and 2MP Front Camera.
- **Audio:** Dual Box Speakers, 3.5mm Headphone Jack.
- **Durability:** Kid-friendly EVA Shockproof Case with 360° Rotating Handle and 180° Rotating Stand.
- **Certifications:** GMS Certified Google Play, Widevine L1 HD Streaming Certified.



Image: Overview of the SVITOO Kids Tablet's main features.

SETUP

1. Charging the Tablet

Before first use, fully charge the tablet using the provided USB-C charging cable and power adapter. The charging port is located on the side of the tablet. A full charge typically takes several hours.

6000mAh

All-Day Battery Life

Endless Play Power Through The Entire Day.



Night Mode



Energy Saving



9H
Video



12H
Music



12H
Browsing



60Days
Standby

Image: Tablet connected to charger, illustrating battery life.

2. Powering On/Off

To power on, press and hold the Power ON/OFF button located on the side of the tablet until the screen lights up. To power off, press and hold the Power ON/OFF button, then select 'Power off' from the on-screen options.

3. Initial Configuration

Follow the on-screen prompts to complete the initial setup:

- **Language Selection:** Choose your preferred language.
- **Wi-Fi Connection:** Connect to a stable Wi-Fi network. This is essential for downloading apps and updates.
- **Google Account:** Sign in with an existing Google account or create a new one. This is required for accessing Google Play Store and parental controls.
- **Parental Controls (Google Kids Space):** Set up Google Kids Space to manage content, screen time, and app access for your child. This feature allows you to create a safe digital environment.

Video: Demonstration of setting up parental controls on the SVITOO Kids Tablet.

Description: This video illustrates the process of configuring parental controls, including setting up Google Kids Space, to ensure a safe and

OPERATING INSTRUCTIONS

1. Basic Navigation

The tablet uses a touch-based interface. Swipe to navigate between screens, tap to open apps, and pinch to zoom. The navigation bar at the bottom of the screen provides quick access to Home, Back, and Recent Apps.

2. Using Parental Controls (Google Kids Space)

Google Kids Space offers a curated library of apps, books, and videos suitable for children. Parents can:

- Set daily screen time limits.
- Approve or block specific apps and websites.
- Monitor app usage and activity.
- Track your child's location (if enabled).

Access parental control settings through the dedicated app or your linked parent device.



Image: Illustration of Smart Google Family Link Parental Controls features.

3. Installing and Managing Apps

Apps can be downloaded from the Google Play Store. Within Google Kids Space, parents can approve apps for their children. To manage installed apps, go to Settings > Apps & notifications.

4. Media Playback

The tablet supports various media formats. With Widevine L1 HD Streaming certification, you can enjoy high-definition content from supported streaming platforms. Use the built-in video player or download third-party apps.

5. Camera Usage

The tablet features an 8MP rear camera and a 2MP front camera. Open the Camera app to take photos or record videos. The EVA case has cutouts for both cameras.

6. GPS Navigation

The integrated GPS allows for location tracking and navigation using compatible map applications. This can be useful for travel or for parents to monitor the tablet's location.

7. Eye Protection Mode

Activate Eye Protection Night Mode in the display settings to reduce blue light emission, promoting better eye comfort during extended use, especially in low-light conditions.



Image: Tablet displaying Eye Protection Mode for comfortable viewing.

8. Using the Shockproof EVA Case

The durable EVA case protects the tablet from drops and bumps. It features a 360° rotating handle that can also be converted into a 180° rotating stand for hands-free viewing.

Drop-Resistant Design



180° Rotating Stand

360° Rotating Handle



Image: The tablet's drop-resistant design with rotating stand and handle.

Video: A detailed overview of the SVITOO 10-Inch Android Tablet, showcasing its features and design.

Description: This video provides a comprehensive look at the tablet's functionalities, including its display, performance, and user interface, suitable for a kids' learning and entertainment device.

MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid abrasive cleaners or solvents.
- **Storage:** Store the tablet in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the tablet regularly and avoid leaving it plugged in for extended periods after it's fully charged.
- **Software Updates:** Regularly check for and install system updates to ensure optimal performance and security.

TROUBLESHOOTING

Issue	Possible Solution
Tablet won't turn on	Ensure the battery is charged. Press and hold the power button for 10-15 seconds to perform a forced restart.
Apps are slow or freezing	Close unnecessary background apps. Clear app cache (Settings > Apps & notifications > [App Name] > Storage & cache > Clear cache). Restart the tablet.
Wi-Fi connection issues	Restart the tablet and your Wi-Fi router. Forget the network and reconnect. Ensure you are within range of the Wi-Fi signal.
Screen is unresponsive	Perform a forced restart. If the issue persists, contact customer support.
Parental controls not working	Ensure Google Kids Space is properly configured and linked to your parent account. Check for app updates.

SPECIFICATIONS

Feature	Detail
Model Number	SVITOO P10KIDS
Operating System	Android 15
Screen Size	10 Inches
Screen Resolution	1280 x 800 pixels (HD IPS)
Processor	Unisoc T7200 Octa-Core CPU (1.6 GHz)
RAM	20GB (3GB + 17GB expandable)
Internal Storage	64GB
Expandable Storage	Up to 1TB via microSD card
Battery Capacity	6000mAh (Average 12 hours life)
Wireless Connectivity	802.11ac, 802.11b, 802.11g, 802.11n (Dual-Band 2.4/5 GHz)
Bluetooth	Bluetooth 5.0
Cameras	Rear: 8MP, Front: 2MP
Ports	USB Type-C, 3.5mm Headphone Jack
Dimensions (LxWxH)	9.7 x 6.4 x 0.4 inches
Item Weight	2.42 pounds

WARRANTY AND SUPPORT

Your SVITOO Kids Tablet comes with a **1-Year Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or natural disasters.

For warranty claims, technical support, or any inquiries, please refer to the contact information provided in your Quick Start Guide or reach out to the SVITOO Official Store via your Amazon order details.



A Professional Tablet Factory
with Over 15 Years of Expertise



One Year
Protection



FCC
Certification



One Year
Protection



Return
For Exchange



Excellent
Customer Service

Contact: Amazon
order - Contact Us

From Factory to Hands:
1-Year Protection, End-to-End Peace of Mind

*Does not cover damage caused by man, natural disasters or other force majeure.

Image: Detailed view of the tablet's ports and controls.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F5V1K543>

More documents and user manuals: <https://manuals.plus/>